

4PL-2.4G

Frequency Hopping Spread Spectrum

2.4GHz
S-FHSS

*Digital Proportional
R/C System
for Use with Surface Models*



INSTRUCTION MANUAL

CE0682

1M23N24105

Futaba[®]

Digital Proportional R/C System

Thank you for purchasing a Futaba 4PL-2.4GHz system.
Before using your 4PL-2.4GHz system, read this manual carefully in order to use
your R/C set safely.

After reading this manual, store it in a safe place.

Application, Export, and Modification

1. This product may be used for models only. It is not intended for use in any application other than the control of models for hobby and recreational purposes.
2. Exportation precautions:
 - (a) When this product is exported from the country of manufacture, its use is to be approved by the laws governing the country of destination for devices that emit radio frequencies. If this product is then re-exported to other countries, it may be subject to restrictions on such export. Prior approval of the appropriate government authorities may be required. If you have purchased this product from an exporter outside your country, and not the authorized Futaba distributor in your country, please contact the seller immediately to determine if such export regulations have been met.
 - (b) Use of this product with other than models may be restricted by Export and Trade Control Regulations, and an application for export approval must be submitted.
3. Modification, adjustment, and replacement of parts: Futaba is not responsible for unauthorized modification, adjustment, and replacement of parts on this product. Any such changes may void the warranty.

Compliance Information Statement (for U.S.A.)

This device, trade name Futaba Corporation of America, model number R2104GF, complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference.
- (2) This device must accept any interference received, including interference that may cause undesired operation.

The responsible party for the compliance of this device is:

Futaba Service Center

3002 N Apollo Drive Suite 1, Champaign, IL 61822 U.S.A.

TEL (217)398-8970 or E-mail: support@futaba-rc.com (Support)

TEL (217)398-0007 or E-mail: service@futaba-rc.com (Service)

Battery Recycling (for U.S.A.)



The RBRC™ SEAL on the (easily removable) nickel-cadmium battery and nickel-metal-hydride battery contained in Futaba products indicates that Futaba Corporation of America is voluntarily participating in an industry program to collect and recycle these batteries at the end of their useful lives, when taken out of service within the United States. The RBRC™ program provides a convenient alternative to placing used nickel-cadmium batteries and nickel-metal-hydride batteries into the trash or municipal waste system, which is illegal in some areas.

You may contact your local recycling center for information on where to return the spent battery. Please call 1-800-8-BATTERY for information on NiCd/NiMH battery recycling in your area. Futaba Corporation of America's involvement in this program is part of its commitment to protecting our environment and conserving natural resources.

NOTE: Our instruction manuals encourage our customers to return spent batteries to a local recycling center in order to keep a healthy environment.

RBRC™ is a trademark of the Rechargeable Battery Recycling Corporation.

-
- No part of this manual may be reproduced in any form without prior permission.
 - The contents of this manual are subject to change without prior notice.
 - This manual has been carefully written. Please write to Futaba if you feel that any corrections or clarifications should be made.
 - Futaba is not responsible for the use of this product.

For Your Safety As Well As That Of Others.....8

Explanation of Symbols.....	8
2.4GHz System Precautions.....	8
High Speed Mode Precautions.....	8
Operation Precautions.....	9
Ni-MH/Ni-Cd Battery Handling Precautions	10
Storage And Disposal Precautions	11
Other Precautions	11

Before Using12

Features	12
Set Contents	14
TransmitterT4PL	15
Nomenclature.....	15
Battery Replacement Method.....	16
Low Battery Alarm.....	16
When Using The Optional Battery.....	17
Charging The Battery	17
Power & Display Switch.....	18
High Voltage Alarm.....	18
Display When Power Switch Is Turned On	19
LCD Screen Contrast	19
Power Off Forgotten Alarm.....	19
Digital Trim Operation.....	20
Grip Lever Operation.....	20
Mechanical ATL Adjustment.....	21
Wheel & Trigger Tension Adjustment.....	21
Trigger Slide Adjustment	22
About Transmitter Antenna And Receiver.....	22
About The Transmitter Antenna.....	22
Receiver Terminology.....	23
How To Link The Transmitter And The Receiver	23
Receiver Installation	24

Installation25

Receiver And Servo Connections	25
Installation Safety Precautions	26

Initial Set-Up29

Preparations (Transmitter).....	29
---------------------------------	----

Function Map32

Operation Of Screen	32
Function List.....	35
Characters Selection.....	36

Functions38

Model/Receiver Type/Servo Response Mode "MODEL RX" ...	38
Model/Receiver Mode Menu Display.....	38
Model Selection "SEL"	39
Model memory call	
Model Copy "COPY"	40
Model memory copy	
Model Reset "RESET"	41
Model memory reset	
Receiver Mode "RX MODE".....	42
Model Name "MDL NAME"	43
Model memory name set/modify	
Servo Reverse "REV"	44
Servo operation reversing	
Subtrim "SUBTR"	45
Servo center position fine adjustment	
End Point Adjuster "EPA"	46
End point adjustment	
Fail Safe/Battery Fail Safe Function "F/S"	49
Fail safe, battery fail safe	
Steering EXP "STR EXP"	51
Steering operation curve adjustment	
Throttle EXP "THR EXP"	52
Throttle curve adjustment	
Steering Speed "SPEED"	54
Steering servo delay	
Throttle Speed "SPEED"	56
Throttle servo delay	
Throttle Acceleration "ACCFW/ACCBK"	57
Function which adjusts the movement characteristic from the throttle neutral position	
Displaying Other Functions Of Each Channel Menu	59
Trim, D/R, ATL, Channel 3/4 Position, etc.	
Function Select Trim/Dial "TRIM, DIAL"	60
Selection of functions operated by dial and digital trim	

**For Your Safety
As Well As
That Of Others**

**Before
Using**

Installation

**Initial
Set-Up**

**Function
Map**

Functions

Reference

Function Select Switch "SWITCH"	62
Selection of functions operated by switches	
Advance Menu "ADVANCE"	64
Brake mixing, 4WS mixing, A.B.S, neutral brake, and other special functions	
Programmable Mixing "PROG MIX"	66
Programmable mixing between arbitrary channels	
A.B.S. Function "A.B.S"	68
Pulse brake	
Brake Mixing "BRAKE"	72
Front and rear independent brake control for 1/5GP car, etc.	
4WS Mixing "4WS MIX"	74
Special mixing used with Crawler and other 4WS type vehicles	
Dual ESC Mixing "DUAL ESC"	76
Special mixing used with Crawler and other 4WD type vehicles	
Throttle Mode "THR MODE"	78
Throttle Servo Neutral Position "SXNT"	78
Throttle servo forward and brake operation proportion setting	
Idle-Up "IDLUP"	79
Idle up at engine start	
Neutral brake "NTBRK"	80
Neutral brake function	
Throttle Off (Engine Cut) "THOFF"	81
Engine cut off by switch	
ESC Link Function "MC LINK"	82
Special function, Futaba ESC (MC950CR, MC851C, MC602C, MC402CR, etc.)	
Timer Function "TIMER"	86
Up, Fuel down, or lap timer	
Lap List "LAP LIST"	92
Lap timer data check	
System Functions "SYSTEM"	93
Liquid crystal screen contrast adjustment	
Liquid crystal screen backlighting display mode setup	
Backlight display time setup	
Battery type setting	
Buzzer sound tone adjustment	
The power off forgotten alarm setting	
Item which displays the basic menu screen in katakana characters for Japanese use	
Adjuster "ADJUSTER"	97
Steering wheel and throttle trigger correction	

Reference99

Ratings	99
Warning Displays	100
Optional Parts	102
When requesting repair	102

**For Your Safety
As Well As
That Of Others**

**Before
Using**

Installation

**Initial
Set-Up**

**Function
Map**

Functions

Reference

Use this product in a safe manner. Please observe the following safety precautions at all times.

Explanation of Symbols

The parts of this manual indicated by the following symbols are extremely important and must be observed.

Symbols	Explanation
 Danger	Indicates a procedure which could lead to a dangerous situation and may cause death or serious injury if ignored and not performed properly.
 Warning	Indicates procedures which may lead to dangerous situations and could cause death or serious injury as well as superficial injury and physical damage.
 Caution	Indicates procedures that may not cause serious injury, but could lead to physical damage.

Symbols:

 : Prohibited

 : Mandatory

2.4GHz System Precautions

Warning

 Special attention should be paid before turning on the system while other cars are running or other airplanes are flying because the 2.4GHz RC system could potentially affect them.

 Be sure to set the Fail Safe function.

High Speed Mode Precautions

Caution

 When using the T4PL in the high speed (HIGH) mode, always use it under the following conditions:

Servos :Futaba digital servo (including BLS Series brushless servos)

Receiver's battery :Matched to the ratings of the receiver and connected digital servo (dry cell battery cannot be used).

Transmitter mode :HIGH mode (See p.42 for setting method.)

Under other conditions, the set will not operate, or the specified performance will not be displayed even if it operates. In addition, it may cause servo trouble. Futaba will not be responsible for damage, etc. caused by combination with the products of other companies.

In addition, the FSU Fail Safe Unit cannot be used because the system is different. Use the fail safe function of the transmitter.

 When using analog servos, always switch the T4PL servo response to the "NORM" mode.

Transmitter mode : "NORM" mode (See p.42 for setting method.)

Receiver's battery :Matched to the ratings of the receiver and connected servo (dry cell battery cannot be used).

The set cannot operate in the "HIGH" mode. Operation in this mode will cause trouble with the servo and other equipment.

Digital servos (including BLS Series brushless servos) can also be used in the "NORM" mode.

Operation Precautions

Warning

⚠ Do not operate outdoors on rainy days, run through puddles of water or use when visibility is limited.
Should any type of moisture (water or snow) enter any component of the system, erratic operation and loss of control may occur.

⚠ Do not operate in the following places.

- Near other sites where other radio control activity may occur.
- Near people or roads.
- On any pond when passenger boats are present.
- Near high tension power lines or communication broadcasting antennas.

Interference could cause loss of control. Improper installation of your Radio Control System in your model could result in serious injury.

⚠ Do not operate this R/C system when you are tired, not feeling well or under the influence of alcohol or drugs.

Your judgment is impaired and could result in a dangerous situation that may cause serious injury to yourself as well as others.

⚠ Do not touch the engine, motor, speed control or any part of the model that will generate heat while the model is operating or immediately after its use.

These parts may be very hot and can cause serious burns.

ⓘ Always perform an operating range check prior to use.

Problems with the radio control system as well as improper installation in a model could cause loss of control.

(Simple range test method)

Have a friend hold the model, or clamp it down or place it where the wheels or prop cannot come in contact with any object. Walk away and check to see if the servos follow the movement of the controls on the transmitter. Should you notice any abnormal operation, do not operate the model. Also check to be sure the model memory matches the model in use.

ⓘ Turning on the power switches.

Always check the throttle trigger on the transmitter to be sure it is at the neutral position.

1. Turn on the transmitter power switch.
2. Turn on the receiver or speed control power switch.

Turning off the power switches

Always be sure the engine is not running or the motor is stopped.

1. Turn off the receiver or speed control power switch.
2. Then turn off the transmitter power switch.

If the power switches are turned off in the opposite order, the model may unexpectedly run out of control and cause a very dangerous situation.

ⓘ When making adjustments to the model, do so with the engine not running or the motor disconnected.

You may unexpectedly lose control and create a dangerous situation.

Caution

(Fail safe function)

Before running (cruising), check the fail safe function.

Check Method; Before starting the engine, check the fail safe function as follows:

- 1) Turn on the transmitter and receiver power switches.
- 2) Wait at least one minute, then turn off the transmitter power switch. (The transmitter automatically transfers the fail safe data to the receiver every minute.)
- 3) Check if the fail safe function moves the servos to the preset position when reception fails.
The fail safe function is a safety feature that minimizes set damage by moving the servos to a preset position when reception fails. However, if set to a dangerous position, it has the opposite effect. When the reverse function was used to change the operating direction of a servo, the fail safe function must be reset.
Setting example: Throttle idle or brake position

NiMH / NiCd Battery Handling Precautions

(Only when NiMH/NiCd batteries are used)

Warning

Never plug the charger into an outlet of other than the indicated voltage.

Plugging the charger into the wrong outlet could result in an explosion or fire.

Never insert or remove the charger while your hands are wet.

You may get an electric shock.

Do not use the transmitter's battery, HT5F1700B, as the receiver's battery.

Since the transmitter's battery has an overload protection circuit, the output power will be shut down when the high current load is applied. This may result in runaway or fatal crash.

Always check to be sure your batteries have been charged prior to operating the model.

Should the battery go dead while the model is operating, loss of control will occur and create a very dangerous situation.

To recharge the transmitter battery, use the special charger made for this purpose.

Overcharging could cause the battery to overheat, leak or explode. This may lead to fire, burns, loss of sight and many other types of injuries.

Caution

Do not use commercial AA size NiCd and NiMH batteries.

Quick charging may cause the battery contacts to overheat and damage the battery holder.

Do not short circuit the battery terminals.

A short circuit across the battery terminals may cause abnormal heating, fire and burns.

Do not drop the battery or expose it to strong shocks or vibrations.

The battery may short circuit and overheat; electrolyte may leak out and cause burns or chemical damage.

When the model is not being used, always remove or disconnect the battery.

Leaving the battery connected could create a dangerous situation if someone accidentally turns on the receiver power switch. Loss of control could occur.

ⓘ Always keep the charger disconnected from the outlet while it is not in use.

Storage and Disposal Precautions

⚠ Warning

⊘ Do not leave the radio system or models within the reach of small children.

A small child may accidentally operate the system. This could cause a dangerous situation and injuries. Ni-Cd batteries can be very dangerous when mishandled and cause chemical damage.

⊘ Do not throw NiMH/NiCd batteries into a fire. Do not expose batteries to extreme heat. Also do not disassemble or modify a battery pack.

Overheating and breakage will cause the electrolyte to leak from the cells and cause skin burns, loss of sight, and other injuries.

ⓘ When the system will not be used for any length of time, store the system with HT5F1700B batteries in a discharged state. Be sure to recharge the batteries prior to the next time the system is used.

If the batteries are repeatedly recharged in a slightly discharged state, the memory effect of the Ni-MH/Ni-Cd battery may considerably reduce the capacity. A reduction in operating time will occur even when the batteries are charged for the recommended time. (After discharge to 1cell E.V.=1V)

<NiMH/NiCd Battery Electrolyte>

The electrolyte in NiCd/NiMH batteries is a strong alkali. Should you get even the smallest amount of the electrolyte in your eyes, DO NOT RUB. Wash immediately with water, and seek medical attention at once. The electrolyte can cause blindness. If electrolyte comes in contact with your skin or clothes, wash with water immediately.

⚠ Warning

⊘ Do not store your R/C system in the following places.

- Where it is extremely hot or cold.
- Where the system will be exposed to direct sunlight.
- Where the humidity is high.
- Where vibration is prevalent.
- Where dust is prevalent.
- Where the system would be exposed to steam and condensation.

Storing your R/C system under adverse conditions could cause deformation and numerous problems with operation.

ⓘ If the system will not be used for a long period of time, remove the batteries from the transmitter and model and store in a cool, dry place.

If the batteries are left in the transmitter, electrolyte may leak and damage the transmitter. This applies to the model also. Remove the batteries from it also to prevent damage.

<NiMH/NiCd/Li-ion Battery Recycling>

A used battery is a valuable resource. Insulate the battery terminals and dispose of the battery by taking it to a battery recycling center.

Other Precautions

⚠ Caution

⊘ Do not expose plastic parts to fuel, motor spray, waste oil or exhaust.

The fuel, motor spray, waste oil and exhaust will penetrate and damage the plastic.

ⓘ Always use only genuine Futaba transmitters, receivers, servos, ESCs (electronic speed controls), NiMH/NiCd batteries and other optional accessories.

Futaba will not be responsible for problems caused by the use of other than genuine Futaba parts. Use the parts specified in the instruction manual and catalog.

Features

-2.4GHzSS (Spread Spectrum) radio communication system

Frequency channel setting is unnecessary: Channel shifting takes place within the 2.4GHz band automatically. This system minimizes the interference from other 2.4GHz systems.

-Model memory for 40 models

Model names can use up to 10 letters, numbers, and symbols, so that logical names may be used. A model memory with different setups can be created by using the model copy function.

- Menu Selection

The setup screens are called from menu screens. The menu screen can be selected from among 2 levels (LEVEL1/LEVEL2).

-Brake mixing for large cars (BRAKE)

Brake mixing of the front and rear wheels of 1/5GP and other large cars can be adjusted independently.

-4WS Mixes (4WS MIX)

This function can be used with crawlers and other 4WS type vehicles.

-Anti-skid braking system (A.B.S)

This function applies the brakes so that the tires of gasoline engine cars, etc. do not lose their grip on the road even when braking at corners.

-Throttle acceleration (ACCFW/ACCBK)

Gasoline engine cars have a time lag before the clutch and brakes become effective. The throttle acceleration function reduces this time lag.

-Throttle speed (SPEED)

Sudden trigger operation on a slippery road surface will only cause the tires to spin and the model to not accelerate smoothly. By setting the throttle speed function, operation can be performed smoothly and easily. It also suppresses battery consumption.

-Steering speed (SPEED)

When you sense that the steering servo is too fast, etc., the servo operating speed (direction that suppresses the maximum speed) can be adjusted.

-Racing timer (TIMER)

The lap timer can record 100 lap times and total time. The timer can also be started automatically by trigger operation. The race time and audible alarm can be set. Re-/fueling time are indicated by an audible alarm. An up timer is also provided.

-Digital trim

The current trim position is displayed on the LCD screen. The operating amount of 1 step can also be adjusted. Trim operation has no effect on the maximum travel of the steering and throttle servos.

-Function select trim/ dial function (TRIM DIAL)

This function assigns functions to dials (digital trim, digital dial). The step amount and operating direction can also be adjusted. Trim positioning at each model call is unnecessary because all the dials are digital.

-Function select switch function (SWTCH)

This function assigns functions to 2 switches. The operating direction can also be set.

-ESC-Link function (MC-LINK)

This is a dedicated function which allows setting of the contents of the Link software which makes possible Futaba speed controller (ESC), MC950CR, MC850C, MC851C, MC602C, MC402CR, etc. variable frequency and other data changes by T4PL.

-Trigger position can be changed

The position of the throttle trigger can be moved forward and backward.

-Tension adjustment function

The tension of the steering wheel & throttle trigger springs can be adjusted from the outside.

-Mechanical ATL Adjustment

Make this adjustment when you want to decrease the total travel of the brake (push) side of the throttle trigger.

-Display switch

Display switch allows function setup without transmitting.

Set Contents

After opening the box, first check if the contents conform to the following. The contents depend on the set as shown below.

Before Using

Transmitter	T4PL
Receiver	R2104GF
Miscellaneous	<p style="text-align: center;">Dry battery holder *Installed in transmitter.</p> <p style="text-align: center;">Receiver switch</p> <p style="text-align: center;">Mini screwdriver * It is used for R2104GF.</p> <p style="text-align: center;">Instruction manual</p>

- If any of the set contents are missing, or you have any questions, please contact your dealer.

Caution

! When using the T4PL in the high speed (HIGH) mode, always use it under the following conditions:

Servos :Futaba digital servo (including BLS Series brushless servos)

Receiver's battery :Matched to the ratings of the receiver and connected digital servo (dry cell battery cannot be used).

Transmitter mode : "HIGH" mode (See page 42 for setting method.)

Under other conditions, the set will not operate, or the specified performance will not be displayed even if it operates. In addition, it may cause servo trouble. Futaba will not be responsible for damage, etc. caused by combination with the products of other companies.

In addition, the FSU Fail Safe Unit cannot be used because the system is different. Use the fail safe function of the transmitter.

! When using analog servos, always switch the T4PL servo response to the "NORM" mode.

Transmitter mode : "NORM" mode (See page 42 for setting method.)

Receiver's battery :Matched to the ratings of the receiver and connected digital servo (dry cell battery cannot be used).

The set cannot operate in the "HIGH" mode. Operation in this mode will cause trouble with the servos and other equipment.



Digital servos (including BLS Series brushless servos) can also be used in the "NORM" mode.

! Always use only genuine Futaba transmitters, receivers, servos, ESCs (electronic speed controls), NiMH, NiCd, Li-ion batteries and other optional accessories.

Futaba will not be responsible for problems caused by the use of other than Futaba genuine parts. Use the parts specified in the instruction manual and catalog.

Transmitter T4PL

Nomenclature



*The switches, dial, and trimmers in the figure are shown in the initial setting position.



Before Using

Battery Replacement Method (4 AA Size Batteries)

Load the four batteries in accordance with the polarity markings on the battery holder.

Battery Replacement Method

- 1** Remove the battery cover from the transmitter by sliding it in the direction of the arrow in the figure.
- 2** Remove the used batteries.
- 3** Load the new AA size batteries. Pay very close attention to the polarity markings and reinsert accordingly.
- 4** Slide the battery cover back onto the case.



Check:

Turn the power switch on the transmitter to the ON position. Check the battery voltage display on the LCD screen. If the voltage is low, check the batteries for insufficient contact in the case or incorrect battery polarity.

Disposal of the Dry Cell Batteries:

The method to dispose of used dry cell batteries depends on the area in which you reside. Dispose of the batteries in accordance with the regulations for your area.

⚠ Caution

- ⊘ Do not use commercial AA size NiCd and NiMH batteries.

Quick charging may cause the battery contacts to overheat and damage the battery holder.



- ❗ Insert the batteries in the correct polarity.

If the polarity is incorrect, the transmitter may be damaged.

- ❗ When the transmitter is not in use, remove the batteries.

If the battery electrolyte leaks, wipe off the case and contacts.


Low Battery Alarm

If the transmitter battery voltage drops to 5.0V (when using dry cell battery: 4.2V) or less, an audible alarm will sound and "BATTERY LOW VOLTAGE" will be displayed on the LCD screen.

⚠ Warning

- ❗ When a low battery alarm is generated, cease operation immediately and retrieve the model.

If the battery goes dead while in operation, you will lose control of the model.



When using the optional battery

When using an optional rechargeable battery, replace the battery as described below.

- Always use the optional HT5F1700B or FT2F2100B rechargeable battery.
- When the transmitter will not be used for a long time, remove the battery.
- When using the optional HT5F1700B or FT2F2100B (LiFe) battery, always set the battery type "BATT" to "N5/L2". (See page 93 for the battery types).

Battery Replacement Method

- 1** Refer to the previous description and remove the transmitter battery cover.
- 2** After removing the dry cell battery box from the transmitter, disconnect the connector.
- 3** Insert the connector of the new battery and load the new battery into the transmitter.
- 4** Finish by installing the battery cover.

⚠ Caution

- ❗ When closing the battery cover, be careful that the battery cover does not pinch the battery lead wires.
- Shorting of the battery lead wires may lead to fire and abnormal heating and cause burns or fire disaster.


Charging the battery

Charging method


(Example: When using the HT5F1700B with the special charger)

- 1** Plug the transmitter cord of the special charger into the charging jack on the rear of the transmitter.
- 2** Plug the charger into an AC outlet.
- 3** Check that the charging LED lights.

The charging time when charging the HT5F1700B battery with the optional special charger is approximately 15 hours. However, when the battery has not been used for some time, repeat charging 2 or 3 times to activate the battery. Charge the optional FT2F2100B (LiFe) battery with the special charger in accordance with the instruction manual supplied.



Charging jack



When using Futaba CR-2000

The HT5F1700B is 5-cells, so, when charging the HT5F1700B battery with Futaba CR-2000 charger, you have to use the RX output side.

Over current protection

The transmitter charging circuit is equipped with an over current protection circuit (1.0A). If the battery is charged with a quick charger for other than digital proportional R/C sets, it may not be fully charged.

⚠ Warning

⊘ Never plug it into an outlet of other than the indicated voltage.
Plugging the charger into the wrong outlet could result in an explosion or fire.

⊘ Do not insert and remove the charger when your hands are wet.
It may cause an electric shock.

❗ Always use the special charger or a quick charger for digital proportional R/C sets to charge a digital proportional R/C set Ni-MH battery.
Overcharging a Ni-MH battery can result in burns, fire, injuries, or loss of sight due to overheating, breakage, or electrolyte leakage.



⚠ Caution

⊘ Never try to recharge a dry cell battery.
The transmitter may be damaged or the battery electrolyte may leak or the battery may break.

❗ When the charger is not in use, disconnect it from the AC outlet.
Do this to prevent accidents and to avoid overheating.

Power & Display Switch


The power switch and display switch of the T4PL are integrated. In the PWR ON mode, radio waves are transmitted and in the DISP mode, model data, settings can be checked without transmitting radio waves.



High Voltage Alarm

If a battery exceeding 8V is used with the T4PL, an audible alarm will sound and "BATTERY HIGH VOLTAGE" will be displayed on the LCD screen.


Immediately remove the battery because it may cause damage to the T4PL.



Precautions when turning the power switch on and off.

When the data is changed using the edit keys or trim levers, wait at least two seconds before turning off the power. If the power is turned off within two seconds after the data is changed, the new data will not be written to memory.

Display when power switch is turned on



LCD Screen Contrast

The LCD screen contrast can be adjusted. (For more information, see page 93.)

Caution


Do not adjust the contrast so that the LCD is too bright or too dark.
 When the display cannot be read due to a temperature change, data cannot be set.

Power Off Forgotten Alarm

When the steering wheel, throttle trigger, push switch, or edit button are not operated for 10 minutes (default), an alarm sounds and "NOT OPERATED FOR A LONG TIME" is displayed on the LCD screen.

When the steering wheel, throttle trigger, push switch, or edit button are operated, the alarm is reset. If the system is not to be used, turn off the power.

The function can be deactivated at the system menu (p.93).




Digital Trim Operation

(Initial settings: DT1: Steering trim, DT2: Throttle trim,)

Operating by the lever: Push the lever to the left or right (up or down) The current position is displayed on the LCD screen.

Before Using



- Each step is indicated by a tone.
- When the trim exceeds the maximum trim adjustment range, the beep will change and the servo will not move any farther.
- Trim lever adjustments have no effect on the maximum servo travel. This prevents the linkages from binding when adjustments are made.


Trim Operation

With the center trim feature, trim adjustments have no effect on the maximum servo travel. This prevents the linkages from binding when adjustments are made.

Grip Lever Operation

(Initial setting: DT3: Steering D/R, DT4: ATL)

Operate the dials by turning them. The current set value is displayed on the LCD screen.



- Each step is indicated by a tone.
- When the trim exceeds the maximum trim adjustment range, the tone will change pitch and the servo will not move any farther.

Mechanical ATL Adjustment


Make this adjustment when you want to decrease the stroke of the brake (back) side of the throttle trigger for operation feel.

Adjustment

1 Using a 2.5mm hex wrench, adjust the trigger brake (reverse) stroke. (The screw moves the throttle trigger stopper.)

- When the screw is turned clockwise, the stroke becomes narrower. Adjust the stroke while watching the screw.

**Mechanical ATL
adjusting screw**



Note:

Once you have changed the mechanical stroke on the brake side, be sure to adjust the scale of the throttle channel accordingly by using the "Adjuster Function" (page 97).

Due to this change, you also need to adjust in most cases the travel of the throttle servo by using "End point Adjuster".

Before Using


Wheel & Trigger Tension Adjustment

Make this adjustment when you want to change the wheel or trigger spring's tension.

Adjustment

1 Using a 1.5mm hex wrench, adjust the wheel spring tension by turning the screw inside the adjusting hole in the arrow direction.

- The spring is set to the weakest tension at the factory.
- When the adjusting screw is turned clockwise, the spring tension increases.



**Wheel tension
adjusting screw**

**Trigger tension
adjusting screw**

Note:


The adjustment range is up to 7 to 8 turns from the fully tightened (strongest) position. If turned farther than this, the adjusting screw may fall out.

Trigger Slide Adjustment

The throttle trigger position can be moved forward and backward.

Adjustment



- 1 Using a 2.5mm hex wrench, loosen the trigger slide mounting screw by turning it slightly counterclockwise.
- 2 Using a 2.5mm hex wrench, turn the trigger slide adjusting screw, and adjust the trigger slide position within the marked range. When the adjusting screw is turned clockwise, the trigger slide moves away from the grip handle.
- 3 Retighten the mounting screw loosened at step 1 and fasten the trigger slide.



Before Using

About Transmitter Antenna and Receiver

About The Transmitter Antenna




⚠ Warning

- ❗ Adjust the antenna vertically to the ground.
Otherwise, the operating range may become shorter.

- ⊘ Never hold only the antenna.
Hold the grip handle. Otherwise, the antenna may be damaged.

- ⊘ The antenna position can be changed in the range as shown in figures A and B. However, please do not apply unnecessary force or shock.
The internal cable may be damaged; thus transmitting distance decreases and it may cause malfunction.

Receiver Terminology



Connectors


- 4 :CH4 servo(CH4)
- 3 :CH3 servo(CH3)
- 2 :Throttle servo(CH2)
- 1 :Steering servo(CH1)
- B :Power connector

How to link the transmitter and the receiver

Each transmitter has an individually assigned, unique ID code. In order to start operation, the receiver must be linked with the ID code of the transmitter to which it is being paired. Once the link is made, the ID code is stored in the receiver and no further linking is necessary unless the receiver needs to be used with another transmitter.

Link procedure

- 1** Bring the transmitter and the receiver close to each other, within 20 inches (half meter).
- 2** Turn on the transmitter.
- 3** Turn on the receiver.
- 4** Push the tactile switch of the receiver.
When the link is complete, the LED in the receiver changes to solid green.



Precaution:

If there are many Futaba S-FHSS/FHSS systems turned on in close proximity to the R2104GF, your receiver might not link to your transmitter. In this case, even if the receiver's LED stays solid green, unfortunately the receiver might have established a link to one of other transmitters. This is very dangerous if you do not notice this situation. In order to avoid the problem, we strongly recommend you to double-check whether your receiver is really under control by your transmitter by giving the stick input and then checking the servo response.

*Please refer to the table below for LED status vs receiver's condition.

LED status vs receiver's condition:

No signal reception	Red : On
Receiving signals	Green: On
Receiving signals, but ID is unmatched.	Green: Blink *1

*1: LED could be change to red during intermittently during data processing.

⚠ Warning

❶ After the linking is done, please cycle receiver power and check if the receiver to be linked is really under the control of your transmitter.

⊘ Do not perform the linking procedure with motor's main wire connected or the engine operating as it may result in serious injury.


Receiver Installation

Install the R2104GF receiver on the car as follows:

The operating range may become shorter, depending on where the receiver and the antenna are mounted.

⚠ WARNING

- ⊘ Do not cut or bundle the receiver antenna wire.
- ⊘ Do not bend the coaxial cable. It causes damage.
- ❶ Install the antenna in the higher place as shown in the figure.
- ❶ Put the antenna in the antenna tube to protect it.
- ❶ Keep the antenna as far away from the motor, ESC and other noise sources as you possibly can.
- ❶ Wrap the receiver with something soft, such as foam rubber, to avoid vibration. If there is a chance of getting wet, put the receiver in a waterproof bag or balloon.



Before Using

⚠ Caution

- ❶ Always use R2104GF under the following conditions:
 - Battery :Power requirement Rated voltage 4.8~7.4V (dry cell battery cannot be used) / 3.5 to 8.4V useable
Matched to the ratings of the receiver and connected servo.
 - RX Type : "SFH" or "FH" (See p.42 for setting method.)
 - Transmitter mode-"HIGH" mode :Futaba digital servo (See p.42 for setting method.)
 - Transmitter mode-"NORM" mode :Futaba all servo (See p.42 for setting method.)
- Under other conditions, the set will not operate, or the specified performance will not be displayed even if it operates. In addition, it may cause trouble with servos and other equipment. Futaba will not be responsible for damage, etc. caused by combination with the products of other companies.

Transmitter mode setting

Set the transmitter to the "HIGH" mode or "NORM" mode. See page 42 for a description of the setting method.

Note: However, digital servos (including BLS Series brushless servo) can only be used in the HIGH mode.


When the power is turned on, whether the receiver is in the "HIGH" or "NORM" mode the R2104GF operates in that mode until the power is turned off. When the transmitter mode is changed, operation becomes possible when the receiver power is turned on again.

Receiver and Servo Connections


Connect the receiver and servos as shown below. Connect and install the receiver and servos in accordance with "Installation Safety Precautions" on the next page.

The figure shown below is an example. The method of connecting the motor controller to the motor and battery depends on the motor controller used. Purchase the motor controller and servos separately. The receiver also depends on the set.

Installation When An Electronic Speed Control Is Used



Installation For Gas Powered Models



Installation Safety Precautions


⚠ Warning

Receiver (receiver antenna)

- ⊘ Do not cut or bundle the receiver antenna wire.
- ⊘ Do not bundle the receiver antenna wire together with the motor controller lead wire.
- ⊘ Keep the receiver antenna wire at least 1cm away from motor, battery, and other wiring carrying heavy current.
- ❗ Install the receiver antenna holder as closely as possible to the receiver.

If the antenna wire is cut, bundled, or routed near a noise source, the receiving sensitivity will drop, the running (sailing) range will decrease, and you may lose control of the model.

*Noise is transmitted through metal, carbon, and other conductive material, so keep the receiver antenna wire away from such parts.



Install the receiver as far away as possible from the battery, motor controller, motor, silicon cord and other noise sources. Keep it away from the antenna wire, in particular.

Receiver vibration-proofing / waterproofing


(Car)

- ❗ Vibration-proof the receiver by wrapping it in foam rubber or other vibration-absorbing material and mount it with thick double-sided tape.
- ❗ When using the receiver holder supplied with the model kit, mount the holder to the chassis through a rubber grommet.

(Boat)

- ❗ Vibration-proof the receiver by wrapping it in foam rubber or other vibration-absorbing material. Also waterproof the receiver by sealing it in a plastic bag.

If the receiver is exposed to strong vibration and shock, it will operate erroneously due to the invasion of water drops and you may lose control of the model.




Warning

Connector Connections

- ❗ Be sure the receiver, servo, battery and connectors are fully and firmly connected.
If vibration from the model causes a connector to work loose while the model is in operation, you may lose control.


Servo Installation

- ❗ When you install the servos, always use the rubber grommets provided in servo hardware bags. Mount the servos so they do not directly come in contact with the mount.
If the servo case comes in direct contact with the mount, vibration will be directly transmitted to the servo.
If this condition continues for a long time, the servo may be damaged and control will be lost.



Servo Throw

- ❗ Operate each servo over its full stroke and be sure the linkage does not bind or is loose.
The continuous application of unreasonable force to a servo may cause damage and excessive battery drain.



Warning

Electronic Speed Control


- ❗ Install the heat sinks where they will **not** come in contact with aluminum, carbon fiber or other parts that conduct electricity.

If the FET Amp (Electronic speed control) heat sinks touch other materials that conduct electricity a short circuit could occur. This could result in loss of control and damage to the system.

Motor Noise Suppression

- ❗ Always install capacitors to suppress noise when electric motors are used.

If capacitors are not properly installed you could experience erratic operation and reduced range as well as loss of control.



Motors with no suppressor capacitors, or inadequate suppression, may cause the receiver to malfunction. Always solder the capacitors supplied to your motor.

The Schottky diode improves the efficiency of the speed control / motor combination and provides extra protection to the brake FETs. The white ring must always face the positive side.

Other Noise Suppression Methods

- ❗ Be sure there are no metal parts in your model which under vibration can come in contact with other metal parts.


Metal to metal contacts under vibration will emit a high frequency noise that will affect the receiver's performance. You could experience erratic operation and reduced range as well as loss of control.

Preparations (Transmitter)

Before setting the Transmitter functions, check and set items 1 to 4 below.


(Display when power switch turned on)

When the power switch is turned on, the currently selected model number is displayed. Check if this number is the model number you want to set-up. To change the model number, use the Model Select function (See page 39).




1.Rx Type Check

The T4PL transmitter can use both FHSS 2.4GHz system and increased response S-FHSS 2.4GHz system receivers. The R2104GF receiver supplied with the T4PL set can be used in both the FHSS type and S-FHSS type modes by automatic recognition. As the FHSS type mode cannot be used when the FHSS 2.4GHz system R603GF/R2004GF receiver is used, check the setting. If the setting is incorrect, change it using "RX MODE" (P42). Which RX type is set can be checked with the HOME screen.



2. Servo Response Mode Check


When the RX type is set to S-FHSS 2.4GHz (SFH), the servo response mode can be set to the high speed mode (HIGH). However, check if the servos used are compatible. When using digital servos (including BLS Series brushless servos), either "HIGH" or "NORM" can be used. Since "HIGH" cannot be used with other analog servos, the servo response mode must be set to "NORM". If the setting is incorrect, change it using "RX MODE" (P42). When the RX type is set to FHSS 2.4GHz (FH) the high speed mode cannot be selected



"HIGH" is displayed for high speed type and nothing is displayed for normal type.

3. Throttle Mode Check

The throttle servo travel can be set to 5:5 or 7:3 for throttle trigger operation as required by the throttle mode function (page 78).



F5/B5 or F7/B3



4. Trims Initial Set-Up

- Steering trim (DT1) check

On the initial set-up, steering trim is assigned to the DT1 trim lever above the steering wheel. Operate the lever and make sure the marker moves on the ST graph. If default has been changed, test steering trim in its new location. After checking the trim, set the trim display to the center (N) position.


- Throttle trim (DT2) check

On the initial set-up, throttle trim is assigned to the DT2 trim lever on the left side of the steering wheel. Operate the lever and make sure the marker moves on the TH graph. If the default has been changed, test the throttle trim in its new location. After checking the trim, set the trim display to the center (N) position.




- Steering dual rate (DT3) check

At initial set-up, steering dual rate (D/R) is assigned to the DT3 lever, at the grip of the transmitter. Operate the DT3 and check if the D/R value displayed on the screen changes. After checking D/R, set the steering dual rate to 100%.



- Throttle ATL (DT4) check

At initial setting, throttle ATL (ATL) is assigned to the DT4 lever, below the DT3. Operate the DT4 and check if the ATL value displayed on the screen changes. After checking ATL, set throttle ATL to 100%.



(Set-Up Procedure When Installed In a Car)

When installing the servos in a car, performing function set-up in the following order is recommended.

- 1** Perform step 1 to 4. Trims Initial Set-Up of Preparations on the preceding page.
- 2** Set the servo direction of operation using the Reverse function. (p.44)
 - The servo installation method and linkage direction depend on the kit. Therefore, the servo operation direction may have to be reversed relative to transmitter operation. Before installing the servo, check the operating direction and set it using the Reverse function.
- 3** Set the subtrim and adjust the servo neutral point. (p.45)
- 4** Set the trigger travel by adjusting the throttle trigger mechanical ATL to your liking. (p.21)
 - When the stroke was adjusted, compensate the throttle by adjuster function (See page97).
- 5** Set EPA of each channel and adjust the servo throw (travel). (p.46)

Operation of screen

In this instruction manual, Edit Buttons are represented by the symbols shown below.


Calling the menu screen

The item indicated by the reverse displayed cursor is selected.


The cursor is moved up and down with the (UP) and (DN) buttons.

A screen with the ▼ symbol at the bottom is on the next page.


The figure at the right shows the state in which STEERING is selected on the menu screen.



Edit Buttons



STEERING is selected on the menu screen.





Item selection

The items move in the order shown in the figure above.


Switch of screen

When the (CT) button is pressed after selecting an item using the (UP) and (DN) buttons on the HOME screen as shown in the figure at the right, that screen can be directly displayed.



For example, when MENU is selected and the (CT) button is pressed, the MENU screen can be displayed; when timer display is selected and the (CT) button is pressed, the timer setting screen can be displayed; and when MODEL is selected and the (CT) button is pressed, the MODEL RX screen can be displayed.



(MENU screen)




(MODEL RX screen)



(TIMER screen)


When the (CT) button is pressed at all the screens, an item preceded by an * is displayed to its setup screen. For example, when *STEERING is selected at the MENU screen and the (CT) button is pressed, that item is displayed to the steering related setup screen and REV (servo reverse), SUBTR (sub trim), EPA (end point adjuster), and other functions can be set.



STEERING selected by pressing the (UP) or (DN) button on the menu screen. (STEERING 1 screen) THROTTLE selected by pressing the (UP) or (DN) button on the STEERING 1 screen. (THROTTLE screen)


Value of each function and changing the set value


Values, settings, and other data on all the function setting screens are changed with the (+) and (-) buttons.



Returning to the menu screen and HOME screen

Return from a setting screen to the menu screen and HOME screen as follows:






Function list

Function abbreviation	Description of function	Page No
MODEL RX	Model memory call/ Model memory copy/ Model memory reset Servo response mode and receiver type selection	P-38
REV	Servo operation reversing	P-44
SUBTR	Servo center position fine adjustment	P-45
EPA	End point adjustment	P-46
F/S	Fail safe, battery fail safe	P-49
STR EXP	Steering curve adjustment	P-51
THR EXP	Throttle curve adjustment	P-52
SPEED (ST)	Steering servo delay	P-54
SPEED (TH)	Throttle servo delay	P-56
ACCFW/BK	Function which adjusts the rise characteristic from the throttle neutral position	P-57
TRIM. DIAL	Selection of functions operated by digital dial and digital trim	P-60
SWITCH	Selection of functions operated by switches	P-62
PROG MIX	Programmable mixing between arbitrary channels	P-66
A.B.S	Pumping brake	P-68
BRAKE MIX	Front and rear independent brake control for 1/5GP car, etc.	P-72
4WS MIX	4WS mixing	P-74
DUAL ESC	Front and rear ESCs mixing	P-76
THR MODE	Throttle servo forward side and brake side operation rate setting/ Neutral brake/ Idle up at engine start/ engine cut off by switch	P-78
MC LINK	MC950CR/851C/602C/402CR/850C/601C/401CR Link software setting function	P-82
TIMER	Up, down, or lap timer	P-86
LAP LIST	Lap timer data (lap time, total time) check	P-92
SYSTEM	LCD contrast/backlight/Battery type/buzzer/power off forgotten alarm/Basic menu character display	P-93
ADJUSTR	Steering wheel and throttle trigger correction	P-97

Characters selection




Edit Buttons

In this instruction manual, Edit Buttons are represented by the symbols shown at left.

Basic menu Japanese Katakana character display


On the system menu, the basic menu screen shown below can be displayed in Japanese katakana characters.

Alphabetic characters	"KATAKANA" characters
STEERING	ステアリング
THROTTLE	スロットル
MODEL RX	モデル RX
ADVANCE	アドバンス
CH3 CH4	CH3 CH4
DIAL SW	ダイヤルスイッチ
SYSTEM	システム



Changing the character

Function Map




After changing the setting, select <MENU> and press (CT).
On the menu screen, when <HOME> is selected and (CT) is pressed, the LCD returns to the HOME screen.

Menu level selection

A menu screen divided into steering system and throttle system can be selected from the following two types at each model memory.

- LEVEL 1: Displays the basic steering and throttle functions.
- LEVEL 2: Displays all the steering and throttle functions.



LEVEL1

<p style="text-align: center;">STEERING-1</p> <div style="border: 1px solid black; padding: 5px;"> <p style="text-align: center;">STEERING 1</p> <p>REV : NOR</p> <p>TRIM : 0</p> <p>SUBTR: 0</p> <p>EPA-L: 100</p> <p>EPA-R: 100</p> <p>D/R : 100</p> <p>*THROTTLE</p> <p style="text-align: center;">▼</p> </div>	<p style="text-align: center;">THROTTLE-1</p> <div style="border: 1px solid black; padding: 5px;"> <p style="text-align: center;">THROTTLE 1</p> <p>REV : NOR</p> <p>TRIM : 0</p> <p>SUBTR: 0</p> <p>EPA-F: 100</p> <p>EPA-B: 100</p> <p>ATL : 100</p> <p>*STEERING</p> <p style="text-align: center;">▼</p> </div>
<p style="text-align: center;">STEERING-2</p> <div style="border: 1px solid black; padding: 5px;"> <p style="text-align: center;">STEERING 2</p> <p>F/S : OFF</p> <p>POSI: (FREE)</p> <p style="text-align: center;">▼</p> </div>	<p style="text-align: center;">THROTTLE-2</p> <div style="border: 1px solid black; padding: 5px;"> <p style="text-align: center;">THROTTLE 2</p> <p>F/S : OFF</p> <p>POSI: (FREE)</p> <p>BFS : ---</p> <p style="text-align: center;">▼</p> </div>

LEVEL2

<p style="text-align: center;">STEERING-1</p> <div style="border: 1px solid black; padding: 5px;"> <p style="text-align: center;">STEERING 1</p> <p>REV : NOR</p> <p>TRIM : 0</p> <p>SUBTR: 0</p> <p>EPA-L: 100</p> <p>EPA-R: 100</p> <p>D/R : 100</p> <p>*THROTTLE</p> <p style="text-align: center;">▼</p> </div>	<p style="text-align: center;">THROTTLE-1</p> <div style="border: 1px solid black; padding: 5px;"> <p style="text-align: center;">THROTTLE 1</p> <p>REV : NOR</p> <p>TRIM : 0</p> <p>SUBTR: 0</p> <p>EPA-F: 100</p> <p>EPA-B: 100</p> <p>ATL : 100</p> <p>*STEERING</p> <p style="text-align: center;">▼</p> </div>
<p style="text-align: center;">STEERING-2</p> <div style="border: 1px solid black; padding: 5px;"> <p style="text-align: center;">STEERING 2</p> <p>F/S : OFF</p> <p>POSI: (FREE)</p> <p>*EXP : 0</p> <p>SPEED</p> <p>TURN: 100</p> <p>RETN: 100</p> <p style="text-align: center;">▼</p> </div>	<p style="text-align: center;">THROTTLE-2</p> <div style="border: 1px solid black; padding: 5px;"> <p style="text-align: center;">THROTTLE 2</p> <p>F/S : OFF</p> <p>POSI: (FREE)</p> <p>BFS : ---</p> <p>*EXPF: 0</p> <p>*EXPB: 0</p> <p>SPEED: 100</p> <p>ACCFW: 0</p> <p>ACCBK: 0</p> <p>*THR MODE</p> <p style="text-align: center;">▼</p> </div>


Model / Receiver Type / Servo Response Mode "MODEL RX"

Forty model data (data for 40 R/C cars) can be saved in the T4PL transmitter. This menu selects the model, copies data between models, sets the menu which sets the model name, and sets the mode of the receiver used.



Model/receiver mode menu display

The MODEL RX menu screen can be displayed by the following 2 methods:

On the HOME screen, the MODEL RX menu screen can be displayed by selecting MODEL by (UP) or (DN) button and pressing the (CT) button.



On the HOME screen, open the MENU screen by selecting MENU by (UP) or (DN) button and pressing the (CT) button. Next, display the MODEL RX screen by selecting MODEL RX by (UP) or (DN) button and pressing the (CT) button.



Model Selection "SEL"

Forty model data (model data for 40 R/C cars) can be saved in the 4PL transmitter and used when the relevant model data is called.

Using the model select function

- Display the MODEL RX menu by referring to P38.

1 (Selection of model select)

Move the cursor to MODE by (UP) or (DN) button and select "SEL" with the (+) or (-) button.

```
MODEL RX
M1
MODEL-M1
MODE: SEL
M-No: M1
EXEC: ---
MODEL-M1
*MDL NAME
<RX MODE>
TYPE: SFH
RESP: NORM
```

Move the cursor to MODE and select "SEL" with the (+) or (-) button.

2 (Model No. selection)

Move the cursor to M-No by (UP) or (DN) button and select the model number with the (+) or (-) button. "M1" ~ "M40" are displayed.

```
MODEL RX
M1
MODEL-M1
MODE: SEL
M-No: M2
EXEC: +/-
MODEL-M2
*MDL NAME
<RX MODE>
TYPE: SFH
RESP: NORM
```

Model #.
M1~M40

Move the cursor to M-No and select model # with the (+) or (-) button.

3 (Model select execution)

Move the cursor to EXEC:+/- by (UP) or (DN) button and press the (+) and (-) buttons simultaneously for approximately 1 second. A beeping sound is generated and the model is selected.

- Model change is complete when the model No. and model name on the screen change.

```
MODEL RX
M1
MODEL-M1
MODE: SEL
M-No: M2
EXEC: +/-
MODEL-M2
*MDL NAME
<RX MODE>
TYPE: SFH
RESP: NORM
```

Move the cursor to EXEC:+/- and press the (+) and (-) buttons simultaneously for approximately 1 second.

```
MODEL RX
M2
MODEL-M2
MODE: SEL
M-No: M2
EXEC: ---
MODEL-M2
*MDL NAME
<RX MODE>
TYPE: SFH
RESP: NORM
```

Modified model # and model name

4 When ending, return to the menu screen by pressing the (CT) button.

When the receiver type and servo response were changed to a different model (FH, SFH or HIGH, NORM) and the type was changed to a different model, signals are output by previous model type until the transmitter power is turned off. Use after turning the transmitter power off and on.

Model Copy "COPY"

The contents of the currently selected model data can be copied to another model.

Using the model copy function

- Display the MODEL RX menu by referring to P38.

1 (Selection of model select)

Move the cursor to MODE by (UP) or (DN) button and select "COPY" with the (+) or (-) button.

```
MODEL RX
M1
MODEL-M1
MODE: COPY
M1 → M2
EXEC: +/-
MODEL-M2
*MDL NAME
<RX MODE>
TYPE: SFH
RESP: NORM
```

Move the cursor to MODE and select "COPY" with the (+) or (-) button.

2 (Model No. selection)

Move the cursor to M-No by (UP) or (DN) button and select the copy destination model number with the (+) or (-) button. "M1" ~ "M40" are displayed.

```
MODEL RX
M1
MODEL-M1
MODE: COPY
M1 → M2
EXEC: +/-
MODEL-M2
*MDL NAME
<RX MODE>
TYPE: SFH
RESP: NORM
```

Model #.
M1-M40

Move the cursor to M-No and the copy destination model # with the (+) or (-) button.

3 (Model copy execution)

Move the cursor to EXEC:+/- by (UP) or (DN) button and press the (+) and (-) buttons simultaneously for approximately 1 second. A beeping sound is generated and the model data is copied.

```
MODEL RX
M1
MODEL-M1
MODE: COPY
M1 → M2
EXEC: +/-
MODEL-M2
*MDL NAME
<RX MODE>
TYPE: SFH
RESP: NORM
```

Move the cursor to EXEC:+/- and press the (+) and (-) buttons simultaneously for approximately 1 second.

-Copying is complete when "OK!" is displayed on the screen.

```
MODEL RX
M1
MODEL-M1
MODE: COPY
M1 → M2
EXEC: OK!
MODEL-M1
*MDL NAME
<RX MODE>
TYPE: SFH
RESP: NORM
```

"OK!" is displayed.

Model name is also copied.

4 When ending, return to the menu screen by pressing the (CT) button.

Model Reset "RESET"

This function resets and initializes the contents of the currently selected model data.

However, the adjuster function (ADJUSTER), system setting (SYSTEM), and type of receiver mode (TYPE)/servo response (RESP) are not initialized.

Using the model reset function

- Display the MODEL RX menu by referring to P38.

1 (Selection of model reset)

Move the cursor to MODE by (UP) or (DN) button and select "RESET" with the (+) or (-) button.

```
MODEL RX
M1
MODEL-M1
MODE:RESET
M-No: *M1
EXEC: +/-

*MDL NAME

<RX MODE>
TYPE: SFH
RESP: NORM
```

Move the cursor to MODE and select "RESET" with the (+) or (-) button.

2 (Model reset execution)

Move the cursor to EXEC: +/- by (UP) or (DN) button and press the (+) and (-) buttons simultaneously for approximately 1 second. A beeping sound is generated and the model data is reset.

-Resetting is complete when "OK!" is displayed on the screen.

```
MODEL RX
M1
MODEL-M1
MODE:RESET
M-No: *M1
EXEC: +/-

*MDL NAME

<RX MODE>
TYPE: SFH
RESP: NORM
```

Move the cursor to EXEC: and press the (+) and (-) buttons simultaneously for approximately 1 second.

```
MODEL RX
M1
MODEL-M1
MODE:RESET
M-No: *M1
EXEC: OK!

*MDL NAME

<RX MODE>
TYPE: SFH
RESP: NORM
```

"OK!" is displayed.

3 When ending, return to the menu screen by pressing the (CT) button.

When the receiver type and servo response (FH, SFH or HIGH, NORM) were changed on the MODEL RX menu screen, the change is not complete until the power is turned on again. When receiver type or servo response change followed by model reset were executed while the power was still on, the receiver type and servo response return to their previous mode. When the receiver type and servo response were changed, use the model reset function after turning the power off and on.

Receiver Mode

"RX MODE"

The T4PL transmitter has an FHSS 2.4GHz system transmit mode and an increased response S-FHSS 2.4GHz system transmit mode. The R2104GF supplied with the T4PL set can be used by both the S-FHSS (SFH) and FHSS(FH) type by automatic recognition. However, when the FHSS 2.4GHZ system R603GF/R2004GF is used, operation is impossible if it is not the FHSS(FH) type.

When the setting is incorrect, change it by "TYPE". Which RX type is set can be checked with the HOME screen.

Servos used

When the RX type is S-FHSS(SFH), the servo response can be selected from high speed (HIGH) and normal (NORM) mode. The high speed mode is exclusively for our digital servos (including BLS system brushless servo). When using other servos, select the normal mode. All servos, including digital servos, can be used in the normal mode. When the RX type is FHSS(FH), the high speed (HIGH) mode cannot be used.

Selecting the receiver type and servo response

- Display the MODEL RX menu by referring to P38.

(Preparation)

- Select TYPE or RESP on the RX MODE menu screen by (UP) or (DN) button.

```

MODEL RX
M1
MODEL-M1

MODE: SEL
M-No: M1
EXEC: ---

*MDL NAME

<RX MODE>
TYPE: SFH
RESP: NORM
  
```

TYPE :Receiver type
RESP :Servo re response

→ Select "TYPE" or "RESP" by (UP) or (DN) button.

1 Select RX type or servo response with the (+) or (-) button.

```

MODEL RX
M1
MODEL-M1

MODE: SEL
M-No: M1
EXEC: ---

*MDL NAME

<RX MODE>
TYPE: SFH
RESP: HIGH
      (BLS DIGI)
  
```

TYPE
FH, SFH

RESP
HIGH (BLS DIGI)
NORM

→ Select RX type or servo response with the (+) or (-) button.


When the RX MODE setting was changed, and a model with an RX MODE setting different from the current model was selected, turn the transmitter power off and on. At that time the transmitter transmits in the set RX MODE.

Model name "MDL NAME"

A model name (up to 10 characters) can be registered for each model. Letters, symbols, and numbers can be used.


Model name input screen display

The model name input screen can be displayed by referring to P38 and displaying the MODEL RX menu and selecting MDL NAME by (UP) or (DN) button on the MODEL RX menu screen and pressing the (CT) button.




Setting the menu name


- 1 (Move the cursor to the character you want to change.)
Select the model name character you want to set or change by moving the cursor by (UP) or (DN) button. The selected character blinks.



- 2 (Selection of character to be used)
The character is decided when selected by (+) or (-) button.



Also move the cursor to "RES<+/->" by (UP) or (DN) button and press the (+) and (-) buttons simultaneously for approximately 1 second. A beeping sound is generated and the model name is initialized to the factory setting.



- 3 When ending, return to the menu screen by pressing the (CT) button.

Servo Reverse "REV"


(All channel)

This function reverses the direction of operation of the servos related to transmitter steering, throttle, and channel 3 /4 operation.

However, when the position set by trim or subtrim shifts from the center, the center becomes the opposite side.

Channel menu display

Display to each channel menu by the following method:



Function

Servo Reverse Function Setting

(Preparation)

Move the cursor to REV by (UP) or (DN) button

1 (Servo reverse setting)

Use the (+) or (-) button to reverse the servo operation direction.

(Each channel can be set similarly.)

2 When ending, return to the menu screen by pressing the (CT) button.

Reverse Function selection

- Move the cursor to REV by (UP) or (DN) buttons.

Select button



- Select with the (+) or (-) buttons.

Subtrim "SUBTR"

(All channel)


Use this function to adjust the neutral position of the steering, throttle, channel 3 and channel 4 servos.

*Subtrim adjusts the entire range of the servo in the set direction.



Use to adjust the neutral position

Refer to P44 and display the channel menus to be set.



Subtrim adjustment

(Preparation)

- Set the steering and throttle digital trims to the neutral "0" position. Set CH3 to the center "0" position.
- Refer to P44 and display the channel menus to be set.
- Move the cursor to SUBTR by (UP) or (DN) button.

1 (Subtrim adjustment)

Use the (+) or (-) button to adjust the center.

(Each channel can be set similarly.)

2 When ending, return to the menu screen by pressing the (CT) button.

Subtrim function selection

- Move the cursor to SUBTR by (UP) or (DN) buttons.

Adjust button

- Adjust with the (+) and (-) buttons.
- Return to the initial value "0" by pressing the (+) and (-) buttons simultaneously for about 1 second.

Subtrim

ST :L100~R100
 TH :B100~F100
 CH3 :-100~+100
 CH4 :-100~+100
 Initial value : 0

Function

End Point Adjuster "EPA"

(All channel)

Use this when performing left and right end point adjustments, throttle high side/brake side operation amount adjustment, channel 3 and channel 4 servo up side/down side operation amount adjustment during linkage.

- Correct the maximum steering angle for left and right steering angles when there is a difference in the turning radius due to the characteristics, etc. of the vehicle.

Maximum steering angle

The EPA function basically determines the maximum steering angle of each channel. The functions shown below may have been adjusted or the operating range set by EPA function may be exceeded. Check the linkage each time the following functions are adjusted.

- Sub trim (all channels)..... P45
- Program mixing slave side (all channels) P66
- Idle up (throttle) P79
- Throttle dff, Engine Cut (throttle)..... P81
- Throttle acceration (throttle)..... P57


ATL trim

ATL trim allows adjustment of the brake side operation amount during operation. Therefore, when the operating angle is adjusted with throttle EPA, ATL trim must also be taken into account.

Warning


❗ Operate each servo over its full stroke and be sure the linkage does not bind or is not loose.

The continuous application of unreasonable force to a servo may cause damage and excessive battery drain.



Decide the EPA value at the contact point.

Adjust the steering servo so that unreasonable force is not applied to the servo by the chassis at maximum servo travel.



Adjust the throttle servo so that unreasonable force is not applied when the engine carburetor is fully open, fully closed, and the brakes are applied fully.

If the brakes overheat while running, their ability to function properly decreases. Before running, adjust the suitable maximum servo travel so that unreasonable force is not applied even when the servo travel is increased while running.

Refer to P44 and display the channel menus to be set.

Channel menu screens

STEERING 1

REV : NOR

TRIM : 0

SUBTR: 0

EPA-L: 100

EPA-R: 100

D/R : 100

*THRATTLE

▼

Move the cursor to *STEERING by (UP) or (DN) button and press the (CT) button.

THRATTLE 1

REV : NOR

TRIM : 0

SUBTR: 0

EPA-F: 100

EPA-B: 100

ATL : 100

*STEERING

▼

UP DN

CH3

REV : NOR

POSI : 0

SUBTR: 0

EPA-U: 100

EPA-D: 100

F/S : OFF

POSI: (FREE)

▼

CH4

REV : NOR

POSI : 0

SUBTR: 0

EPA-U: 100

EPA-D: 100

F/S : OFF

POSI: (FREE)

▼

(STEERING 1 menu screen) (THRATTLE 1 menu screen) (CH3/CH4 menu screen)

Setting item (channel and direction)

EPA-L :Steering (left side)

EPA-R :Steering (right side)

EPA-F :Throttle (foward side)

EPA-B :Throttle (brake side)

EPA-U :3rd or 4th channel (up side)

EPA-D :3rd or 4th channel (down side)


Setting item selection (Steering and Throttle direction)

- The direction (EPA-L and EPA-R) linked with the steering wheel is switched.
- The direction (EPA-F and EPA-B) linked with the throttle trigger is switched.

Steering (EPA) adjustment


(Preparation)

- Display the STEERING 1 menus to be set.
- Before setup of the steering end point adjustment (EPA), set the steering D/R rever (initial setup: DT3) to the maximum steering angle position 100%.
- Select the setting item "EPA-L" by (UP) or (DN) button.




1 Steering (left side) adjustment

Turn the steering wheel fully to the left and use the (+) or (-) buttons to adjust the steering angle.



2 Steering (right side) adjustment

Turn the steering wheel fully to the right and use the (+) or (-) buttons to adjust the steering angle.



3 When ending, return to the menu screen by pressing the (CT) button.

Adjust button

Adjust with the (+) and (-) buttons.

- Return to the initial value "100" by pressing the (+) and (-) buttons simultaneously for about 1 second.

Steering EPA


EPA-L :0~120
 EPA-R :0~120
 Initial value :100

Function

Throttle (EPA) adjustment

(Preparation)


- Display the THROTTLE 1 menus to be set.
- Before setting the throttle end point adjustment(EPA), set the throttle ATL lever (initial setup: DT4) to the maximum throttle angle position 100%.
- Select the setting item "EPA-F" by (UP) or (DN) button.



(HOME screen)

1 Throttle (forward side) adjustment

Pull the throttle trigger fully to the high side and use the (+) or (-) buttons to adjust the throttle angle. However, when using an FET amp, set to 100%.



2 Throttle (brake side/reverse side) adjustment

Move the throttle trigger fully to the brake side and use the (+) or (-) buttons to adjust the throttle angle. However, when using an ESC, set to 100%.



3 When ending, return to the menu screen by pressing the (CT) button.

Adjust button

- Use the (+) and (-) buttons to make adjustments.
- Return to the initial value "100" by pressing the (+) and (-) buttons simultaneously for about 1 second.

Throttle EPA

EPA-F :0~120
EPA-B :0~120
Initial value :100

3rd & 4th channel servo (EPA) adjustment

(Preparation)

- Refer to P44 and display the channel 3 or channel 4 menu and make the following adjustments:

1 3rd/4th channel servo (up side) adjustment

Select the setting item "EPA-U" by (UP) or (DN) button, and set the 3rd or 4th channel dial fully to the up side (+ side) and use the (+) or (-) buttons to adjust the servo angle.

2 3rd/4th channel servo (down side) adjustment

Select the setting item "EPA-D" by (UP) or (DN) button, and set the 3rd or 4th channel dial fully to the down side (- side) and use the (+) or (-) buttons to adjust the servo angle.

3 When ending, return to the menu screen by pressing the (CT) button.

Adjust button

- Adjust with the (+) and (-) buttons.
- Return to the initial value "100" by pressing the (+) and (-) buttons simultaneously for about 1 second.

3rd & 4th channel EPA

EPA-U :0~120
EPA-D :0~120
Initial value :100

Fail Safe Mode (F/S)

This function moves each servo to a preset position when the receiver cannot receive the signals from the transmitter for some reason.

-When the condition set at "FH" is Rx type (P42), fail safe (F/S) can be set only for throttle (TH). Other channels are set to the normal mode.

-The fail safe data is transferred from the transmitter to the receiver 10 seconds after the transmitter power was turned on. The data is transferred every 5 seconds after that. Be careful because normally the transmitter power is turned on first and the receiver power is turned on next and the data is transferred for approximately 10 seconds after the receiver power is turned on.

-For gasoline engine cars, for safety we recommend that this fail safe function be used to set the throttle channel in the direction in which the brakes are applied.

Hold mode (HOLD)

This function holds the receiver in its position immediately before reception was lost. It is an R2104GF and other S-FHSS type receiver only function. When the receiver used is the R603GF/R2004GF FHSS type, this function cannot be used because the receiver type is set to "FH" by receiver type setting (p.42).

Off mode (OFF)

This function stops output of signals to the servos and places the servos into the free state when the receiver cannot receive.

The F/S, HOLD, and OFF modes are automatically reset when signals from the transmitter can be received again.


Battery fail safe function (BFS)

If the receiver battery voltage drops below a certain value when this function is enabled, the throttle servo moves to the position set by fail safe function. When the battery voltage recovers, the battery fail safe function is automatically reset.

-This function cannot be used when the throttle (TH) is not set to fail safe (F/S).

-This function is for the R2104FG and other S-FHSS types only. It cannot be used with the R603GF and R2004FG FHSS type.

Refer to P44 and display the channel menus to be set. For steering and throttle display the STEERING 2 screen and THROTTLE 2 screen by (UP) or (DN) button.



Fail safe mode selection

(Preparation)

- Refer to P44 and display the channel menus to be set. For steering and throttle, display the STEERING 2 screen and THROTTLE 2 screen by (UP) or (DN) button.

1 (Mode selection)

Select the mode by (+) or (-) button.

(Each channel can be individually set.)


- ### 2
- When ending hold or off mode setting, return to the menu screen by pressing the (CT) button. When setting fail safe, set the servo position by the following method.

F/S mode

OFF, HOLD, F/S

F/S mode selection

- Select with the (+) or (-) buttons.



Fail safe function setup

1 (Servo position setup)

When the fail safe function operates, select the setting item "POSI" by (UP) or (DN) button. The steering wheel, the throttle trigger or 3rd, 4th channel dial remains in the desired operation position. When the (+) and (-) buttons are pressed simultaneously for about 1 second, the servo position is displayed and you can confirm that the function was set.


When you want to release the setting, press the (+) or (-) button for 1 second. "HOLD" is displayed.

(Each channel can be set similarly.)

- ### 2
- When ending, return to the menu screen by pressing the (CT) button.

F/S position setup button

- The (+) and (-) buttons are pressed simultaneously for about 1 second.



Battery fail safe function ON/OFF

(Preparation)

- Select the setting item by (UP) or (DN) button. For BATT-F/S function ON/OFF, select "OFF" or "ACT" of "BFS".

1 (Battery fail safe function ACT/OFF)


The BFS function can be switched by (+) or (-) button.

- ### 2
- When ending, return to the menu screen by pressing the (CT) button.

Battery fail safe function

OFF, ACT

Initial value: OFF



When the receiver power supply of an electric car uses a common power supply from an ESC, we recommend that this function be set to OFF because the voltage supplied to the receiver may drop momentarily and the battery fail safe function may be activated.

Steering EXP "STR EXP"



(Steering system)

This function is used to change the sensitivity of the steering servo around the neutral position. It has no effect on the maximum servo travel.

Racers Tip

When the setting is not determined, or the characteristics of the model are unknown, start with 0%. (When EXP is set to 0%, servo movement is linear.)

Refer to P44 and display the STEERING 1 menu and the steering EXP screen by the following method. When set to LEVEL1 by menu level (P37), this function is not displayed.



Steering EXP adjustment

(Preparation)

- On the STEERING 1 screen, display the STEERING 2 screen by (UP) or (DN) button and make the following adjustments:

For graph screen display, adjustment is also possible on the graph screen by referring to the steering menu map of the preceding figure.

- 1 Select the setting item "*EXP" by (UP) or (DN) button. When you want to quicken steering operation, use the (+) button to adjust the + side. When you want to make steering operation milder, use the (-) button to adjust the - side.

- 2 When ending adjustment, move the cursor to an item other than "EXP" by (UP) or (DN) button and return to the menu screen by pressing the (CT) button.

Adjustment range

-100~0~+100

Adjust button

- Adjust with the (+) and (-) buttons.
- Return to the initial value "0" by pressing the (+) and (-) buttons simultaneously for about 1 second.

Function

Dial / Trim Setting

The steering EXP adjustment (RATE) can be controlled with digital dial or digital trim. With the function select dial function. (See page 60)

Throttle EXP "THR EXP"

(Throttle system)


This function makes the throttle high side and brake side direction servo operation quicker or milder. It has no effect on the servo maximum operation amount.

Advice


When the course conditions are good and the surface has good grip, set each curve to the + side (quick side). When the road surface is slippery and the drive wheels do not grip it, set each curve to the - minus (mild) side.

Refer to P44 and display the THROTTLE 1 menu and the throttle EXP screen by the following method. When set to LEVEL1 by menu level (P37), this function is not displayed.

EXPF (Forward)



EXPB (Brake/ Reverse)



Dial / Trim Setting


The throttle EXP adjustment (RATE) can be controlled with digital dial or digital trim, using the function select dial function. (See page 60)

Adjustment method for EXP curve

(Preparation)

- On the THROTTLE1 screen, display the THROTTLE2 screen by (UP) or (DN) button and make the following adjustments:

For graph screen display, adjustment is also possible on the graph screen by referring to the throttle menu map of the preceding figure.



Adjustment range

EXPF :Forward
EXPB :Brake/ Reverse

Adjustment range

-100 ~ 0 ~ +100%


Adjust button

Adjust with the (+) and (-) buttons.

- Return to the initial value "0" by pressing the (+) and (-) buttons simultaneously for about 1 second.


1 Forward Exponential Adjustment.

Select the setting item "*EXPF" by (UP) or (DN) button. Use the plus (+) button to adjust for a faster throttle response or use the minus (-) button for a slower or milder throttle response.



2 Brake Exponential Adjustment

Select the setting item "*EXPB" by (UP) or (DN) button. Use the plus (+) button to adjust for a faster brake response or use the minus (-) button for a slower or milder brake response.



Adjustment range

-100 ~ 0 ~ +100%

Adjust button

Adjust with the (+) and (-) buttons.


- Return to the initial value "0" by pressing the (+) and (-) buttons simultaneously for about 1 second.

- 3 When ending adjustment, move the cursor to an item other than "EXP-F"/"EXP-B" by (UP) or (DN) button and return to the menu screen by pressing the (CT) button.

Steering Speed "SPEED"


(Steering system)

Quick steering operation will cause momentary understeering, loss of speed, or spinning. This function is effective in such cases.




Operation

- This function limits the maximum speed of the steering servo. (Delay function)
- The steering speed when the steering wheel is operated (TURN direction) and returned (RETN direction) can be independently set.
- If the steering wheel is turned slower than the set speed, the steering servo is not affected.



Refer to P44 and display the STEERING 1 menu and the steering speed screen by the following method. When set to LEVEL1 by menu level (P37), this function is not displayed.

STEERING menu screens




Function

Steering Speed adjustment


(Preparation)

- On the STEERING 1 screen, display the STEERING 2 screen by (UP) or (DN) button and make the following adjustments:




1 "TURN" direction adjustment

Select the setting item "TURN" by (UP) or (DN) button, and use the (+) or (-) buttons to adjust the delay amount.



Adjustment range

1~100% (each direction)
At 100%, there is no delay.



Servo operation is delayed.

2 "RETURN" direction adjustment

Select the setting item "RETN" by (UP) or (DN) button, and use the (+) or (-) buttons to adjust the delay amount.



Adjust button

- Adjust with the (+) and (-) buttons.
- Return to the initial value "100" by pressing the (+) and (-) buttons simultaneously for about 1 second.

- ### 3
- When ending, return to the menu screen by pressing the (CT) button.

Setting example (Steering servo: BLS451 / BLS351) ... (Setting criteria)

- Onroad TURN side: Approx. 50~80% RETURN side: Approx. 60~100%
- Offroad TURN side: Approx. 70~100% RETURN side: Approx. 80~100%

Dial / Trim Setting

The steering speed adjustment "TURN" and "RETN" can be controlled with digital dial or digital trim. With the function select dial function. (See page 60)

Throttle Speed "SPEED"

(Throttle system)



Sudden throttle trigger operation on a slippery road only causes the wheels to spin and the vehicle cannot accelerate smoothly. Setting the throttle speed function reduces wasteful battery consumption while at the same time permitting smooth, enjoyable operation.



Operation

-Throttle servo (ESC) operation is delayed so that the drive wheels will not spin even if the throttle trigger is operated more than necessary.

This delay function is not performed when the throttle trigger is returned and at brake operation.



Throttle Speed adjustment

(Preparation)

- On the THROTTLE 1 screen, display the THROTTLE 2 screen by (UP) or (DN) button and make the following adjustments:

1 (Delay adjustment)

Select the setting item "SPEED" by (UP) or (DN) button, and use the (+) or (-) button to adjust the delay of the entire throttle forward side range.

2

When ending, return to the menu screen by pressing the (CT) button.

Adjustment range

1~100%

At 100%, there is no delay.

1% 100%



Servo operation is delayed.

Adjust button

- Adjust with the (+) and (-) buttons.
- Return to the initial value "100" by pressing the (+) and (-) buttons simultaneously for about 1 second.

Dial / Trim Setting


The throttle speed adjustment can be controlled with digital dial or digital trim. With the function select dial function. (See page 60)

Throttle Acceleration "ACCFW / ACCBK" (Throttle system)

The servo will jump to the input position at its maximum possible speed. Unlike exponential, which adjusts the whole throttle movement into a curve, throttle acceleration simply "jumps" away from neutral and then leaves the remaining response linear.

Operation

- Operation near the throttle trigger neutral position becomes a sharp rise.
- The forward and brake sides can be set separately.
- When the brake mixing function (p.72) is set, the CH3/CH4 brake can also be set.




Set value


The standard value (100% point) of this setup affects the operation amount set by throttle EPA function.

Convenient usage method

For gasoline engine cars, the linkage must have a clearance because one servo controls the engine carburetor and brake. Thus, there is a noticeable time delay at both the forward and brake sides. Sharp response comparable to that of electric motor cars is obtained by reducing this clearance at the transmitter side.




Refer to P44 and display the THROTTLE 1 menu and the throttle acceleration screen by the following method. When set to LEVEL1 by menu level (P37), this function is not displayed.



Throttle acceleration adjustment

(Preparation)

- On the THROTTLE 1 screen, display the THROTTLE 2 screen by (UP) or (DN) button and make the following adjustments:



1 (Forward acceleration amount adjustment)

Select the setting item "ACCFW" by (UP) or (DN) button and use the (+) and (-) buttons to adjust the acceleration amount.

"0" :No acceleration

"100" :Maximum acceleration (Approximately 1/2 of the forward side throttle angle)

2 (Brake side acceleration amount adjustment)

Select the setting item "ACCBK" by (UP) or (DN) button and use the (+) and (-) buttons to adjust the acceleration amount.

"0" :No acceleration

"100" :Maximum acceleration (Brake side maximum throttle angle)

4 When ending, return to the menu screen by pressing the (CT) button.

Forward acceleration amount (ACCFW)

0~100

Initial value: 0

Brake side acceleration amount (ACCBK)

0~100

Initial value: 0

Adjust button

Adjust with the (+) and (-) buttons.

- Return to the initial value "0" by pressing the (+) and (-) buttons simultaneously for about 1 second.

Dial / Trim Setting

The throttle acceleration adjustment amount (ACCFW), (ACCBK) can be controlled with digital dial or digital trim. With the function select dial function. (See page 60)


Displaying other functions of each channel menu (All channel)

In addition to the steering, throttle, CH3/4 REV, EPA, SUBTR, EXP, ACC, SPEED, F/S and other settings displayed before this page, TRIM/D/R, ATL, and CH3/4 POSI can be checked and adjusted on each channel menu screen.

When the TRIM D/R, ATL, and CH3/4 POSI functions are not assigned to trim/dial, they can be set on this screen.

When the functions displayed on this screen are assigned to trim/dial by function select dial function (P60), they are linked with that dial.

When CH3 or CH4 is set to SW by function select switch function (P62), they are linked to switch operation. Therefore be careful because when CH3/4 are adjusted on this screen, unintended operation may be performed when the switch was operated.



Rate/position adjustment on channel menu screen

1 (Function selection)

On each channel menu screen select D/R, ATL, POSI or other setting item by (UP) or (DN) button.

2 (Position setting/rate adjustment)

Adjust the position or rate with the (+) or (-) button.

3 When ending adjustment, return to the menu screen by pressing the (CT) button.

Adjust button

- Adjust with the (+) and (-) buttons.
- Return to the initial value "100" by pressing the (+) and (-) buttons simultaneously for about 1 second.

Channel 3 position (POSI)

Channel 4 position (POSI)

0~100%

Initial value: 0

D/R rate (D/R)

0~100%

Initial value: 100

Brake amount (ATL)

0~100%


Initial value: 100%

Function Select Trim Dial "TRIM DIAL"

Selection of the function to be performed by digital trim (DT1, DT2, DT3, DT4) and dial (DL1) and step amount adjustment and operation direction reversal can be performed by this function.

- The functions that can be assigned to dial and digital trim are listed on the next page.
- The step amount can be adjusted. (The relationship between set value and step amount is shown in the table on the next page.)
- The direction of operation of the servos can be reversed. (NOR/REV)

Display the function select trim/dial screen by as follows:



Function select dial setting

1 (Setting dial/trim selection)

Select the dial or trim you want to set by (UP) or (DN) button.

2 (Function setting)


Select the function with the (+) or (-) button.

- Refer to the list on the next page for the abbreviations of the functions.

(Step amount setting)

Select the step amount you want to set by (UP) or (DN) button. Set the step amount with the (+) or (-) button.

- Refer to the next page for the relationship between set value and step amount.




Adjust button

Adjust with the (+) and (-) buttons.

- Return to the initial value "2" by pressing the (+) and (-) buttons simultaneously for about 1 second.

3 When ending setting, return to the DIAL SW screen by pressing the (CT) button. To return to the menu screen, select <MENU> by (UP) or (DN) button and press the (CT) button and to return to the HOME screen select <HOME> by (UP) or (DN) button and press the (CT) button.



Relationship between set value and step amount

(Setting range: 1~10, 20, 30, 40, 50, 100, 2P)

-Steering trim/throttle trim

When set to the minimum "1", the total trim operating width is 200 clicks. For "100", the total operating width is 2 clicks and for 2P, the total operating width is 1 click.

-Rate, etc. setting

This is the % value which is operated by 1 click relative to the set value of each rate. Since the total operating width of functions having a rate of -100~0~+100 is 200%, when set to "100", the total operating width is 2 clicks. Since the total operating width of functions with a 0~100 rate is 100%, "100" and 2P are operated by 1 click.

-Channel 3/4

When set to the minimum "1", the total operating width of channel 3 is 200 clicks. For "100", the total operating with is 2 clicks and 2P is operated by 1 click.

Set table functions (DL1, DT1/DT2/DT3)

Abbreviation used on setup screen	Function name, etc
D/R	Dual rate function
ATL	ATL function
EXP-ST	Steering EXP
EXP-FW	Throttle EXP (Forward side)
EXP-BK	Throttle EXP (Brake side)
SPD-TN	Steering speed (Turn side)
SPD-RN	Steering speed (Return side)
ABS.PS	A.B.S. function (Return amount)
ABS.DL	A.B.S. function (Delay)
CYCLE	A.B.S. function (cycle speed)
ACC-FW	Throttle acceleration (Forward side)
ACC-BK	Throttle acceleration (Brake side)
TH-SPD	Throttle speed
ST-TRM	Steering trim
TH-TRM	Throttle trim
CH3	Channel 3
CH4	Channel 4
SUBTR1	Sub trim (CH1)
SUBTR2	Sub trim (CH2)
SUBTR3	Sub trim (CH3)
SUBTR4	Sub trim (CH4)
IDLE	Idle up function
ESC-RT	Dual ESC mixing (4ch ESC rate)
TH-OFF	Throttle off (engine cut)
PMX-A	Program mixing (RGHT/BRAK/DOWN sides)
PMX-B	Program mixing (LEFT/FWRD/UP sides)
BK3-RT	Brake mixing (3ch brake rate)
BK4-RT	Brake mixing (4th brake rate)
4WS-RT	4WS mixing (3ch steering rate)
OFF	Not used

Function Select Switch "SWITCH"


Selection of the function to be performed by push switch (SW1.PSH, PS2.SLD) and operation system setting can be performed by this function.

- The functions that can be assigned to each switch are listed on the next page.
- SW1.PSH alternate operation (operation which switches between ON and OFF each time the switch is pressed) is possible.

NOR (Normal) -ON only while pressed, OFF when released.

ALT (Alternate) -Switched between ON and OFF each time pressed.

Display the function select switch screen by as follows:



Function select switch setting

1 (Setting SW selection)

Select the SW you want to set by (UP) or (DN) button.

2 (Function setting)


Select the function with the (+) or (-) button.

-Refer to the list for the abbreviations of the functions.

(Changing the SW1.PSH operation system)

Select DIR of <SW1.PSH> by (UP) or (DN) button.


Select ALT or NOR with the (+) or (-) button.



Adjust button

Adjust with the (+) and (-) buttons.

- ### 3
- When ending setting return to the DIAL SW screen by pressing the (CT) button. To return to the menu screen, select <MENU> by (UP) or (DN) button and press the (CT) button and to return to the HOME screen select <HOME> by (UP) or (DN) button and press the (CT) button.




Set table functions (SW1. PSH)	
Abbreviation used on setup screen	Function name, etc
NT-BRK	Neutral brake function ON/OFF
ABS	A.B.S function ON/OFF
IDLE	Idle up function ON/OFF
PRGMIX	Program mixing function ON/OFF
TH-OFF	Throttle off (engine cut) function ON/OFF
CH3	channel 3
CH4	channel 4
4WS MIX	4WS mixing type select
TIMER	Timer function start/stop
OFF	Not used

Set table functions (SW2. SLD)	
Abbreviation used on setup screen	Function name, etc
NT-BRK	Neutral brake function ON/OFF
ABS	A.B.S function ON/OFF
IDLE	Idle up function ON/OFF
PRGMIX	Program mixing function ON/OFF
TH-OFF	Throttle off (engine cut) function ON/OFF
CH3	channel 3
CH4	channel 4
OFF	Not used

Function

Advance Menu "ADVANCE"

The brake mixing, 4WS mixing, ABS, neutral brake, and other special functions are set with the ADVANCE menu.



Advance function

<pre> PROG MIX MODE: INH LEFT: +100 RGHT: +100 MST : STR SLV : CH3 MXMD: OFF TRIM: OFF </pre> <p>Program mixing function</p>	<pre> A.B.S MODE: INH AB.P: 50 DELY: 0 CYCL: 10 TG.P: 30 DUTY: MID </pre> <p>A.B.S function</p>	<pre> BRAKE MIX <CH3> MODE: INH RATE: 100 DELY: 0 ABS : INH <CH4> MODE: INH RATE: 100 DELY: 0 ABS : INH <CH2> DELY: 0 </pre> <p>Brake mixing function</p>	<pre> 4WS MIX MODE: INH <NO SW> RATE: 100 MXMD: OFF ▶SWITCH▶ </pre> <p>4WS mixing function</p>
<pre> DUAL ESC MODE: INH RATE: 100 <R MXMD: OFF <R TRIM: OFF <R ▶DT/DL▶ </pre> <p>Dual ESC function</p>	<pre> THR MODE SXNT: FS/BS IDLUP: 0 NTBRK: 0 THOFF: 0 ▶SWITCH▶ <MENU> </pre> <p>Throttle mode function</p>	<pre> DIAL SW *TRIM.DIAL ▶SWITCH▶ *ADVANCE <MENU> <HOME> </pre> <p>Function trim dial/switch</p>	<pre> MC LINK MODE: READ EXEC: +/- (NO DATA) </pre> <p>MC link function</p>

Program mixing [PRG MIX]

Mixing can be applied between the steering, throttle, channel 3, and channel 4 channels.

A.B.S function [ABS]

Pumping brake operation, which brakes the throttle servo intermittently at brake operation, can be set.

Brake mixing [BRAKE MIX]

This function is used when the front and rear brakes are independent and are adjusted individually such as a 1/5GP car.

4WS mixing [4WS MIX]

This function can be used with crawlers and other 4WS type vehicles. It is mixing which controls front side steering by CH1 and rear side steering by CH3.

Dual ESC [DUAL ESC]

This function is mixing used when the front and rear drive motor controllers of a crawler or similar vehicle are used independently.

Throttle mode [THR MODE]

This menu contains the following throttle functions:

SXNT (Neutral position)

The forward and brake (back) operation ratio can be selected from 7:3 and 5:5 by changing the neutral position of the throttle servo.

IDLUP (Idle up)

This function is used to improve engine starting performance by raising the idling speed when the engine of a gasoline car (boat) is started.

NTBRK (Neutral brake)

The neutral brake position, which applies the brakes at the neutral position of the trigger, can be set.

THOFF (Throttle off)

This function stops the engine of a boat, etc. by operating the throttle servo to the set position by switch regardless of the throttle trigger position.

Function trim dial/switch [DIAL SW]

Refer to the function trim dial and function switch described on P60 to P63.

MC link [MC LINK]

This is a special function which allows Futaba motor controller (MC) data changes to be set by the T4PL transmitter (MC950CR, MC851C, MC602C, MC02R, etc.).

Programmable Mix "PROG MIX"

(All channels)

This function allows you to apply mixing between the steering, throttle, channel 3 and channel 4.

Additional Functions

-When the steering or throttle channel is the master channel (channel that applies mixing), trim data can be added. (Trim mode)

- The mixing mode selection. (Master mixing mode)

Relating function

steering :EPA, STR EXP, D/R, SPEED, 4WS MIX

throttle :EPA, THR EXP, ATL, ABS, SPEED, BRAKE MIX, NT-BRK, ESC MIX, ACCFW/BK


CH3 :EPA,BRAKE MIX,4WS MIX

CH4 :EPA,BRAKE MIX,ESC MIX

Movement of the slave channel side

The movement of the master channel side will be added to the movement of the slave channel side.

Display the programmable mixes screen as described on P64.



Setup item selection

- Select by (UP) or (DN) button.

Setup items

MODE : Function ON/OFF

LEFT : Mixing rate (Left side)

RGHT : Mixing rate (Right side)

MST : Master channel

SLV : Slave channel

MXMD : Mix mode

TRIM : Trim mode

Program mixing adjustment

(Preparation)

- When "PROG MIX" is turned ON and OFF by switch, set the switch by function select switch function (P62).

1 (Mixing function ON/OFF)

Select the setting item "MODE" by (UP) or (DN) button. Press the (+) or (-) and set the function to the "ON" or "OFF" state.

"INH" : Function OFF

"ON" : Function ON. When the switch is OFF, "OFF" is displayed.

Function SW

PROGMIX

Function ON/OFF (MODE)

INH,ON(OFF)

Adjust button

- Adjust with the (+) and (-) buttons.

- Return to the initial value "100" by pressing the (+) and (-) buttons simultaneously for about 1 second.

2 (Master channel)

Select setup item "MST" by (UP) or (DN) button, and select the master channel by pressing the (+) or (-) button.

Channel selection (MST)

STR, THR, CH3, CH4
Initial value :STR

3 (Slave channel)

Select setup item "SLV" by (UP) or (DN) button, and select the slave channel by pressing the (+) or (-) button.

Channel selection (SLV)

STR, THR, CH3, CH4
Initial value :CH3

4 (Left, forward or up side mixing amount adjustment)

Select the setting item "LEFT", "FWRD", or "UP" by (UP) or (DN) button. Use the (+) or (-) button and adjust the left, forward, or up side mixing amount.

Mixing amount

-120~0~+120
Initial value: +100

5 (Right, brake or down side mixing amount adjustment)

Select the setting item "RGHT", "BRAK", or "DOWN" by (UP) or (DN) button. Use the (+) or (-) button and adjust the right, brake, or down side mixing amount.

Mixing amount

-120~0~+120
Initial value: +100

6 (Mixing mode setup)

Select setup item "MXMD" by (UP) or (DN) button, and use the (+) or (-) button to select the mixing mode.

"OFF" :Mixing proportional to master channel operation.

"MIX" :Mixing by master channel another function considered.

Mixing mode (MXD)

OFF, ON
Initial value: OFF

7 (Trim mode setup)

Select setup item "TRIM" by (UP) or (DN) button, and use the (+) or (-) button to select the mixing mode.

"OFF" :Trim is removed.

"ON" :Trim is added.

Trim mode (TRIM)

OFF, ON
Initial value: OFF

8

When ending, return to the ADVANCE menu screen by pressing the (CT) button.

A.B.S. Function "A.B.S"

(Throttle system)

When the brakes are applied while cornering with a 4 Wheel Drive or other type of vehicle, understeer may occur. The generation of understeer can be eliminated and corners can be smoothly cleared by using this function.

Operation

- When the brakes are applied, the throttle servo will pulse intermittently. This will have the same effect as pumping the brakes in a full size car.
- The brake return amount, delay amount, pulse cycle, and brake duty can be adjusted.

Operation display

During ABS operation, the LED blinks.

Display the A.B.S function screen as described on P64.

A. B. S	
MODE:	INH
AB.P:	50
DELY:	0
CYCL:	10
TG.P:	30
DUTY:	MID


A.B.S function

Setup item selection


- Select by by (UP) or (DN) button.

Setup items

- MODE : Function ON/Off
- AB.P : Brake return amount
- DELY : Delay amount
- CYCL : Cycle speed
- TG.P : Trigger point
- DUTY : Cycle duty ratio




Without A.B.S.



With A.B.S.

- AB.P : Amount of brake return

Sets the rate at which the servo returns versus trigger operation for brake release. When set to 0%, the ABS function is not performed. When set to 50%, the servo returns 50% (1/2) of the trigger operation amount and when set to 100%, the servo returns to the neutral position.



- DELY : Delay

Sets the delay from brake operation to ABS operation. When set to 0%, the ABS function is activated without any delay. At 50%, the ABS function is activated after a delay of approximately 1 second and at 100%, the ABS function is activated after a delay of approximately 2 seconds.

- CYCL : Cycle speed

Sets the pulse speed (cycle). The smaller the set value, the faster the pulse cycle.

- TG.P : Trigger point

Sets the trigger point at which the ABS function begins to operate at brake operation.

- DUTY : Cycle duty ratio

Sets the proportion of the time the brakes are applied and the time the brakes are released by pulse operation. The ratio can be set to HIGH, MID or LOW.

- MODE : Function ON/OFF

ABS function ON/OFF setting. When using the ABS function, set to "ACT(ON)".

A.B.S function adjustment

1 (Function ON/OFF)

Select the setting item "MODE" by (UP) or (DN) button. Set the function to the active state by pressing the (+) or (-) button.

- "INH(OFF)" :Function OFF
- "ACT(ON)" :Function ON
- "ACT(OFF)" :Switch OFF when setting switches

Setup item selection

- Select by by (UP) or (DN) button.

Adjustment buttons


- Use the (+) and (-) buttons to make adjustments.
- Return to the initial value by pressing the (+) and (-) buttons simultaneously (approx. 1 sec).

Function ON/OFF (MODE)

INH(OFF), ACT(ON), ACT(OFF)

2 (Brake return amount adjustment)

Select the setting item "AB.P" by (UP) or (DN) button. Use the (+) or (-) button to adjust the return amount.



- "0" :No return
- "50" :Return to the 50% position of the brake operation amount
- "100" :Return to the neutral position.

Brake return amount (AB.P)

0 ~ 50 ~ 100
Initial value: 50

- Brake return amount (AB.P) is influenced by the "EXP" rate on the brake side.

3 (Delay amount setup)

Select the setting item "DELY" by (UP) or (DN) button. Use the (+) or (-) button to adjust the delay amount.


- "0" :A.B.S. function performed without any delay
- "50" :A.B.S. function performed after an approximate 1 sec delay.
- "100" :A.B.S. function performed after an approximate 2 secs delay.

Delay amount (DELY)

0 ~ 100
Initial value: 0

4 (Cycle speed adjustment)

Select setting item "CYCL" by (UP) or (DN) button. Use the (+) or (-) button to adjust the pulse speed (cycle).




Cycle speed (CYCL)

1 ~ 30
Initial value: 10

- The smaller the set value, the faster the pulse speed.

5 (Trigger point setup)

Select setting item "TG.P" by (UP) or (DN) button. Use the (+) or (-) button to adjust the operation point.




Trigger point (TG.P)

10 ~ 100
Initial value: 30

- Sets the throttle trigger position at which the A.B.S. function is performed. The number is the % display with the full brake position made 100.

6 (Cycle duty ratio setup)

Select setting item "DUTY" by (UP) or (DN) button. Use the (+) or (-) button to adjust the duty ratio.



Duty ratio (DUTY)

LOW - MID - HIGH
Initial value: MID

"LOW" :Brake application time becomes shortest. (Brakes lock with difficulty)
"HIGH" :Brake application time becomes longest (Brakes lock easily)
(Remark) For low grip, set at the LOW side and for high grip, set at the HIGH side.

7

When ending, return to the ADVANCE menu screen by pressing the (CT) button.

Dial / Trim Setting

The brake return amount (AB.P), delay amount (DELY) and cycle (CYCL) can be controlled with digital dial or digital trim, with the function select dial function. (See page 60)

Switch setting

Use SW1.PSH or SW2.SLD to switch the A.B.S. function ON/OFF.
See the function select switch function (See page 62).

Fail Safe Unit

When the T4PL is used with the Futaba fail safe unit (FSU-1), it will operate as described below. However, FSU-1 cannot be used at the high speed mode.

- When the FSU-1 is connected to the throttle channel, and the A.B.S. function has been activated, the FSU-1 LED will flash each time the servo operates. The reason for this is that the FSU-1 responds to sudden data changes caused by A.B.S. function pumping operation. It does not mean that the fail safe function is activated. The servo will not be affected.

Example of A.B.S. function setting when BLS351 / BLS352 used (There will be a slight difference depending on the state of the linkage.)

- Basic setting

AB.P: Approx. 30% (If this value is too high, the braking distance will increase.)

CYCL: 5~7

DUTY: (When grip is low: LOW side, when grip is high: HIGH side)

DELY: 10~15%

TG.P: Approx. 70%

- When the wheels lock, or the car spins, when the brakes are applied fully

AB.P: Increase from 30%

DUTY: Shift to "LOW" side

DELY: Reduce the delay

- When the braking effect is poor and the braking distance is long when the brakes are applied fully

AB.P: Decrease from 30%

DUTY: Shift to "HIGH" side

DELY: Increase the delay


1/5 scale car and other independent brakes and ABS

ABS can be independently set for the brakes which are controlled by the 3rd CH and 4th CH by using the brake mixing (BRAKE) function described on page 72. For more information, read the brake mixing (BRAKE) item.

Brake Mixing "BRAKE"

(Throttle, 3rd /4th channel system)

This function is used when the front and rear brakes must be adjusted independently such as a 1/5 scale GP car. This mixing uses the 2nd CH for the rear brakes and the 3rd or 4th CH for the front brakes, or controls the front brakes with the 3rd CH and 4th CH servos, or controls the 2nd CH by independent throttle and controls the rear and front brakes with the 3rd CH and 4th CH.




Operation

- When braking, mixing is applied to 2nd CH→3rd CH, 4th CH.
- 3rd CH and 4th CH brake amount, 2nd CH, 3rd CH, and 4th CH brake delay, and 3rd CH and 4th CH brake ABS can be set.

CH3/4 brake ABS function

The ABS function can be used independently at the CH3 and CH4 sides even when the CH2 side ABS function is OFF. The pumping speed (CYCL), operation point (TG.P), and duty ratio (DUTY) can be set in common with the CH2 side ABS function.

Display the brake mixing screen as described on P64.



Brake mixing function

Setup item selection

- Select by by (UP) or (DN) button.

Setup item

<CH3>
 MODE : Brake function ON/OFF
 RATE : Brake rate
 DELY : Delay amount
 ABS : ABS. function ON/OFF

<CH4>
 MODE : Brake function ON/OFF
 RATE : Brake rate
 DELY : Delay amount
 ABS : ABS. function ON/OFF

<CH2>
 DELY : Delay amount

Brake mixing adjustment

1 (Brake mixing function ON/OFF)

Using the (UP) or (DN) button, select "MODE" of <CH3> for CH3 brake and "MODE" of <CH4> for CH 4 brake.

Press the (+) or (-) key and set the function to the "ACT" state.

"INH" : Function OFF
"ACT" : Function ON

- When "(4WS>OFF)" is displayed below <CH3>ABS, the CH3 brake cannot be used if the 4WS function is not set to "ACT".

- When "(ESC>INH)" is displayed under <CH4>ABS, the CH4 brake cannot be used if the dual ESC function is not set to "INH".

Adjustment buttons

- Use the (+) and (-) buttons to make adjustments.

Function ON/OFF (MODE)

INH, ACT

2 (Brake rate)

Using the (UP) or (DN) button, select "RATE" of <CH3> for CH3 brake and "RATE" of <CH4> for CH 4 brake, and use the (+) and (-) buttons to adjust the Brake rate amount.

Brake rate (RATE)

0 ~ 100
Initial value:100

3 (Delay amount setup)

Using the (UP) or (DN) button, select "DELY" of <CH3> for CH3 brake, "DELY" of <CH4> for CH 4 brake and "DELY" of <CH2> for CH 2 brake. Use the (+) and (-) buttons to adjust the delay amount.

"0" : No delay
"100" : Maximum delay amount

Delay amount (DELY)

(CH3) 0 ~ 100
(CH4) 0 ~ 100
(CH2) 0 ~ 100
Initial value:0

4 (3rd & 4th channels brake-A.B.S ON/OFF)

Using the (UP) or (DN) button, select "ABS" of <CH3> for CH3 brake and "ABS" of <CH4> for CH 4 brake.

Press the (+) or (-) key and set the function to the "ACT" state.

Function ON/OFF (ABS)

INH, ACT

5 When ending, return to the ADVANCE menu screen by pressing the (CT) button.

Setting the 4WS mixing/dual ESC function

To use CH3 of the brake mixing function, 4WS mixing (P74) must be set to "INH" and to use CH4, the dual ESC function must be set to "INH"

Dial / Trim Setting

The function select dial function can control the 3rd/4th channels. Brake rate (RATE) can be controlled with digital dial or digital trim, using the function select dial function. (See page 60)


4WS Mixes "4WS MIX"

(Steering, 3rd channel system)


This function can be used with crawlers and other 4WS type vehicles. It is mixing which uses the 1st CH to control the front side steering and the 3rd CH to control the rear side steering.

OFF (front side only), reverse phase, same phase, rear side only and other 4WS type switching is used by selecting SW1.PSH with the function select switch function (P62). If not selected, <NO SW> is displayed. Therefore, select SW1.PSH.

Display the 4WS mixing screen as described on P64.



Function



4WS mixing adjustment

(Preparation)

Since this function is used by switching the type of 4WS with a switch, the switch used by the function select switch function (page 62) is set.

1 (4WS type selection)

Operate the (UP) or (DN) button, and select the setting item "MODE". Select the type by pressing the (+) or (-) button.

- "INH" :Function OFF (front only)
- "2TYP" :Front side only, reverse phase switching
- "3TYP" :Front side only, reverse phase and same phase switching
- "4TYP" :Front side only, reverse phase, same phase, and rear side only switching


Setup buttons

- Use the (+) and (-) buttons to make adjustments.

Function ON/OFF (MODE)


OFF, 2TYP, 3TYP, 4TYP

Switched in the order shown in the figure below by set SW



"2TYP" : Front side only and reverse phase switching

"3TYP" : Front side only, reverse phase, and same phase switching



"4TYP" : Front side only, reverse phase, same phase, and rear side only switching

2 (Rear side travel adjustment)

Select setting item "RATE" by (UP) or (DN) button. Adjust the rear side travel with the (+) or (-) button.

Adjustment buttons

- Use the (+) and (-) buttons to make adjustments.
- Return to the initial value by pressing the (+) and (-) buttons simultaneously (approx. 1 sec).

Rear rate (RATE)

0 ~ 100
Initial value:100

3 (Mix mode setting)

Select setting item "MXMD" by (UP) or (DN) button. Set the mix mode with the (+) or (-) button.

- "OFF" :The EXP function of the 1st CH and other settings are not mixed.
- "ON" :The EXP function o the 1st CH and other settings are mixed.

Mixing mode (MXMD)

OFF, ON
Initial value: OFF

4 When ending, return to the ADVANCE menu screen by pressing the (CT) button.


Dual ESC mixing "DUAL ESC"

(Throttle system)

This function is mixing used with crawlers and other 4WD type vehicles and uses the 2nd CH to control the front motor controller and the 4th CH to control the rear motor controller.

Front drive only, rear drive only, or both front and rear drive can be selected using any programmed DT (digital trim) button.

Display the Dual ESC function screen as described on P64.



Setup item selection

- Select by by (UP) or (DN) button.

Setup items

MODE : DUAL ESC Type
RATE : 4ch rate (Rear side)
MXMD : Mix mode
TRIM : Trim mode

Dual ESC mixing adjustment

(Preparation)

- This function is used to switch between front drive/4WD/rear drive using one of the programmed DT buttons. Set the desired button for this function using the DT button screen (P60).

"Programmed DT buttons" :Select to CH4
"Range (step)" :Select to 100

1 (Dual ESC setting)

Select the setting item "MODE" by (UP) or (DN) button. Set the function by pressing the (+) or (-) button.


"INH" : Function OFF
"ACT" : Function ON

Setup buttons

- Use the (+) and (-) buttons to make adjustments.

Function ON/OFF (MODE)

INH, ACT



The programmed DT button is used to select the drive type as shown in the figure below.

2 (Rear side travel adjustment)

Select the setting item "RATE" by (UP) or (DN) button. Use when applying a rotation difference to the front and rear wheels by adjusting the rear (CH4) motor controller travel with the (+) or (-) button.

3 (Mix mode setting)

Select the setting item "MXMD" by (UP) or (DN) button. Set the mix mode with the (+) or (-) button.

"OFF" : CH2 EXP function and other settings are not mixed.
"ON" : CH2 EXP function and other settings are mixed.

4 (Trim mode setting)

Select the setting item "TRIM" by (UP) or (DN) button. Set the trim mode with the (+) or (-) button.

"OFF" : Front side (CH2) trim data is not included.
"ON" : Front side (CH2) trim data is included.

5 When ending, return to the ADVANCE menu screen by pressing the (CT) button.

Adjustment buttons

- Use the (+) and (-) buttons to make adjustments.
- Return to the initial value by pressing the (+) and (-) buttons simultaneously (approx. 1 sec).

Rear rate (RATE)

0 ~ 120
Initial value:100

Mixing mode (MXMD)

OFF, ON
Initial value: OFF

Trim mode (TRIM)

OFF, ON
Initial value: OFF

Dial / Trim Setting

The function select dial function can control the 4th channel's ESC (Rear side) rate (RATE) with digital dial or digital trim, using the function select dial function. (See page 60)


Note:

As this function drives 2 separate motor controllers simultaneously, a mutual load is applied. Use this function carefully so that the motor controllers are not damaged. Futaba will not be responsible for motor controller, motor, and other vehicle trouble due to use of this function.

This menu has the following 4 functions:


- Servo neutral mode, which sets the throttle neutral ratio to 7:3 or 5:5
- Idle up, which raises the idling speed when starting the engine to improve engine starting performance of a gasoline car (boat)
- Neutral brake, which applies the brakes at the neutral position of the throttle trigger
- Throttle off (engine cut), which stops the engine of a boat, etc. by operating the throttle servo to the low side regardless of the position of the throttle trigger.

Display the Throttle mode function screen as described on P64.



Throttle servo neutral position "SXNT"

-This function allows selection of the forward side and brake (reverse) side operation ratio from 7:3 or 5:5 by changing the neutral position of the throttle servo.



Selecting the throttle servo neutral position

1 (Mode selection)

Select the setting item "SXNT" by (UP) or (DN) button. Select "F5/B5" or "F7/B3" by (+) or (-) button.

- "F5/B5" =Forward 50% : Back50%
- "F7/B3" =Forward 70% : Back30%

Adjustment buttons

- Use the (+) and (-) buttons to make adjustments.

Mode selection (SXNT)

F5/B5, F7/B3

2 When ending, return to the ADVANCE menu screen by pressing the (CT) button.

Idle-Up "IDLUP"

This is a function select switch function. The idle up ON/OFF switch must be set. (P62)
 This function is used to improve engine starting performance by raising the idling speed when starting the engine of a gasoline car (boat). It is also effective when you want to prevent the braking when the power was turned off during running, due to the effect of your gear ratio setting and choice of motor when operating an electric car. However, considering safety, and to prevent the motor from rotating instantly when the power was turned on, the MC950CR, MC851C, MC602C, MC402CR, and other Futaba MC (Motor Controllers) will not enter the operation mode if the neutral position is not confirmed. When using the MC950CR, MC851C, MC602C, MC402CR, or other Futaba MC, confirm that the MC is in the neutral position and the set is in the operation mode before setting the idle up function switch to ON.

Operation

The throttle neutral position is offset to the forward side or brake side. There is no linkage locking, etc. because there is no change near the maximum operation angle even when the neutral position is offset by this function.

Operation Display

While this function is ON, the LED blinks.

< NO SW >
 If function's ON/OFF switch is not selected, <NO SW> is displayed.

The function select switch screen (P62) can be displayed from this screen.

```

    THR MODE
    SXNT: F5/B5
    IDLUP: 0
    NTRK: 0
    THOFF: 0
    <NO SW>
    >SWITCH<
    <MENU>
    
```

If the power switch is turned on while the idle-up switch is on, an audible alarm will be heard. Immediately set the Idle-Up switch to OFF.

```

    WARNING
    MIX WARN
    IDLE UP
    OF
    THOFF
    OF
    NEUTRAL
    BRAKE
    
```

Warning display

Idle-Up function adjustment

(Preparation)

- Use the function select switch to select the switch. (page 62)

1 (Idle-Up rate)

Select the setting item "IDLUP" by (UP) or (DN) button. Use the (+) and (-) buttons to set the Idle-Up rate.

2 When ending, return to the ADVANCE menu screen by pressing the (CT) button.

Dial / Trim Setting

The function select dial function can control the Idle-up rate with digital dial or digital trim. (See page 60)

Adjust button

- Adjust with the (+) and (-) buttons.
- Return to the initial value "0" by pressing the (+) and (-) buttons simultaneously for about 1 second.

Idle-Up rate (IDLUP)

D50 ~ D1, 0, U1 ~ U50

Initial value: 0
 "D": Brake side
 "U": Forward side

Neutral brake "NTBRK"

This is a function select switch function. The neutral brake function ON/OFF switch must be set. (P62)

The neutral brake, which applies the brakes at the neutral position of the throttle trigger, can be set. However, when using the MC950CR, MC851C, MC602C, MC402CR, or other Futaba MC (Motor Controller), confirm that the MC is in the neutral position and the set is in the operation mode before setting the neutral brake function switch to ON, the same as the idle up function (P79). In addition, when the idle up function (P79) or throttle off function (P81) is set, this function has a higher priority than the neutral brake function.

Reference

The ESC neutral brake function and T4PL neutral brake function can be used simultaneously. However, when setting is difficult to understand, we recommend that only one neutral brake function be used.

Dial / Trim Setting

When the neutral brake function is "ON", the neutral brake rate adjustment is automatically assigned to the throttle trim (DT1/2/3/4 or DL1).

Operation display

An LED blinks while the neutral brake function is active.

< NO SW >
If function's ON/OFF switch is not selected, <NO SW> is displayed.

The function select switch screen (P62) can be displayed from this screen.

THR MODE
SXTNT: F5/B5
IDLUP: 0
NTBRK: 0
THOFF: 0
< NO SW >
SWITCH
< MENU >

If the power switch is turned on while the neutral brake switch is on, an audible alarm will be heard. Immediately set the neutral brake switch to OFF.

WARNING
MIX WARN
IDLE UP
oF
THOFF
oF
NEUTRAL BRAKE

Warning display

Neutral Brake function adjustment

(Preparation)

- Use the function select switch to select the switch. (page 62)

1 (Neutral brake rate)

Select the setting item "NTBRK" by (UP) or (DN) button. Use the (+) and (-) buttons to set the neutral brake rate.

2 When ending, return to the ADVANCE menu screen by pressing the (CT) button.

Adjust button

- Adjust with the (+) and (-) buttons.
- Return to the initial value "0" by pressing the (+) and (-) buttons simultaneously for about 1 second.

Brake rate (NTBRK)

0 ~ B100
Initial value: 0

Effect of set value of other functions on neutral brake

Throttle side EPA function, or ATL function setting, also affects neutral brake side operation.

Throttle off (engine cut) "THOFF"


This is a function select switch function. The throttle off function ON/OFF switch must be set. The engine cut function stops the engine of a boat, etc. by operating the throttle servo to the slow side by switch regardless of the position of the throttle trigger and the setting of other functions (reverse function setting is effective).

Dial / Trim Setting

The function select dial function can control the throttle-off position can be controlled with digital dial or digital trim. (See page 60)

Operation display

An LED blinks while the neutral brake function is active.



Engine Cut function adjustment

(Preparation)

- Use the function select switch to select the switch. (page 62)

1 (Preset position setup)

- Select the setting item "THOFF" by (UP) or (DN) button. Use the (+) and (-) buttons to set the preset position of the throttle servo.

Adjust button

- Adjust with the (+) and (-) buttons.
- Return to the initial value by pressing the (+) and (-) buttons simultaneously (approx. 1 sec).

2 When ending, return to the ADVANCE menu screen by pressing the (CT) button.

Preset position (THOFF)

0 ~ B100
Initial value: 0

⚠ Caution



❗ Always operate carefully before using this function.

While switch with preset function set is in the ON state, the servo (motor controller) is locked in the preset position and does not operate even if the throttle trigger is operated. If the servo was operated at the wrong setting, you may lose control of the car (boat).

ESC Link Function "MC LINK"

This is a special function which lets you set the contents of the Link software which performs Futaba speed controller (ESC), MC950CR, MC851C, MC602C, MC402CR, etc. variable frequency and other data changes at the T4PL transmitter. However, some data changes require a PC and Link software. This function is used by connecting ESC directly to the transmitter. The T4PL power switch is used at the display side. Use the various optional servo extension cords according to the distance between the transmitter and ESC. The last data read from ESC to T4PL or the last data written from T4PL to ESC is saved to the T4PL. Since the data for each model memory can be saved, the data of up to 40 models can be saved.

- When the T4PL battery voltage drops, the display switches to low battery display. Therefore, use this function when there is ample battery capacity remaining.
- Also connect the battery at the ESC side.




MC LINK screen



Example: MC402CR

When "MC-LINK" menu is selected when the transmitter power switch is at the transmit side (PWR ON) the message shown below prompting you to set the switch to the display side is displayed.



Using the ESC Link function

(Preparation)


-Connect the T4PL and ESC in accordance with the connection diagram, and connect the battery to ESC.

1 Set the transmitter power switch to the display side (DISP).
Display the MC LINK function screen as described on P64.

2 (ESC read)

Execute this function to read the connected ESC type and the data currently set at the amp. To save the ESC data to the T4PL, rewrite the read data.

When you want to write the data saved in the T4PL to an ESC of the same type, execute the following "WRITE"(write) without executing "READ"(read).



a -Select the setting item "MODE" by (UP) or (DN) button, and select "READ" by (+) or (-) button.

b -Select the setting item "EXEC" by (UP) or (DN) button, and press the (+) and (-) buttons simultaneously for 1 second or longer.

- "COMPLETE!" blinks on the screen and the ESC type and currently set contents are read.

- If "LINK ERROR" blinks on the screen, communication with the amp is not being performed normally. Check the T4PL and ESC connection and the battery connection to ESC and the ESC power switch and repeat steps a→b.



3 (Writing to ESC)

Execute this function to write the setting data to ESC. See pages 84~85 for the setting data contents.



a -Select the setting item "MODE" by (UP) or (DN) button, and select "WRITE" by (+) or (-) button.

b -Select the setting item "EXEC" by (UP) or (DN) button, and press the (+) and (-) buttons simultaneously for 1 second or longer.

- "COMPLETE!" blinks on the screen and the setting data is written to ESC.

If "LINK ERROR" blinks on the screen, communication with the amp is not being performed normally. Check the T4PL and ESC connection and the battery connection to ESC and the ESC power switch and repeat steps a→b. In addition, if (NO DATA) is displayed on the T4PL screen, "WRITE" cannot be selected because there is no setting data to be written.

- Different type ESC data cannot be written. If writing is attempted, "TYPE ERROR" will link on the screen to show that the ESC type is wrong.




4 (Initialization)

This function writes the MC setting data set at the factory to the connected MC and T4PL. Perform "READ" before performing initialization.

a -Select the setting item "MODE" by (UP) or (DN) button, and select "RESET" with the (+) or (-) button.

b -Select the setting item "EXEC" by (UP) or (DN) button, and press the (+) and (-) buttons simultaneously for approximately 1 second

- "COMPLETE!" blinks on the screen and the initial data is written to the ESC. If "LINK ERROR" blinks, communication with the amp was not performed normally. Check the T4PL and ESC connection and the battery connection to ESC and the ESC power switch, and repeat steps a→b. In addition, when (NO DATA) is displayed on the T4PL screen "RESET" cannot be selected because there is no write initial data.




ESC function setup

- 1 Select the setting item by (UP) or (DN) button.
Set the value by (+) and (-) button.

Setup item selection

- Select by (UP) or (DN) button.



Adjustment buttons

- Use the (+) and (-) buttons to make adjustments.
- Return to the initial value by pressing the (+) and (-) buttons simultaneously (approx. 1 sec).

Setup item

Min-(PWM FREQ MIN LD) 100Hz~10000Hz (10kHz)
MC950CR:500Hz~30000Hz (30kHz)

Same as Link software PWM frequency (at Min. load),
Min sets the "0"A PWM frequency at minimum load.

MAX-(PWM FREQ MAX LD) 100Hz~10000Hz (10kHz)
MC950CR:500Hz~30000Hz (30kHz)

Same as Link software PWM frequency (at Max. load).
MAX sets the PWM frequency at maximum load at the output current limit value set by Current Limiter.

BRK-(PWM FREQ BRK LD) nORM(2000Hz)/ HIGH(1000Hz)/ SAPHI(500Hz)
MC950CR:500Hz~30000Hz (30kHz)


Same as Link software Brake PWM at frequency.
This setting can set the brake PWM frequency.

nTB-(NEUTRAL BRAKE) 0%(OFF)~100%

Same as Link software Neutral Brake.
Make this setting when you want to use the brakes at the neutral throttle (OFF) position by throttle operation. The larger this value, the greater the braking force. When you want to use the neutral brake, set this value to "0%".

CLM-(CURRENT LIMIT) 50A~300A (MC950CR:50A~300A), OFF Same as Link software Current Limiter.

Current Limiter sets the current value at maximum load here.
Since setting of the MAX is based on the output current limit value set by Current Limiter, Current Limiter does not have to be turned OFF except when a current exceeding 300A is generated.



"Min" which sets the frequency when the load is small, is set to the high frequency side (large value) when extension is desired after straight-aways and curves.

"MAX" which sets the frequency when the load is large, is set to the high frequency side (large value) when you want to suppress the rise from low speed and when motor heating and commutator roughness are sensed.

When the rise from low speed is poor, and becomes bad even when "MAX" is set to the low frequency side, use the log data to check if there was a momentary voltage drop. When you want to suppress the overall power, lengthen the run time, and otherwise improve efficiency, set both "MAX" and "Min" to the high frequency side. When you want to set a fixed PWM frequency at full range regardless of the load current, set PWM frequency (at Max. load) and PWM frequency (at Min. load) to the same value.


LBP-(LOW BATTERY VOLT) 2.5V~6V**2.5V~7.5V for MC950CR**

Same as Link software Low Bat Protection
 This setting cuts off the output to the motor when the running battery voltage drops to the set voltage to prevent the receiver from stopping operation when the supply of voltage to the receiver becomes insufficient while running due to a drop in the power supply voltage. When the power supply voltage recovers, power is supplied to the motor once more.


DBA-(DEAD BAND) $\pm 2\mu s \sim \pm 50\mu s$

Same as Link software Dead Band.

This sets the range (neutral point range) over which the ESC does not respond to transmitter throttle operation. The larger the set value, the wider this range.




Position at which motor starts to run
 Point at which brakes start taking effect
 Throttle neutral position

**CTM-(C.L. TIME LIMIT) 50A~300A /CLT-(C.L. TIMER) 0sec(OFF)~240sec (except MC950CR)**

Same as Link software Current Limiter (Time Limit)/Current Limit timer.
 The output current can be limited up to the set time lapse from the start of running. This is effective in preventing the motor from outputting wasted energy when the voltage is high immediately after the power battery was recharged.
 - "CTM" (Time Limit) sets the maximum output current within the time the output current is limited.
 - "CLT" sets the time the output current is limited. This function is disabled when set to "0" sec.
 Since the Current Limit Timer starts when the throttle is operated to the forward side and current is output to the motor, this function begins to operate when the motor is run during trim adjustment, etc.

FWB-(FORWARD BOOST) 0~100 (except MC850C)


Same as Link software Forward Boost
 Operation near the throttle trigger (stick) neutral position becomes a sharp rise.

**BMD-(BRAKE MAX DUTY) 0%~100%**

Same as Link software Brake Max. Duty.
 This setting can set the braking force between the neutral point and Max brake point. The larger this value, the greater the braking force. When set to "0%", the brakes are not effective.

RMD-(REVERSE MAX DUTY) w/back only 0%~100%

Same as Link software Reverse Max. Duty
 This setting can set the reverse power between the neutral point and Max reverse point. The larger this value, the greater the reverse power. When set to "0%", the reverses are not effective.

**MC950CR only setup item****REV-(REV CANCEL) BRK /REV**

Same as Link software Reverse Cancel.

When set to BRK, reverse operation is not performed.

LA-(LEAD ANGLE) 0~1500


Same as Link software Lead Angle.

The lead angle of the motor can be set at the MC950CR side. However, we recommend that it normally be set to "0". Since this setting is premised on setting by referring to the speed log by the Link software, independent use of the MC LINK function of the T4PKS is recommended.

Function

Timer Function "TIMER"

Use the timer by selecting one of the three timers UP TIMER, DOWN TIMER, and LAP TIMER.




UP TIMER function

Up timer function

- This function can be used to count the time between start and stop, etc.
- The timer repeatedly starts and stops each time the switch is pressed and accumulates the time between each start and stop. When the count reaches 99 minutes 99 seconds, the count returns to 00 minutes 00 seconds and is repeated.
- The first start operation can be linked to the throttle trigger.
- The passage of time is announced by sounding of a buzzer (beep) each minute after starting.

- Alarm :Beep sounds at the set time (minute).
- Prealarm :Alarm advance announcement sound. Beeping begins 5 seconds before the alarm.(beeps)

- After starting, the timer continues to count and can be stopped by switch even when the LCD switches to another screen.



FUEL DOWN TIMER function

Fuel down timer function

- This function is primarily used to check the refueling time of a gasoline car. (The remaining time is displayed.)
- Each time the switch is pressed, the timer is restarted and the set time is reset. The start time becomes the alarm set time. (When counted down to 00 minute 00 second, the down timer becomes an up timer.)
- The down timer can be initially started by throttle trigger.
- The passing of time is indicated by sounding of a buzzer (beep) each minute after starting.



- Alarm :A beep sounds at the set time (minute).
 - Prealarm :Alarm advance announcement sound. Beeping begins 5 seconds before the alarm.(beeps)
- After starting, the timer continues to count even if the LCD switches to another screen.


LAP TIMER

Lap timer function

- Each lap time can be memorized by switch operation. (100 laps)
- The race time can be set. Switch operation after the time set by alarm has elapsed automatically stops the timer. The passing of time is indicated by sounding of a buzzer (beep) each minute after starting.

- Alarm :Beep sounds at the set time.
- Prealarm :Alarm advance announcement sound. Sounding begins 5 seconds before the alarm. (beeps)


- The lap timer can be initially started by throttle trigger.



(LAP TIMER operation)

- The lap timer is started by switch or throttle trigger.
 - Number of laps (LAP): After starting, the timer is counted up and the lap time blinks for 3 seconds each time the switch is pressed. To prevent erroneous counting, switch operation is not accepted during this period. When 1 lap exceeds 10 minutes, counting is repeated from 0.
 - Lap list: Up to 10 lap times are memorized beginning from lap list 1. After lap memory "No.100", operation returns to lap memory "No.1" and the lap memories are overwritten.
 - The lap time data memorized in the lap memories can be checked with the lap list screen (P92). The entire lap list data is cleared the next time the lap timer is started.
 - TIME: For the first 3 seconds, the preceding lap time is displayed. After that the current lap time is displayed.

Timer screen



Racing timer type selection

(Preparation)

Assign the "TIMER" switch using the function select switch (p.62).

1 (Racing timer type selection)

Select the setting item "TYPE" by (UP) or (DN) button. Press the (+) or (-) button and set the racing timer type.

Timer selection (TYPE)

- UP : Up timer
- DOWN : Down timer
- LAP : Lap timer

Setup item selection

- Select by (UP) or (DN) button.

Adjustment buttons

- Use the (+) and (-) buttons to make adjustments.

2 When ending, return to the home screen by pressing the (CT) button.

Using the up timer

(Preparation)

Select the setting item "TYPE" by (UP) or (DN) button.

Press the (+) or (-) button and select "UP".

Adjustment buttons

- Use the (+) and (-) buttons to make adjustments.
- Press the (+) and (-) buttons simultaneously (approx. 1 sec) to return to the HOME screen.

1 (Alarm time setting)

Select the setting item "ALRM" by (UP) or (DN) button and set the alarm time with the (+) or (-) button.



Alarm time (ALRM)

OFF, 1 ~ 99 m
Initial value: 5 m


2 (Timer start/stop operation)

Start the timer by pressing the switch ("TIMER") set by function select switch function.

Stop the timer with the same switch ("TIMER") as start.

- Linking only start to the throttle trigger

Select the setting item "RST" by (UP) or (DN) button and press the (+) and (-) buttons simultaneously for approximately 1 second. When the set beeps and the status display switches from "RST" to blinking "RDY", the system enters the trigger operation ready state. When the trigger is operated at the forward side, the timer starts. (Status display "RUN")



Switches

Time start / stop

Status display

RST :Reset state
RDY :Throttle trigger operation wait
RUN :Timer running
STP :Timer stopped

If the (CT) button is pressed while the timer is operating, the LCD returns to HOME screen.

3 (Timer reset operation)

Select a status display ("RUN", "STP", or "RDY") by (UP) or (DN) button and press the (+) and (-) buttons simultaneously for approximately 1 second. A beep is generated and "RST" appears on the status display and the timer resets.



Status display

RST :Reset state
RDY :Throttle trigger operation wait
RUN :Timer running
STP :Timer stopped

Using the fuel down timer

(Preparation)

Select the setting item "TYPE" by (UP) or (DN) button.


Press the (+) or (-) button and select "DOWN".

Adjustment buttons

- Use the (+) and (-) buttons to make adjustments.
- Press the (+) and (-) buttons simultaneously (approx. 1 sec) to return to the HOME screen.

1 (Alarm time setting)

Select the setting item "ALRM" by (UP) or (DN) button and set the alarm time with the (+) or (-) button.



Alarm time (ALRM)

OFF, 1 ~ 99 m
Initial value: 5 m

2 (Alarm start/restart operation)

When the switch ("TIMER") set by function select switch function is pressed, the timer starts. When the same switch ("TIMER") is pressed while the timer is operating, the timer is reset and simultaneously restarted. (Restart)

Switches

Timer start / restart

- Linking only start to the throttle trigger

Select the setting item "RST" by (UP) or (DN) button and press the (+) and (-) buttons simultaneously for about 1 second. When the set beeps and the status display switches from "RST" to blinking "RDY", the system enters the trigger operation ready state. When the trigger is operated at the forward side, the timer starts. (Status display "RUN")



Status display

RST :Reset state
RDY :Throttle trigger operation wait
RUN :Timer running

If the (CT) button is pressed while the timer is operating, the LCD returns to the HOME screen.

3 (Timer reset operation)

Select a status display ("RUN") by (UP) or (DN) button and press the (+) and (-) buttons simultaneously for approximately 1 second. A beeping sound is generated and "RST" appears on the status display and the timer resets.



Status display

RST :Reset state
RDY :Throttle trigger operation wait
RUN :Timer running

Using the Lap timer


(Preparation)

Select the setting item "TYPE" by (UP) or (DN) button.

Press the (+) or (-) button and select "LAP".

1 (Alarm time setting)

Select the setting item "ALRM" by (UP) or (DN) button and set the alarm time with the (+) and (-) buttons.



Adjustment buttons

- Use the (+) and (-) buttons to make adjustments.
- Press the (+) and (-) buttons simultaneously (approx. 1 sec) to return to the HOME screen.

Alarm time (ALRM)

OFF, 1 ~ 99 m
Initial value: 5 m

2 (Timer start/ lap count/ stop operation)


When the switch (TIMER) set by function select switch function is pressed, the timer starts. At timer operation, the same switch becomes the lap switch and when the set time elapses, the timer is stopped by the same switch (TIMER)

- Linking only start to the throttle trigger

Select the setting item "RST" by (UP) or (DN) button and press the (+) and (-) buttons simultaneously for about 1 second. When the set beeps and the status display switches from "RST" to blinking "RDY", the system enters the trigger operation ready state. When the trigger is operated at the forward side, the timer starts. (Status display "RUN")

When the switch (TIMER) is pressed after the time set by alarm has elapsed, the timer stops and the lap time and total time are memorized. The status display becomes "GOAL".

If the (CT) button is pressed while the timer is operating, the display returns to the HOME screen.



Switches

Timer start / Lap count

Status display

RST :Reset state
RDY :Throttle trigger operation wait
RUN :Timer running
GOAL: Timer stopped

3 (Timer reset operation)

Select a status display ("GOAL") by (UP) or (DN) button and press the (+) and (-) buttons simultaneously for approximately 1 second. A beeping sound is generated and "RST" appears on the status display and the timer resets.

- When reset operation was performed before the "ALRM" set time had elapsed, the total time is not memorized.
- The lap memory data can be checked with the lap list (P92) screen.



Status display

RST :Reset state
RDY :Throttle trigger operation wait
RUN :Timer running
GOAL: Timer stopped

Lap List "LAP LIST"


The lap list is displayed when checking the lap memory data (lap times) memorized by lap timer (P91) operation.

- After the lap timer starts, the lap times are memorized sequentially each time the switch is operated.

- If the timer is stopped after the set ALRM time has elapsed, the final lap time is memorized and the total time after the last lap is automatically written.

- When the timer was stopped before the set ALRM time has elapsed, the total time is not memorized.

The LAP LIST screen moves from the timer screen as shown below.



Using the lap memory

1 (Lap memory check)

When the (UP) or (DN) button is pressed, the list is scrolled every 10 laps and each lap time can be checked.

2 (Lap memory total data reset)

Press the (+) and (-) buttons simultaneously for approximately 1 second. A beeping sound is generated and all the data is reset.


3 When ending, return to the timer screen by pressing the (CT) button.

System Functions "SYSTEM"


The graphic liquid crystal screen display mode, buzzer sound and menu character mode, etc can be set.

- Liquid crystal screen contrast adjustment (20 steps)
- Liquid crystal screen backlighting display mode setup (OFF, ON at button operation, normally ON)
- Setting of ON time (1~30 secs) when [ON at button operation] was selected above.
- Battery type setting (DRY4, N5/L2)


The T4PL can use an optional rechargeable battery. However, the battery alarm setting is different from that of the dry cell battery (alkaline battery recommended). Therefore, always set the battery type to match the power source used. Always set the battery type to "N5/L2" especially when using a Futaba rechargeable type battery. If the set is used at "DRY4" setting, the time from low battery alarm to system stopping will become extremely short.



- Buzzer sound tone adjustment (OFF, 100 steps)
- The power off forgotten alarm setting (OFF, 10 m)
- Item which displays the basic menu screen in katakana characters for Japanese use.



- *Adjuster (Steering and throttle correction can be applied.)



Setup items

- CONTRA :Contrast
- BK-LHT :Backlighting mode
- LHT-TM :Backlighting time
- BATT :Battery type
- BUZZER :Buzzer tone
- OPE-TM :Power off forgotten alarm
- MENU :Menu screen character
- *ADJUSTER :Correction of wheel and trigger

System function setup


1 (Setting of each item)

(Adjusting the liquid crystal contrast)

Select the setting item "CONTRA" by (UP) or (DN) button, and use the (+) and (-) buttons to adjust the screen contrast.

- Adjust to an easy-to-see contrast.

When ending, return to the menu screen by pressing the (CT) button.



Adjustment buttons

- Use the (+) and (-) buttons to make adjustments.
- Press the (+) and (-) buttons simultaneously (approx. 1 sec) to return to the initial value.

Contrast (CONTRA)


-10~0~+10
Initial value: 0

(Setting the liquid crystal backlighting mode)

Select the setting item "BK-LHT" by (UP) or (DN) button, and select the mode by pressing the (+) or (-) button.

- "KEY" :Fixed time backlighting ON after button operated.
- "ALL" :Backlighting always ON
- "OFF" :Backlighting OFF

When ending, return to the menu screen by pressing the (CT) button.



Backlight mode (BK-LHT)


KEY, ALL, OFF

(Setting liquid crystal backlighting time)

Select the setting item "LHT-TM" by (UP) or (DN) button, and use the (+) and (-) buttons to set the ON time.

- When "KEY" is set at the preceding item, this ON time becomes effective.

When ending, return to the menu screen by pressing the (CT) button.




→ Backlighting time (LHT-TM)
1~30
Initial value: 10

(Setting the battery type)


Select the setting item "BATT" by (UP) or (DN) button, and select the mode by pressing the (+) or (-) button.

"N5/L2" :Futaba rechargeable type battery

"DRY4" :Dry cell battery (alkaline battery recommended) 4 batteries




→ Battery Type (BATT)
DRY4, N5/L2



(DRY4)

Voltage display
When BATT is set to dry cell use DRY4 or N5/L2, the voltage display of the HOME screen changes.



(N5/L2)

When ending, return to the menu screen by pressing the (CT) button.

(Adjusting the buzzer tone)

Select the setting item "BUZZER" by (UP) or (DN) button, and use the (+) and (-) buttons to adjust the tone.

- Decide by referring to the tone at adjustment.

When ending, return to the menu screen by pressing the (CT) button.



→ Buzzer tone (BUZZER)
OFF, 1~100
Initial value: 85

(Changing the power off forgotten alarm setting)

Select the setting item "OPE-TM" by (UP) or (DN) button, and use the (+) and (-) buttons to select the power off forgotten alarm mode.

- "10m" :If an operation is not performed within 10 minutes while the power is on, an audible alarm sounds.
- "OFF" :Power off forgotten alarm setting OFF

```

CONTRA: 0
BK-LHT:KEY
LHT-TM:10s
BATT:DRY4
BUZZER: 85
OPE-TM:10m
MENU :ENG
*ADJUSTER
<MENU>
    
```

→ The power off forgotten alarm (OPE-TM)
10m, OFF

When ending, return to the menu screen by pressing the (CT) button.

(Changing the basic menu character display)

Select the setting item "MENU" by (UP) or (DN) button, and set the basic menu character display with the (+) or (-) button.

- "ENG" : Basic menu displayed in Alphabetic character.
- "カナ" : Basic menu displayed in katakana character.

```

CONTRA: 0
BK-LHT:ALL
LHT-TM:10s
BATT:DRY4
BUZZER: 85
OPE-TM:OFF
MENU :ENG
*ADJUSTER
<MENU>
    
```

→ Menu charactre (MENU)
ENG, カナ

```

*STEERING
*THROTTLE
*MODEL RX
*ADVANCE
*CH3 CH4
*DIAL SW
*SYSTEM
<HOME>
    
```

(ENG)



```

*ステアリング
*スロットル
*モデル RX
*アトバンス
*CH3 CH4
*ダイヤルスイッチ
*システム
<HOME>
    
```

(カナ)

When ending, return to the menu screen by pressing the (CT) button.


- Refer to the next page for a description of the adjuster (ADJUSTER).

Adjuster "ADJUSTER"

Steering wheel and throttle trigger neutral position and servo operating angle correction can be applied. This is used when a mechanical offset has occurred for some reason.

*However, when correction was applied, the set value of all the setting functions must be rechecked.

Display the adjuster screen from the system menu.




Steering adjustment

(Preparation)


- On the system menu screen, select the ADJUSTER screen by selecting "*ADJUSTER" with the (UP) or (DN) button and pressing the (CT) button.

- If "WHEEL" (steering side) is selected by (UP) or (DN) button, the adjuster screen is displayed by pressing the (CT) button.



1 (Steering neutral adjustment)

In the neutral setup screen state (figure at the right), lightly turn the steering wheel to the left and right, then press the (+) and (-) buttons simultaneously in the state in which the wheel is not being touched.





2 (Steering throw adjustment)

In the throw setup screen state (figure at the right), lightly turn the wheel fully to the left or right and when PUSH +/- is displayed, press the (+) and (-) buttons simultaneously.

Internal check is performed automatically. When each adjustment point is within a fixed range, correction is performed and "COMPLETE" (figure at the right) is displayed.

If an adjustment point is not within a fixed range, correction is not performed and the correction data is not updated.

When the correction data is not updated even though correction was performed again, please contact a Futaba Radio Control Customer Center.




- 3** When ending setting, return to the ADJUSTER screen by pressing the (CT) button. When *SYSTEM is selected from the ADJUSTER screen and the (CT) button is pressed, the LCD returns to the system screen and if <HOME> is selected and the (CT) button is pressed, the LCD returns to the HOME screen.

Throttle adjustment

(Preparation)


-On the system menu screen, select the ADJUSTER screen by selecting "*ADJUSTER" by (UP) or (DN) button and pressing the (CT) button.

-In the state in which "TRIGGER" (throttle side) is selected by (UP) or (DN) button, display the ADJUSTER screen by pressing the (CT) button.



1 (Throttle neutral adjustment)

In the neutral setup screen state (figure at the right), lightly pull the throttle trigger in the forward direction and press the (+) and (-) buttons simultaneously in the state in which the trigger is not touched.




2 (Throttle throw adjustment)

In the throw setup screen state (figure at the right), lightly operate the trigger fully to the brake side and the forward side and when PUSH +/- is displayed press the (+) and (-) buttons simultaneously.

Internal check is performed automatically. When each adjustment point is within a fixed range, correction is performed and "COMPLETE!" (figure at the right) is displayed.

If an adjustment point is not within a fixed range, correction is not performed and the correction data is not updated.

When PUSH +/- is not displayed even though correction was performed again, please contact a Futaba Radio Control Customer Center.



- 3** When ending setting, return to the ADJUSTER screen by pressing the (CT) button. When *SYSTEM is selected from the ADJUSTER screen and the (CT) button is pressed, the LCD returns to the system screen and when <HOME> is selected and the (CT) button is pressed, the LCD returns to the HOME screen.

Ratings

*Specifications and ratings are subject to change without prior notice.

Communication method:One-way operation system
Maximum operating range:100m (Optimum condition)
For safety: F/S, B-F/S, ID

Transmitter T4PL-2.4G

(S-FHSS/FHSS system, wheel type, 4 channels)

Transmitting frequency:

2.4GHz band

Power requirement:

(Dry cell battery) Penlight x 4(6V)

Current drain:

250mA or less

Transmission antenna:

1/2λ di-pole

Receiver R2104GF: (S-FHSS/FHSS system, 4 channels)

Power requirement:

4.8V~7.4V battery / 3.5 ~ 8.4V useable

(Dry cell battery cannot be used.)

Receiving frequency:

2.4GHz band

System:

S-FHSS/FHSS system (auto detection)

Size:

1.54x1.02x0.39in. (26x39x10mm) (excluding a projection part)

Weight: 0.28oz. (8g)

Servo S9551 (Digital servo)

Power requirement:

6V (Common with receiver)

Output torque:

8.8kg-cm (122.2 oz.-in.) at 6V

Operating speed:

0.11sec/60 degree at 6V

Size:

1.59x0.78x1.0in. (40.5x20.2x25.4mm)

Weight:

1.31oz. (37.2g)

E.S.C. MC402CR (Electronic speed control)

Operating system:

Forward and brake (resolution:255)

Power requirement:

Nicd, NiMH battery 4~6 cells (4.8~7.2V)

LiPo, LiFe battery 2 cells (6.6, 7.4V)

PWM frequency:

Forward:100Hz~10kHz/ Initial value:2.5kHz~3.0kHz

Brake:500Hz, 1.0kHz, 2.0kHz/ Initial value:500Hz

BEC voltage:

6.0V (excluding at less than 6V)

Setting:

One-touch input by push button switch.

Current capacity (FET rating) :

Forward :360A (Momentary load: 1440A)

Reverse :120A

Fuse:

30A (Battery reverse protection / Overload protection)

Case size:

10.1x10.3x5.1in. (25.7x26.2x12.9mm)

(excluding protruding parts)

Silicon cord gauge size:

AWG14 equivalent

Weight:

0.4oz. (11.2g)

(excluding connector, cords and switch)

⚠ Caution

❶ When using the T4PL in the high speed (HIGH) mode, always use it under the following conditions:

Servos :Futaba digital servo (including BLS Series brushless servos)

Receiver's battery :Matched to the ratings of the receiver and connected digital servo (dry cell battery cannot be used).

Transmitter mode :HIGH mode (See p.42 for setting method.)

Under other conditions, the set will not operate, or the specified performance will not be displayed even if it operates. In addition, it may cause servo trouble. Futaba will not be responsible for damage, etc. caused by combination with the products of other companies.

In addition, the FSU1 Fail Safe Unit cannot be used because the system is different. Use the fail safe function of the transmitter.

❷ When using analog servos, always switch the T4PL servo response to the NORM mode.

Transmitter mode :NORM mode (See p.42 for setting method.)


Receiver's battery :Matched to the ratings of the receiver and connected servo (dry cell battery cannot be used).

The set cannot operate in the HIGH SPEED mode. Operation in this mode will cause trouble with servos and other equipment. Digital servos (including BLS Series brushless servos) can also be used in the NORMAL mode.

Warning Displays

Backup Error

LCD screen:



If the data is lost for an unknown reason, an audible alarm will sound and "MEMORY BACK UP ERROR" will be displayed on the LCD screen.

Audible alarm:

Tone will sound (9 times), then repeat.


Warning

! When a backup error is generated, immediately stop using the system and request repair from the Futaba Service Center.

If you continue to use the system, the transmitter may malfunction and cause loss of control

Low Battery Alarm

LCD screen:



If the transmitter battery voltage drops to 4.1V (when using Futaba rechargeable type battery: 4.9V) or less, an audible alarm will sound and "BATTERY LOW VOLTAGE" will be displayed on the LCD screen.

Audible alarm:

Continuous tone.

Warning

! When a low battery alarm is generated, cease operation immediately and retrieve the model.

If the battery goes dead while in operation, you will lose control.

Power supply and low battery alarm

The T4PL can use an optional rechargeable battery. However, the battery alarm setting is different from that of the dry cell battery (alkaline battery recommended). Therefore, always set the battery type to match the power source used. Always set the battery type to "N5/L2" especially when using a Futaba rechargeable type battery. If the set is used at "DRY4" setting, the time from low battery alarm to system stopping will become extremely short. (See page 93, for a detailed description of the battery types.)

High voltage alarm

LCD screen:



If a battery exceeding 8V is used with the T4PL, an audible alarm will sound and "BATTERY HIGH VOLTAGE" will be displayed on the LCD screen.


Immediately remove the battery because it may cause the T4PL to malfunction.

Audible alarm:

Tone sounds (7 times) and stops (repeated)

Memory Error

LCD screen:



If the data in the transmitter is not transferred normally when the power is turned on, an audible alarm will sound and "MAIN MEMORY ACCESS ERROR" will be displayed on the LCD.


- To stop the alarm, turn off the power.
- Turn the power back on. If the alarm is not generated again, there is no problem.

Audible alarm:

Tone sounds (7 times) and stops (repeated)

MIX Warning

LCD screen:




When the power switch is turned on while the idle-up, preset (engine cut) or neutral brake function switch is on, an audible alarm will sound and "MIX WARN" will be displayed on the LCD. When that function switch is turned off, the alarm will stop.

Audible alarm:

Tone sounds (7 times) and stops (repeated)

Power off forgotten warning

LCD screen:



If the T4PL is not operated for 10 minutes, an audible alarm is sounded and "OPE WARN" is displayed on the screen. The audible alarm stops when the steering wheel, throttle trigger, and any dial, switch, or edit button is operated. If you are not going to use the transmitter, turn the power off. (Setting can be reset at the system menu on page 93.)

Audible alarm:

Tone sounds (7 times) and stops (repeated)

Optional Parts

The following parts are available as 4PL options. Purchase them to match your application. For other optional parts, refer to our catalog.

Transmitter Battery

When purchasing a transmitter battery use the following:

Part name

HT5F1700B (6V/1700mAh) Ni-MH battery

FT2F2100B (6.4V/2100mAh) Li-Fe battery

Please do not use the transmitter batteries HT5F1700B and FT2F2100B as the receiver's battery.

Since the transmitter's battery has an overload protection circuit, the output power will be shut down when the high current load is applied. This may result in runaway or fatal crash.

When requesting repair

Before requesting repair, read this instruction again and recheck your system. Should the problems continue, request as follows.

(Information needed for repair)

Describe the problem in as much detail as possible and send the letter along with the system in question.

- Symptom (Including the conditions and when the problem occurred)
- R/C System (Send transmitter, receiver and servos)
- Model (Type of model, brand name and model number or kit name)
- Detailed packing list (Make a list of all items sent in for repair)
- Your name, address and telephone number.

(Warranty)

Read the Warranty card.

- When requesting warranty service, send the card or some type of dated proof purchase.

FEDERAL COMMUNICATIONS COMMISSION INTERFERENCE STATEMENT (for U.S.A.)

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

CAUTION:

To assure continued FCC compliance:

Any changes or modifications not expressly approved by the grantee of this device could void the user's authority to operate the equipment.

Exposure to Radio Frequency Radiation

To comply with FCC RF exposure compliance requirements, a separation distance of at least 20 cm must be maintained between the antenna of this device and all persons. This device must not be located or operating in conjunction with any other antenna or transmitter.

©Copyright 2010. No part of this manual may be reproduced in any form without prior permission. The contents of this manual are subject to change without prior notice. While this manual has been carefully written, there may be inadvertent errors or omissions. Please contact our service center if you feel that any corrections or clarifications should be made.

FUTABA CORPORATION Phone: +81 475 32 6982, Facsimile: +81 475 32 6983
1080 Yabutsuka, Chosei-mura, Chosei-gun, Chiba 299-4395, Japan

4PL-2.4G

Frequency Hopping Spread Spectrum

2.4GHz
S-FHSS

*Digital Proportional
R/C System
for Use with Surface Models*

Futaba®