

# KODO FPV

## **TECHNICAL TIP**

For best performance, please calibrate the sensors on the Kodo FPV while setting up the drone for its first flight.

1. Place the Kodo on a level surface.
2. Hold both control sticks in the lower right corner as shown until the LED on the rear of the Kodo FPV starts to flash.
3. Release the sticks and wait for the LED to stop flashing.

This procedure should also be performed whenever the Kodo FPV is constantly drifting in the same direction while it is hovering.

