



ALUMINUM FRONT WHEEL

Step 1



3x6mm Screws
(Use threadlock)

Step 2



3x6mm Screws
(Use threadlock)

