

hadron™

Vectored Thrust Flying Wing

TECH NOTICE

If you notice the motor wires catching on the inlet shroud on the back of the turtledeck, remove the turtledeck and use a hobby knife to chamfer the inside of the shroud to accommodate the wires.

