



PRODUCT IMPROVMENT SHEET

On Page 14, **Building The Landing Gear**, Step 1. should read:

1. Cut the 1/16" x 30" [1.6 x 762mm] wire into three pieces of 15-5/8" [397mm], 6-1/4" [159mm] and 8-1/8" [206mm].

On page 15. Step 6. should read:

6. Bend the 6-1/4" [159mm] wire as shown on the cross-brace template on the plan.

Step 7. should read:

7. Bend the tailskid from the remaining piece of 8-1/8" [206mm] wire as shown on the plan.