

GREAT PLANES HEADWIND "B"

Instruction Addendum



Page 7, step 4

A slot for the control horn needs to be cut in the wood of the rudder (not just the covering). Being careful to not cut the leading edge of the rudder, cut the slot through the rudder the same size as the control horn.



Page 8, step 12

The rubber bands have been updated since the writing of this manual. Cut the covering from the rubber band holes in the fuse and tie both rubber bands to the fuse. To mount the wing, pull the rubber band forward over the wing and hook it over the dowel.