

# SPAD XIII

**Please follow these additional instructions to assemble your Spad XIII.**

☐ 1. Excess components are included in this ARF. Please use the bag containing the (2) white plastic pushrod retainers. Omit the similar parts bag which does not contain the (2) white plastic pushrod retainers.

☐ 2. Please ensure that all pre-hinged control surfaces are free to pivot before installation.

☐ 3. **Page 13, PREPARE THE WINGS:** Upon completion of step 4 complete the following step before moving on to step 5. Please remove the masking tape securing the two leads at the center of the wing. Next, tie at least a 6" (153mm) length of string to each extension at the center of the wing. Attaching the string to the lead will allow recovery in the event the lead is pulled into the wing opening during completion of step 5. The strings can be removed after completing step 5.

