

VIPER 500 ADDENDUM

Some engines have back plate bolts that are not long enough to properly mount the engine to the engine mount. To check this remove the rear plate engine bolts completely, and push them in until the threads make contact. Do not screw them in. Measure the distance between the head of the bolt and the backplate of the engine. Make sure there is a gap of at least 3/16" [4.8mm]. If the gap is smaller than 3/16" [4.8mm], new longer bolts will need to be purchased.

The OS .46FX requires four 3x10mm bolts.

The OS .25FX requires four 2.6x10mm bolts.

These are available from your local hardware store and better hobby shops around the world.

