

## GREAT PLANES 38% EXTRA 330S ARF

### *How to relocate the pilot:*

If the top of the pilot's helmet in your Extra 330S ARF is contacting the canopy, the pilot may be relocated 1/4" [6mm] forward to provide adequate clearance. Follow these instructions to move the pilot.

- ❑ 1. Remove the 4-40 socket-head cap screws from the bottom of the canopy hatch—they are thoroughly loc-tited, so use care and turn the screws slowly.
- ❑ 2. In addition to the screws, the pilot is also glued to the cockpit floor, but you should be able to “break” the pilot free with a little force—just carefully push the head forward until the bond is broken.
- ❑ 3. Use a 1/8" [3.2mm] drill to drill new holes in the doubler in the bottom of the canopy hatch 1/4" [6mm] ahead of the original holes.



- ❑ 4. Re mount the pilot with the screws—be certain to use threadlocker on the threads of the screws.