

# Revolver 50cc

## TECHNICAL NOTICE

- On page 15, Step 2 of the manual should read: “Drill a pilot hole through each of the marks on the template. Remove the template and then drill a **13/64" [5.2mm] clearance hole** through the firewall on each of the four pilot holes you drilled.”
- Check the servo tray and formers before flying. If needed, apply CA glue to any loose joints.