



TECH NOTICE



1. To prevent damage to the battery from the nose block screws in a crash, we recommend installing a protective foam block.



2. Locate the foam block included with the kit contents. If the block is not available, a 1-1/8"x1-1/8"x5/8" [30 x 30 x 15mm] piece of the foam packaging included with the kit would suffice.



3. Press the block in place against the protruding screw tips. Use white glue to hold the block in place.