

The concept of stuffing a large-displacement engine in a chassis just large enough for two people and of cloaking the whole thing in a minimum of swoopy bodywork is as appealing now as it was in the mid-Sixties when Carroll Shelby brought us the Cobra. Today's embodiment of that idea is the Dodge Viper, slated to show up in Dodge showrooms in early 1992.

pushed well to the rear to make room for an all-aluminum 8.0-liter V-10 engine, hooked to a Getrag-built 6-speed manual transmission supplying power to the rear wheels. Suspension (double A-arms in the front, a multilink setup at rear) employs no special trickery; just straightforward engineering. Monstrous tires—275 40ZR-17 front, 335 35ZR-17 rear—should provide the necessary grip to handle the V-10's estimated 450 lb.-ft. of torque and ought to produce cornering forces approaching the Corvette ZR-1's 0.94g.


The Viper's look is low, wide and menacing, with contours and proportions that haven't graced a U.S. production car for the last two decades. Its cabin is

READ THIS BEFORE YOU BEGIN


- Study the assembly drawings.
- Each plastic part is identified by a number.
- In the assembly drawings, some parts will be marked by a star (*) to indicate plated plastic.
- Scrape plating from areas to be cemented.
- Check the fit of each piece before cementing in place.
- Do not use too much cement to join parts.
- Use only cement for polystyrene plastic.
- Model may be painted to match photos on box.
- Allow paint to dry thoroughly before handling parts.
- Scrape paint from areas to be cemented.
- For better paint and decal adhesion, wash the plastic parts in a mild detergent solution. Rinse and let air dry.




• DO NOT CEMENT
• NE PAS COLLER
• NO USE
PEGAMENTO



• DECAL (DIP IN WATER)
• DECAL COMANIE (APLON
GEDANS L'EAU)
• DECAL COMANIA (MOJE
CON AGUA)



• REMOVE AND
THROW AWAY
• A RETIRER ET
JETER
• QUITE Y TIRE



• REPEAT SEVERAL
TIMES
• A REPETER
PLUSIEURS FOIS
• REPITA VARIAS VECES

LISEZ CE QUI SUIT AVANT DE COMMENCER LE MONTAGE

- Etudier les schémas d'assemblage.
- Chaque pièce plastique porte un numéro d'identification.
- Sur les schémas d'assemblage, les pièces dont numéro comporte une astérisque (*) sont en plastique chromé.
- Grattez le chromage sur les surfaces à coller.
- Contrôler que pièce soit bien conforme avant de la coller à sa place.
- N'utilisez pas trop de colle pour réunir les pièces.
- Utilisez uniquement une colle spéciale pour polystyrène.
- Le modèle peut être peint conformément aux photos sur la boîte.
- Laissez sécher la peinture complètement, avant de manipuler les pièces.
- Grattez la peinture sur les surfaces devant être collées.
- Pour assurer la meilleure adhésion possible de la peinture et des décalcomanies, lavez les pièces de plastique avec une légère solution savonneuse. Rincez et laissez sécher à l'air.

LEA ESTO ANTES DE EMPEZAR

- Estudie los dibujos de ensamble.
- Cada pieza de plástico se identifica por un número.
- En los dibujos de ensamble, algunos números de las piezas están marcados con una estrella (*) para indicar plástico laminado.
- Raspe el laminado de las superficies que serán pegadas.
- Verifique que cada pieza encaje bien antes de pegar en posición.
- No use demasiado pegamento para unir las piezas.
- Use únicamente pegamento para plástico de poliestirena.
- El modelo puede pintarse de acuerdo con las fotografías de la caja.
- Permita que se seque la pintura completamente antes de tocar las piezas.
- Raspe la pintura de las superficies que serán pegadas.
- Para una mejor fijación de la pintura y de las calcomanías, lávense las piezas plásticas en una solución de detergente suave. Enjuáguese y déjense secar al aire.

To complete this kit as shown, we recommend the following ProModeler paints.

Gloss Red (88-0003)	Rouge	Rojo
Aluminium (88-0014)	Aluminium	Aluminio
Steel (88-0015)	Metallique	Metálico
Satin Black (88-0016)	Noir Mat	Negro Mate
Turn Signal Amber (88-0017)	Ambre	Ambar
Flat Black (88-0022)	Noir Trene	Negro Apagado
Flat White (88-0023)	Blanc	Blanco
Light Ghost Gray (88-0034)	Gris Clair	Gris Fantasma Claro

Every effort has been made to create and manufacture a model kit that is the finest available. If a part may be missing, please write to:

Revell-Monogram
Consumer Service Department
8601 Waukegan Road
Morton Grove, Illinois 60053

Be sure to include the kit number, part number, description, and your return address.

(800) 833-3570

