

Top Flite Gold Edition Piper Arrow II Instruction Manual Addendum

**Please replace step 6 on page 34 with
the following two steps:**

- ❑ 6A. Drill 1/16" [1.6mm] holes through the punchmarks in the die-cut 1/8" [3mm] plywood **firewall bottom 1AB** so you will be able to see the marks on the other side.

- ❑ 6B. Glue 1AB to the other two die-cut 1/8" [3mm] plywood parts of the firewall bottom **1BB** and **1CB**. The parts should be stacked with the embossed lettering facing upward with 1AB on the bottom of the stack, 1BB in the middle and 1CB on the top.

Now the firewall bottom will be correctly assembled so you can continue with the rest of construction.