

FLIPPING the DROMIDA



The Dromida XL is equipped with a flipping function that will enable you to flip the quadcopter with the press of a button. Your first flips should be done at higher altitudes of at least 30-40 feet (9-12 meters) so you can become familiar with how the quad reacts.

Be sure the Dromida XL has plenty of room to flip. The area should be completely free of buildings, trees, poles, etc. as well as any spectators, and especially you, the pilot.



1. To prepare to flip, release the right stick to center and allow the Dromida XL to hover.

2. Press the left stick inward <“beep”> and release.



3. Use the right stick to choose a flipping direction.



NOTE: Normal control will not return until the right stick is allowed to return to center after a flip.

Press and hold the **MOTOR START/STOP** button for 1.5 seconds at any time to immediately shut down the motors.

4. Release the right stick (return to center) when the quad begins to flip.