

⚠️ **IMPORTANT!** ⚠️

READ BEFORE FLYING YOUR DROMIDA XL QUADCOPTER

The Dromida XL will need to be calibrated before your first flight and after any crash, hard landing or malfunction. This is very easy and takes only a few seconds. Please follow the steps below:

1. Center all the trim adjustments. To center the trim settings, hold down one side of the trim button until you hear a long beep. If the controller stops beeping, release the trim button and hold down the other side.
2. Place your Dromida XL on a level surface and link the quadcopter with the controller.
3. Press and hold both sticks to the lower right.
4. When the arm LEDs start to flash, release both sticks. The LEDs will stop flashing when the calibration is complete.



TIPS:

- a. If you crash, press and hold the **MOTOR START/STOP** button to stop the motors. You **WILL** damage the motors if the props are jammed.
- b. Unplug your flight battery after flying. **NEVER** leave the battery plugged in.