


DHC-2 Beaver

Island Wings Select Rx-R




INSTRUCTION MANUAL SUPPLEMENT


With the exception of the colors and receiver, this *Island Wings* Select Rx-R edition is the same as the original Flyzone DHC-2 Beaver Rx-R. Mount the receiver as illustrated in this supplement and refer to the parts below whenever ordering replacement parts for the *Island Wings* edition.



1. Apply a strip of the softer, "loop" side of the included double-sided adhesive-back Velcro® strip to your receiver (not included) and a strip of the rougher, "hook" side inside the fuselage where shown.



4. Mount the receiver. Follow the instructions in the main instruction manual to finish assembling the Beaver.



2. Connect the elevator, ESC (throttle) and rudder servo wires to the corresponding receptacles in the receiver—each is labeled Ch. 2, 3 & 4 accordingly. Connect the included Y-connector into channel 1 (ailerons) and connect the flap and light wires to available auxiliary receptacles in the receiver.

3. Link your transmitter to your receiver.

ISLAND WINGS PARTS

FLZA6545	Fuselage Set
FLZA6546	Wing Set
FLZA6547	Horizontal Stabilizer
FLZA6548	Vertical Stabilizer
FLZA6549	Main Landing Gear
FLZA6550	Cowl
FLZA6551	Float Set
FLZA6552	Float Brackets
FLZA6553	Hatch Set
FLZA6554	3-1/2" [90 mm] Tundra Wheels
FLZA6555	Wing Strut Set
FLZA6556	Decal Sheet

DHC-2 de HAVILLAND BEAVER AND ISLAND WINGS PARTS

FLZA6270	Tail Wheel Set
FLZA6272	12x6 Propeller
FLZA6273	Spinner
FLZA6274	Prop Adapter
FLZA6277	Water Rudders
FLZA6278	Wing Clips
FLZA6280	41-19-850 Motor
FLZA6281	40 Amp ESC
FLZA6283	Servo
FLZA6024	Flyzone LiPo Battery 3S 11.1V 1800mAh 20C
TACJ2600	Tactic TTX600 6Ch SLT 2.4GHz Radio System No Servos
TACL0624	Tactic TR624 6-Channel SLT 2.4GHz Receiver
GPM3318	Great Planes AC/DC 3S LiPo Balancing Smart Charger