



Tech Notice for FlightPower 2S, 4S, & 6S Battery Packs



The indicated red wire leads on these three packs, may come detached from the battery. While these wires are attached to the balance connector, they are **not connected** to the battery circuitry. The battery will charge and discharge properly without these wires attached to the battery or the balance lead.



It is recommended that you remove these wires from the balance connector. This can be done by using a hobby knife to pry the plastic retaining clip and removing the wire. This is only recommended for Flight Power 2S, 4S, and 6S packs.