


INSTRUCTION MANUAL ADDENDUM



Twinstar EP Front Windshield Options

There are two front windshield options for the Twinstar. Use the decal as-is or cut it to match the box.






INSTRUCTION MANUAL ADDENDUM




Before installing the nose gear pushrod, it is necessary to install the nose gear pushrod tube (attached with this addendum) into the fuselage.

1. Feed the tube through the steering opening in the firewall.



2. Use your index finger to lift the pushrod tube and slide it through the openings in formers 1, 2, and 3 so it extends to the servo tray.



3. When the tube is flush with the firewall it is fully installed. Add medium CA to secure the tube to the formers and firewall (as shown).

