



NEVER CONNECT PLUGS OF A DIFFERENT COLOR TOGETHER!!

THE SKYFLY INCLUDES AN AC WALL ADAPTER. THE BATTERY SHOULD NOT BE PLUGGED DIRECTLY INTO THE AC WALL ADAPTER.

THE SKYFLY AC WALL ADAPTER IS INTENDED TO BE USED ONLY WITH THE DC PEAK CHARGER.

To use the AC Wall Adapter please follow these instructions:

- Plug the AC Wall Adapter into a household wall outlet
- Plug the DC Peak Charger **black** connector into the AC Wall Adapter **black** connector
- Plug the **white** battery connector into the DC Peak Charger **white** connector
- Push the start button on the DC Peak Charger. The light will be red while charging.
- NEVER plug a battery directly into the AC Wall Adapter