




## TECHNICAL NOTICE

***On page 6, step 4,***



In order to complete step 4, it may be necessary to remove the elevator servo horn. When step 4 is complete, re-install the servo horn in the pre-removal position on the elevator servo shown on page 6 of the manual.

***On page 13, step 3 should read:***

- 3. Shift your fingers forward or aft between the tape lines until the model balances level on your fingertips. If you cannot balance the model between the tape lines, you will need to shift the battery and/or receiver forward or aft within the fuselage. If the tail continues to drop even with your fingers all the way at the aft tape lines, the model is “tail heavy”. You will need to move the battery pack and/or receiver forward. If the nose continues to drop even with your fingers all the way to the forward lines, the model is “nose heavy”. You will need to move the battery pack and/or receiver ***in the aft direction.***