



Instructions Update



Protect the environment by disposing of rechargeable batteries responsibly. Throwing rechargeable batteries into the trash or municipal waste system is illegal in some areas. Call 1-800-8-BATTERY for information about Ni-Cd battery recycling in your area.

Heli-Max®

CHARGING THE TRANSMITTER BATTERY

The transmitter supplied with your Axe 400 RTF includes a rechargeable Ni-Cd transmitter battery and an overnight charger. Ni-Cd batteries require special care and charging. For complete information please refer to the Futaba® 6EX-2.4GHz manual supplied with your Heli-Max Axe 400 RTF model.



NOTE: The batteries are supplied partially charged but will require a full, overnight charge before the model may be flown.

1. With the transmitter off, connect the transmitter charging cord from the A/C wall charger to the charge jack.

2. Plug the A/C wall charger into a wall outlet.

3. The LED indicator should glow red, indicating that the batteries are being charged. Discharged batteries will take about 15 hours to fully charge. If using an aftermarket fast charger, be certain to follow the manufacturer's instructions provided with the charger so you do not overcharge the batteries. **NEVER** charge the batteries at a rate higher than 600mAh.



Always disconnect the transmitter from the charger after 16 hours. Failure to do so may result in damaging the battery.

LIPO FLIGHT BATTERY PRECAUTIONS

Always disconnect the flight battery from the ESC and remove the battery from the model when you have completed a flight.



LiPo batteries should never be stored in a discharged state for long periods of time as this may damage the battery. After you finish the flight and after the battery has cooled down completely you must recharge the battery using the supplied charger before storing the battery.



Always allow the battery to cool down completely after a flight before charging the battery.



The LiPo battery chemistry has a fairly low self discharge rate and can be stored for a couple of months with the storage charge. After two months of storage you must recharge the battery using the included charger.

Heli-Max®