

AXE™ 100CP

Ready-to-Fly Electric Flybarless Helicopter

Technical Notice



The manual states that the TX-610's NOR/REV selection for Channel 3 should be reversed (REV). This is incorrect and should be adjusted to the **normal (NOR)** position.



These are the proper setup parameters for your Axe 100 CP when using the Spektrum DX6i transmitter. **NOTE:** This setup is a good overall base setup and should get you flying. Please feel free to adjust the settings to your liking as you get more comfortable flying your AXE100.

Axe100CP / DX6i		AILE	ELEV	THRO	RUDD	GYRO	PITC
Type		HELI					
Reverse		R	R	N	R	N	N
Dual Rates (D/R)		100/80	100/80		100/100		
Exponential (EXPO)		Pos 15	Pos 15		0		
Travel Adjustment		100%	100%	100%	100%	100%	100%
Norm Throttle		0	25	50	75	100	
Norm Pitch		42	50	56	66	78	
Stunt Throttle		100	95	90	95	100	
Stunt Pitch		35	45	56	66	78	
Throttle Hold		ON 0%					
Hold Pitch		NULL					
Gyro Mixing	SW-GYRO	ON		60	60		
Swashplate Type		90deg					
Timer		4min					

Spektrum is a registered trademark of Horizon Hobby, Inc.