

1SQ V-CAM & 1Si w/CAMERA TECHNICAL TIP

To minimize any chance of data being lost on the micro SD card, do not insert or remove the card from the camera until the battery is unplugged from the quadcopter.