

Heli-Max®



1Si TECHNICAL TIP

When initializing the 1Si, place the transmitter and quadcopter on a flat surface with the antenna pointed at the LED on the back of the 1Si. Turn on the transmitter before connecting the battery to the quadcopter.

If the 1Si barely responds when the right stick is moved and the quadcopter will not return when the ICM button is pressed, the Flight Sensitivity may need to be changed. Please follow the procedure on page 11 of the manual to adjust the sensitivity of the controls.