


# Heli-Max®




## ***1SQ V-CAM TECHNICAL NOTICE***

The 1SQ V-Cam card reader has been changed.



To use the card reader, first remove the cap.



On the bottom of the USB plug is a small notch. There is a slot below the notch where the microSD card should be installed.