

# Race helper 3 Operation Instruction

MR-RH3

## Features

Digital LCD

Simultaneously displays temperature, Humidity and time with digital LCD

Time and Alarm function

Displays time with alarm function

Two installing methods

Can be placed on the table, nailed on the wall

Basic Specifications and Parameters

Range: Indoor temperature(-30°C~50°C) Humidity(10%~99%)

Celsius - Fahrenheit

Choices of Celsius - Fahrenheit

Accuracy: 0.1 C Humidity 1%

Power: One AAA size battery (1.2~1.5V)

## Operational Instructions

### ● Maximum / Minimum Memory

Press key [MEMORY] and hold for a second to store and overwrite MAX/MIN temperature and MAX/MIN humidity.

### ● Memory Clearing

Press key [RESET] on the back side, and all memory will be cleared.

### ● Time / Month / Date / Alarm 12 or 24 Hour Setting

1. Press [MODE] key and hold 3 seconds to enter setting mode.

2. Press [MODE] to select Hour or Minute / Month / Date / Alarm 12/24 hour adjustment.

3. Press [ADJ] to adjust values, if pressed long enough, values will be fast adjusted.

### ● Alarm Setting

1. Press [MODE] to enter alarm setting mode.

2. Press [ADJ] to choose Alarm/Off

3. Press [MODE] and hold one second.

4. Press [ADJ] to adjust H or M, if pressed long enough, H or M will be fast adjusted.

### ● Month-Date Display

1. Press [ADJ]

2. LCD display will show you Month-Date. Display will be returned to Clock shortly.

The logo for 'Muchmore' is written in a bold, italicized, red font with a thick black outline. The letters are slanted to the right, giving it a dynamic and energetic appearance.

127-1, Poongdong, Ilsangu,

Goyangcity, Gyeong-gi do,

411-842, Korea

TEL +82 31 903 0487 FAX +82 31 903 0497