





INTELLITACH™
DIGITAL TACHOMETER INSTRUCTIONS







Step 1. Remove the battery cover and install a 9-volt battery.




Step 2. Reinstall the battery cover.




Step 3, Propeller selection: Press the left button to turn on the tach. The initial setting will show all three propeller types and each memory location until a default propeller is selected.




Step 4. Press the left button again to select a 3-bladed prop setting or a third time to select a 4-bladed prop setting.




Step 5, Saving a default propeller: If you commonly use the same style propeller on your model, you can save this as the "default" and eliminate the need to scroll through all the propeller settings. Press the left button until the desired prop appears (about 1 second), then, press and hold the right button until the prop starts flashing. To cancel the selected default setting: press and hold the right button until the prop starts flashing.




Step 6, Operation: From behind the model, hold the tach about 6-12" [150-300mm] from the prop. Always use a helper to hold the model.




Step 7. Tilt screen to eliminate sun glare, if needed.




Step 8, Saving your readings: If you wish to store the RPM setting, press the right button. Saving a RPM reading is helpful to gauge how an engine is running from one flying session to the next, when changing fuel type, propeller or glow plug. The memory feature allows you to store up to 3 readings.




Step 9. Press the right button again to resume real time RPM reading.



Step 10. The IntelliTach can save 3 RPM readings. The most recently “saved” reading is stored in the “Mem 1” location. The previous “Mem 1” reading moves to “Mem 2” and the previous “Mem 2” goes to “Mem 3.” The previous “Mem 3” will be lost.



Step 11. Tach will shut-off automatically after 5-minutes of inactivity.



Step 12. You may manually shut off the tach by sequencing the left button until the screen is blank.

GloBee Tachometer Performance Log

Memory #1

Date: ___ / ___ / ___

Airplane Model: _____

Engine: Brand _____ Size _____ Model _____

Engine was new on: ___ / ___ / ___

Propeller: Size ___ x ___ Brand _____ Modified Y or N

Fuel: Brand _____ Nitro Content _____%

Atmospheric Conditions: Temp _____ Humidity _____%

Comments: _____

Memory #2

Date: ___ / ___ / ___

Airplane Model: _____

Engine: Brand _____ Size _____ Model _____

Engine was new on: ___ / ___ / ___

Propeller: Size ___ x ___ Brand _____ Modified Y or N

Fuel: Brand _____ Nitro Content _____%

Atmospheric Conditions: Temp _____ Humidity _____%

Comments: _____

Memory #3

Date: ___ / ___ / ___

Airplane Model: _____

Engine: Brand _____ Size _____ Model _____

Engine was new on: ___ / ___ / ___

Propeller: Size ___ x ___ Brand _____ Modified Y or N

Fuel: Brand _____ Nitro Content _____%

Atmospheric Conditions: Temp _____ Humidity _____%

Comments: _____

ALSO AVAILABLE FROM GLOBEE



GloBee GloCharger

Recharge your glow starter as you fly! GloBee's GloCharger runs on 12V power. The unit shows a red LED during fast-charge and switches to trickle when fast charge is done. Easy to use and works in 15-minutes. **GLBP0100**

1-YEAR LIMITED WARRANTY *USA AND CANADA ONLY

GloBee warrants this product to be free from defects in materials and workmanship for a period of one (1) year from the date of purchase. During that period, GloBee will, at its option, repair or replace without service charge any product deemed defective due to those causes. You will be required to provide proof of purchase (invoice or receipt). This warranty does not cover damage caused by abuse, misuse, alteration or accident. If there is damage resulting from these causes within the stated warranty period, GloBee will, at its option, repair or replace it for a service charge not greater than 50% of its then current retail price. Be sure to include your daytime telephone number in case we need to contact you about your repair. This warranty gives you specific rights. You may have other rights, which vary from state to state.

For service on your GloBee product, either in or out of warranty, send it post paid and insured to:

Hobby Services
1610 Interstate Drive
Champaign, IL 61821
(217) 398-0007

e-mail: productsupport@hobbico.com
<http://www.hobbies.net/globe/index.html>

*For warranty and service information if purchased outside the USA or Canada, ask your retailer for more information.