



P-51D MUSTANG ARF .60 SIZE



Wingspan: 64.5 in [1640mm]
Wing Area: 721 sq in [46.5 dm²]
Weight: 8.75 – 10 lb [3970 – 4540g]
Wing Loading: 28 – 32 oz/ft² [85 – 98g/dm²]
Length: 56 in [1420mm]
Radio: 6+ channel with 8 servos
Engine: .60 – .91 cu in [10 – 15cc] two-stroke,
 .90 – 1.20 cu in [15 – 20cc] four-stroke

WARRANTY.....

Top Flite® Models guarantees this kit to be free from defects in both material and workmanship at the date of purchase. This warranty does not cover any component parts damaged by use or modification. **In no case shall Top Flite's liability exceed the original cost of the purchased kit.** Further, Top Flite reserves the right to change or modify this warranty without notice.

In that Top Flite has no control over the final assembly or material used for final assembly, no liability shall be assumed nor accepted for any damage resulting from the use by the user of the final user-assembled product. By the act of using the user-assembled product, the user accepts all resulting liability.

If the buyer is not prepared to accept the liability associated with the use of this product, the buyer is advised to return this kit immediately in new and unused condition to the place of purchase.

To make a warranty claim send the defective part or item to Hobby Services at the address:

Hobby Services
 3002 N. Apollo Dr., Suite 1
 Champaign, IL 61822 USA

Include a letter stating your name, return shipping address, as much contact information as possible (daytime telephone number, fax number, e-mail address), a detailed description of the problem and a photocopy of the purchase receipt. Upon receipt of the package the problem will be evaluated as quickly as possible.

READ THROUGH THIS MANUAL BEFORE STARTING CONSTRUCTION. IT CONTAINS IMPORTANT INSTRUCTIONS AND WARNINGS CONCERNING THE ASSEMBLY AND USE OF THIS MODEL.

Top Flite Models Champaign, IL

Telephone (217) 398-8970, Ext. 5

airsupport@top-flite.com

TABLE OF CONTENTS

INTRODUCTION	2
AMA	2
SAFETY PRECAUTIONS	2
DECISIONS YOU MUST MAKE	3
Building Stand	3
Radio Equipment	3
Engine Recommendations	3
Landing Gear Options	3
Scale Competition	3
ADDITIONAL ITEMS REQUIRED	4
Hardware & Accessories	4
Adhesives & Building Supplies	4
Optional Supplies & Tools	4
IMPORTANT BUILDING NOTES	4
KIT INSPECTION	5
Kit Contents	5
ORDERING REPLACEMENT PARTS	5
Replacement Parts List	5
METRIC CONVERSIONS	5
PREPARATIONS	7
ASSEMBLE THE WING	7
Hinge the Ailerons & Flaps	7
Mount the Servos	9
Install the Aileron & Flap Pushrods	10
Join the Wing Panels	11
Install the Retracts	13
Install the Retract Servo	14
Finish the Wing	14
Optional Strut Cover Installation	15
ASSEMBLE THE TAIL SECTION	15
Install the Horizontal Stabilizer, Elevators, Servos & Linkages	15
Install the Rudder, Tail Wheel & Linkages	18
INSTALL THE POWER SYSTEM & RECEIVER	19
Glow Engine Installation	19
Install the Receiver & Battery	21
FINISH THE MODEL	22
Install the Cowl	22
Install the Cockpit & Canopy	23
Install the Propeller & Spinner	24
Optional Pneumatic Retracts	25
Apply the Decals	25
GET THE MODEL READY TO FLY	25
Check the Control Directions	25
Set the Control Throws	26
Balance the Model (C.G.)	26
Balance the Model Laterally	27
PREFLIGHT	27
Identify Your Model	27

Charge the Batteries	27
Balance Propellers	27
Ground Check	27
Range Check	27
ENGINE SAFETY PRECAUTIONS	28
AMA SAFETY CODE (EXCERPTS)	28
General	28
Radio Control	28
CHECK LIST	29
FLYING	29
Fuel Mixture Adjustments	29
Takeoff	29
Flight	30
Landing	30

INTRODUCTION

Following the great success of the .60-sized Top Flite P-51 Mustang kit comes the same beautiful model in ARF form! The sky is the limit for the amount of additional detail that could be added during the building process to make the P-51 Mustang ARF a model even the most serious scale-minded builder could appreciate. The model assembles in as little as 15 to 20 hours with time-consuming painting tasks expertly complete out of the box.

For the latest technical updates or manual corrections to the P-51 Mustang ARF visit the Top Flite web site at www.top-flite.com. Open the "Airplanes" link, then select the P-51 Mustang ARF. If there is new technical information or changes to this model a "tech notice" box will appear in the upper left corner of the page.

AMA

We urge you to join the AMA (Academy of Model Aeronautics) and a local R/C club. The AMA is the governing body of model aviation and membership is required to fly at AMA clubs. Though joining the AMA provides many benefits, one of the primary reasons to join is liability protection. Coverage is not limited to flying at contests or on the club field. It even applies to flying at public demonstrations and air shows. Failure to comply with the Safety Code (excerpts printed in the back of the manual) may endanger insurance coverage. Additionally, training

programs and instructors are available at AMA club sites to help you get started the right way. There are over 2,500 AMA chartered clubs across the country. Contact the AMA at the address or toll-free phone number below:



Academy of Model Aeronautics
 5151 East Memorial Drive
 Muncie, IN 47302-9252
 Tele. (800) 435-9262
 Fax (765) 741-0057
 Or via the Internet at:
<http://www.modelaircraft.org>

IMPORTANT!!! Two of the most important things you can do to preserve the radio controlled aircraft hobby are to avoid flying near full-scale aircraft and avoid flying near or over groups of people.

PROTECT YOUR MODEL, YOURSELF & OTHERS. FOLLOW THESE IMPORTANT SAFETY PRECAUTIONS

1. Your P-51 Mustang ARF should not be considered a toy, but rather a sophisticated, working model that functions very much like a full-size airplane. Because of its performance capabilities, the P-51 Mustang ARF, if not assembled and operated correctly, could possibly cause injury to yourself or spectators and damage to property.
2. You must assemble the model **according to the instructions**. Do not alter or modify the model, as doing so may result in an unsafe or unflyable model. In a few cases the instructions may differ slightly from the photos. In those instances the written instructions should be considered as correct.
3. You must take time to **build straight, true and strong**.
4. You must use an R/C radio system that is in first-class condition, and a correctly sized engine and components (servos, servo extension, etc.) throughout the building process.

5. You must correctly install all R/C and other components so that the model operates correctly on the ground and in the air.

6. You must check the operation of the model before **every** flight to insure that all equipment is operating and that the model has remained structurally sound. Be sure to check clevises or other connectors often and replace them if they show any signs of wear or fatigue.

7. If you are not an experienced pilot or have not flown this type of model before, we recommend that you get the assistance of an experienced pilot in your R/C club for your first flights. If you're not a member of a club, your local hobby shop has information about clubs in your area whose membership includes experienced pilots.

8. While this kit has been flight tested to exceed normal use, if the plane will be used for extremely high stress flying, such as racing, or if an engine larger than one in the recommended range is used, the modeler is responsible for taking steps to reinforce the high stress points and/or substituting hardware more suitable for the increased stress.


We, as the kit manufacturer, provide you with a top quality, thoroughly tested kit and instructions, but ultimately the quality and flyability of your finished model depends on how you build it; therefore, we cannot in any way guarantee the performance of your completed model, and no representations are expressed or implied as to the performance or safety of your completed model.

Remember: Take your time and follow the instructions to end up with a well-built model that is straight and true.

DECISIONS YOU MUST MAKE

This is a partial list of items required to finish the P-51 Mustang ARF that may require planning or decision making before starting to build. Order numbers are provided in parentheses.

BUILDING STAND



A building stand or cradle comes in very handy during the build. We use the Robart Super Stand II (ROBP1402) for most of our projects in R&D, and it can be seen in pictures throughout this manual.

RADIO EQUIPMENT

A 6-channel radio system such as a Futaba® 6EXAS with a standard receiver and six standard size servos with a minimum torque of 44 oz-in [3.2 kg-cm] are required for the control surfaces of the P-51 Mustang ARF. The included mechanical retracts require a 180° retract servo. If you will be installing optional pneumatic retracts, a micro servo will be required to operate the air valve. One standard torque servo such as an S3003 is required for the throttle. Two 24" [610mm] servo extensions (aileron servos) and two Y-harnesses (aileron and flap servos) are also required. A receiver battery pack with a minimum capacity of 1000mAh is recommended. Order numbers are provided as follows:

- Futaba S9001 Servo Aircraft Coreless BB (FUTM0075)

- Futaba S136G Compact Retract Servo (FUTM0670)
- Futaba S3003 Servo Standard (FUTM0031)
- Hobbico® Extension 24" Futaba J (HCAM2200)
- Futaba 6" Dual Servo Extension J (FUTM4130)
- Futaba NR4RB Receiver NiCd 4.8V 1000mAh (FUTM1380)

Optional:

- Futaba S3115 Micro Precision Servo (FUTM0415)

ENGINE RECOMMENDATIONS

A .60 to .91 cu in [10 to 15cc] two-stroke or .90 to 1.20 [15 to 20cc] four-stroke engine is required. An O.S.® FS-91 Surpass™ II four-stroke engine installation is shown in this manual.

- O.S. FS-91 Surpass II (OSMG0896)

LANDING GEAR OPTIONS

The P-51 Mustang ARF includes mechanical retracts. Optional pneumatic retracts can also be installed. Part numbers are provided below.

- Robart® 605HD 90° main landing gear w/3/16" wire (ROBQ0005)
- Robart 188VR standard air control kit (ROBQ2302)
- Robart 190 air line quick disconnects (ROBQ2395)

SCALE COMPETITION

Though the Top Flite P-51 Mustang ARF may not have the same level of detail as an "all-out" scratch-built competition model, it is a scale model nonetheless and is therefore eligible to compete in the *Fun Scale* class in AMA competition (we receive many favorable reports of Top Flite models in scale competition!). To receive the five points for scale documentation, the only proof required that a full-size aircraft of this type in your paint/markings scheme did exist is a single sheet such as a kit box cover from a plastic model, a photo, or a profile painting, etc. If the photo is in black and white

other written documentation of color must be provided. Contact the AMA for a rule book with full details.

If you would like photos of the full-size P-51D Mustang for scale documentation, or if you would like to study the photos to add more scale details, photo packs are available from:

Bob's Aircraft Documentation
3114 Yukon Ave
Costa Mesa, CA 92626

Telephone: (714) 979-8058
Fax: (714) 979-7279

E-mail: www.bobsairdoc.com

ADDITIONAL ITEMS REQUIRED

HARDWARE & ACCESSORIES

In addition to the items listed in the "**Decisions You Must Make**" section, following is the list of hardware and accessories required to finish the P-51 Mustang ARF. Order numbers are provided in parentheses.

- R/C foam rubber (1/4" [6mm] - HCAQ1000, or 1/2" [13mm] - HCAQ1050)
- 3' [900mm] Standard silicone fuel tubing (GPMQ4131)

ADHESIVES & BUILDING SUPPLIES

In addition to common household tools (screwdrivers, drill, etc.), this is the "short list" of the most important items required to build the P-51 Mustang ARF. We recommend **Great Planes Pro™ CA and Epoxy glue**.

- 1/2 oz. [15g] Thin Pro CA (GPMR6001)
- Pro 30-minute epoxy (GPMR6047)
- Pro Threadlocker (GPMR6060)
- Drill bits: 1/16" [1.6mm], 5/64" [2mm], 3/32" [2.4mm], 3/16" [4.8mm]
- 8-32 Tap and drill set (GPMR8103)
- Silver solder w/flux (STAR2000)
- #1 Hobby knife (HCAR0105)

- #11 Blades (5-pack, HCAR0211)
- Medium T-pins (100, HCAR5150)
- Masking tape (TOPR8018)
- Denatured alcohol (for epoxy clean up)
- Panel Line Pen (TOPQ2510)
- 220-grit Sandpaper
- Petroleum jelly or oil

OPTIONAL SUPPLIES & TOOLS

Here is a list of optional tools that will help you build the P-51 Mustang ARF.

- Top Flite MonoKote® sealing iron (TOPR2100)
- Top Flite Hot Sock™ iron cover (TOPR2175)
- Top Flite Trim Seal Tool (TOPR2200)
- 1/2 oz. [15g] Medium Pro CA+ (GPMR6007)
- 1/2 oz. [15g] Thick Pro CA- (GPMR6013)
- Pro 6-minute epoxy (GPMR6045)
- Small metal file
- Stick-on segmented lead weights (GPMQ4485)
- 2 oz. [57g] Spray CA activator (GPMR6035)
- 4 oz. [113g] Aerosol CA activator (GPMR6034)
- CA applicator tips (HCAR3780)
- CA debonder (GPMR6039)
- Epoxy brushes 6, (GPMR8060)
- Mixing sticks (GPMR8055)
- Mixing cups (GPMR8056)
- Pliers with wire cutter (HCAR0630)
- Compressed air 10 oz (TAEC1060)
- Microballoons (TOPR1090)
- Switch & Charge Jack Mounting Set (GPMM1000)
- Ernst charge receptacle Futaba J (ERNM3001)
- Rotary tool such as Dremel®
- Rotary tool reinforced cut-off wheel (GPMR8020)
- Servo horn drill (HCAR0698)
- Hobby Heat™ micro torch (HCAR0750)
- Dead Center™ engine mount hole locator (GPMR8130)
- AccuThrow™ Deflection Gauge (GPMR2405)
- C.G. Machine™ (GPMR2400)
- Precision magnetic prop balancer (TOPQ5700)
- Hobbico flexible 18" ruler stainless steel (HCAR0460)

- Hobbico pin vise 1/16" collet w/6 bits (HCAR0696)
- Hobbico 8-piece ball tip hex wrench (SAE HCAR0520)
- Hobbico 7-piece ball tip hex wrench (metric HCAR0521)
- Great Planes precision prop reamer (SAE GPMQ5006)
- Great Planes Precision Prop Reamer (metric GPMQ5007)
- Great Planes clevis installation tool (GPMR8030)
- X-Acto® X-tra Hands double clip (XACR4214)

IMPORTANT BUILDING NOTES


- There are two types of screws used in this kit:

Sheet Metal Screws are designated by a number and a length. For example #6 x 3/4" [19mm].



This is a number six screw that is 3/4" [19mm] long.

Machine Screws are designated by a number, **threads per inch**, and a length. For example 4-40 x 3/4" [19mm].



This is a number four screw that is 3/4" [19mm] long with forty threads per inch.

- When you see the term **test fit** in the instructions, it means that you should first position the part on the assembly **without using any glue**, then slightly modify or *custom fit* the part as necessary for the best fit.

- Whenever the term **glue** is written you should rely upon your experience to decide what type of glue to use.

When a specific type of adhesive works best for that step, the instructions will make a recommendation.

- Whenever just **epoxy** is specified you may use **either** 30-minute (or 45-minute) epoxy **or** 6-minute epoxy. When 30-minute epoxy is specified it is **highly** recommended that you use only 30-minute (or 45-minute) epoxy, because you will need the working time and/or the additional strength.

- **Photos** and **sketches** are placed **before** the step they refer to. Frequently you can study photos in following steps to get another view of the same parts.

KIT INSPECTION

Before starting to build, inspect the parts to make sure they are of acceptable quality. If any parts are missing or are not of acceptable quality, or if you need assistance with assembly, contact **Product Support**. When reporting defective or missing parts, use the part names exactly as they are written in the “**Kit Contents**” list on this page.

Top Flite Product Support

3002 N. Apollo Drive, Suite 1

Champaign, IL 61822

Telephone: (217) 398-8970

Fax: (217) 398-7721

E-mail: airsupport@top-flite.com

KIT CONTENTS

1. Fiberglass Air Scoop
2. Right Aileron
3. Right Flap
4. Right Wing Panel
5. Fuselage
6. Elevator Joiner Wire
7. Tail Wheel
8. Tail Wheel Wire
9. Right Elevator

10. Rudder
11. Horizontal Stabilizer
12. Left Elevator
13. Left Flap
14. Left Wing Panel
15. Left Aileron
16. Right Machine Guns
17. Right Strut Cover
18. Fuel Tank
19. Fiberglass Cowl
20. Right ABS Exhaust Stack
21. Engine Mount Halves
22. Spinner
23. Belly Pan
24. Left ABS Exhaust Stack
25. Canopy
26. Dummy Radio & Battery
27. Seat Back
28. Pilot Figure
29. Instrument Panel
30. Left Strut Cover
31. Left Machine Guns

ORDERING REPLACEMENT PARTS

To order replacement parts for the Top Flite P-51 Mustang ARF, use the order numbers in the **Replacement Parts List** that follows. Replacement parts are available only as listed. Not all parts are available separately (an aileron cannot be purchased separately, but is only available with the wing kit). Replacement parts are not available from Product Support, but can be purchased from hobby shops or mail order/Internet order firms. Hardware items (screws, nuts, bolts) are also available from these outlets. If you need assistance locating a dealer to purchase parts, visit www.top-flite.com and click on “Where to Buy.” If this kit is missing parts, contact **Product Support**.

REPLACEMENT PARTS LIST

<u>Order Number</u>	<u>Description</u>	<u>How to purchase</u>
Missing Pieces.....	Contact Product Support	
Instruction Manual	Contact Product Support	
Full-Size Plans.....	Not Available	

Contact your hobby supplier to purchase these items:

- TOPA1725 Fuselage Set
- TOPA1726 Wing Set
- TOPA1727 Tail Set (Elevators and Stabilizers)
- TOPA1728 Cowl
- TOPA1729 Cockpit Kit
- TOPA1730 Decal
- TOPA1731 Canopy
- TOPA1732 Spinner
- TOPA1733 Air Scoop
- TOPA1734 Dummy Exhaust
- TOPA1735 Landing Gear Struts
- TOPA1736 Landing Gear Doors
- TOPQ7950 Retracts Landing Gear

METRIC CONVERSIONS


1" = 25.4mm (conversion factor)

1/64" = .4mm	3/4" = 19.0mm
1/32" = .8mm	1" = 25.4mm
1/16" = 1.6mm	2" = 50.8mm
3/32" = 2.4mm	3" = 76.2mm
1/8" = 3.2mm	6" = 152.4mm
5/32" = 4.0mm	12" = 304.8mm
3/16" = 4.8mm	18" = 457.2mm
1/4" = 6.4mm	21" = 533.4mm
3/8" = 9.5mm	24" = 609.6mm
1/2" = 12.7mm	30" = 762.0mm
5/8" = 15.9mm	36" = 914.4mm



PREPARATIONS

❑ 1. If you have not done so already, remove the major parts of the kit from the box and inspect for damage. If any parts are damaged or missing, contact Product Support at the address or telephone number listed in the **“Kit Inspection”** section on page 5.





❑ 2. Carefully remove the tape and separate all the control surfaces. Use a covering iron with a covering sock on medium/high heat to tighten the covering if necessary. Apply pressure over sheeted areas to **thoroughly** bond the covering to the wood.



ASSEMBLE THE WING

HINGE THE AILERONS & FLAPS

You can do the right wing first so your work matches the photos the first time through, or you can work on them together.




❑ ❑ 1. Test fit the included hinge points into the pre-drilled pockets in the **flap**. Press the hinge points into the pockets with the tabs on the hinge points aligned parallel with the hinge line on the flap. Push the hinge points as far deep as they can fit into the pockets in the flap. Work the hinge up and down in the pocket. Be sure that the hinges move freely inside the pocket. If there is any interference, use a hobby knife to slightly enlarge the pocket as necessary.




❑ ❑ 2. Fit the flap to the **wing panel** by inserting the other ends of the hinge points into the pockets

in the wing TE. Push the flap up against the wing so that the flap LE and the wing TE edge touch. If the two surfaces cannot touch, carefully deepen the hinge point pockets in the wing panel with a 3/16" [4.8mm] drill bit as necessary. When satisfied, deflect the flap down at least 1-1/4" [32mm] which will cause the pivot pins in the hinge points to align themselves in the center of the flap LE radius. Work the flap up and down to ensure smooth movement.





❑ ❑ 3. Remove the flap from the wing panel and pull the hinge points from the pockets. Coat the center of each hinge point with petroleum jelly or oil. This will prevent epoxy from sticking to the pivoting portion of the hinges.

Before performing steps 4 and 5, have denatured alcohol and some paper towel pieces ready for epoxy cleanup.




❑ ❑ 4. Mix up a batch of 30-minute epoxy. Use a toothpick or something similar to coat the insides of the hinge point pockets in the flap and the wing


panel. Wipe away any excess epoxy from around the pockets using a paper towel dampened with alcohol.





5. Coat one end of each hinge point with epoxy up to the tabs. Insert the hinges into the pockets in the flap. Use a clean toothpick to scrape out any excess epoxy that may have squeezed out of the pocket.





6. Coat the other end of each hinge point up to LE of the flap. Slowly join the flap to the wing while wiping away any excess epoxy that squeezes out of the pockets. When the flap is all the way against the wing panel, deflect it downward and check the LE for excess epoxy. Pull the flap away from the wing approximately 1/64" [0.4mm] so that the LE does not bind against the wing TE when the flap is deflected. When satisfied, set the wing aside and allow the epoxy to cure undisturbed.



7. Cut the included 2" x 9" [51 x 229mm] piece of CA hinge material into 3/4" x 1" [19 x 25mm] individual hinges. Use a hobby knife or scissors to trim the corners from each hinge to make them easier to insert into the hinge slots.




8. Drill a 3/32" [2.4mm] hole 1/2" [13mm] deep in the center of each hinge slot in the wing panel and aileron. Use a sharp hobby knife to carefully cut away the covering just around each hinge slot.



9. Fit a CA hinge into each hinge slot in the wing panel. If the hinges are difficult to install, use a hobby

knife to slightly enlarge the slots. Push a pin (T-pins work well for this) through the middle of each hinge to keep them centered.




10. Fit the aileron to the hinges and center it between the wing tip and the flap. Remove the pins from the hinges and position the aileron against the TE of the wing panel. The hinge gap between the aileron and wing should only be wide enough to allow a small line of light through. When satisfied, apply 6 drops of thin CA glue to the center of each hinge on both sides. When the CA has dried, gently pull on the aileron to confirm that it is securely glued in place.


11. Repeat steps 1-10 for the left wing panel.

MOUNT THE SERVOS


Before completing this section, confirm that the servos that you will be using will properly fit between the servo mounting block locations on the aileron and flap servo hatch covers. Make adjustments as necessary for your brand servos. The block locations shown in this section will fit a standard size Futaba brand servo.




1. Use epoxy to glue the 5/16" x 3/4" x 3/4" [8 x 19 x 19mm] hardwood servo mounting blocks to the inside of the aileron servo hatch cover. Be sure that the blocks are aligned over the rectangles with the grain direction perpendicular to the covers as shown. Allow the epoxy to cure undisturbed.





2. Cut three arms from a four-armed servo arm included with the aileron servo. Enlarge the outer hole of the remaining arm with a 5/64" [2mm] drill bit.




3. Attach a 24" [610mm] servo extension to each aileron servo and secure the connector using tape or heat shrink tubing (not included). Center the servos with your radio system and install the servo arm to the servo perpendicular to the servo case as shown. Be sure to reinstall the servo arm screw into the servo.



4. Place a piece of paper folded several times, between the servo and the servo hatch cover to raise the servo off of the servo hatch. Position the servo against the underside of the aileron servo hatch cover between the mounting blocks. Drill 1/16" [1.6mm] holes through the mounting tabs on the servo case into the blocks. Thread a servo mounting screw (included with the servo) into each hole and back it out. Remove the piece of paper and apply a drop of thin CA to each hole to harden the wood. When the CA has dried, install the servo onto the hatch cover using the hardware supplied with the servo.



□ □ 5. Use the string taped inside the aileron servo hatch to pull the servo lead through the wing ribs.




□ □ 6. Thread a #2 x 3/8" [9.5mm] self-tapping screw into each hatch mounting hole and back it out. Apply a drop of thin CA to each hole to harden the wood. Install the aileron hatch cover to the wing as shown using four #2 x 3/8" [9.5mm] self-tapping screws.





□ □ 7. Mount the flap servo and hatch cover in the same way. The flap servo does not require a servo lead extension.

□ □ 8. Repeat steps 1 to 7 for the left wing panel. Make note that the flap servo arm will be mounted on the root rib side of the left wing panel so that when the flap servos are joined together using a Y-harness, they will both move in the same direction.

INSTALL THE AILERON & FLAP PUSHRODS



□ □ 1. Thread a 2-56 nut and a metal clevis 15 complete turns onto a 4" [152mm] pushrod. Slide a silicone clevis retainer onto the clevis and connect the clevis to the outer hole of a nylon control horn.






□ □ 2. Position the control horn over the **plywood plate** in the aileron (if you cannot see it, hold the aileron at a shallow angle in good lighting or use a small pin to puncture the covering) using the position of the servo arm as a guide. Align the holes in the control horn directly over the aileron hinge line and mark the location of the control horn mounting holes.






□ □ 3. At the marks, drill 1/16" [1.6mm] holes through the plywood plate. **Do not drill all the way through the aileron!** Thread a #2 x 3/8" [9.5mm] self-tapping

screw through each hole and back it out. Apply a couple drops of thin CA glue to each hole to harden the wood. When the glue has dried, install the control horns onto the aileron using two #2 x 3/8" [9.5mm] self-tapping screws.



4. Use tape or a small clamp to hold the aileron in the neutral position. Make a mark on the pushrod where it crosses the outer hole in the servo arm. Make a 90° bend at the mark on the pushrod and cut off the excess pushrod 1/4" [6mm] beyond the bend. Attach the pushrod to the servo arm using a nylon FasLink. Thread the clevis up or down on the pushrod as necessary to center the aileron with the servo arm centered. When satisfied, apply a drop of threadlocking compound onto the threads behind


the clevis and tighten the 2-56 nut against it. Slide the silicone clevis retainer to the end of the clevis to secure it.





5. The flap pushrod is installed in the same manner. The control horn must be trimmed as shown to clear the TE of the wing when the flap is deflected down. Also, use the aileron hinge line as a guide to position the control horn onto the flap (as described in step 2)

6. Repeat steps 1-5 for the other wing panel.

JOIN THE WING PANELS




1. Route the flap and aileron servo leads through the holes on the top of the wing near the root of each wing panel.




2. Locate the three **plywood wing joiners**. Glue the pieces together with 30-minute epoxy, being sure

that the sides are flush with each other. Wipe away any excess epoxy with denatured alcohol. Small clamps can be used to hold the pieces together while the epoxy cures.




❑ 3. Test fit the joiner into **the wing joiner pocket** of each wing panel with the “V” shaped side pointing to the bottom of the wing. The joiner should be able to fit halfway into each pocket and be slightly loose to allow room for epoxy. Sand the joiner as necessary for the proper fit. Dry fit the wing panels together using the joiner and nylon anti-rotation pin. The root ribs of the panels should sit flat against each other with no gaps. Lightly sand the face of the root ribs if necessary to eliminate any gaps between the wing panels.




❑ 4. When satisfied with the fit of the wing panels, mix up a batch of 30-minute epoxy and coat the inside of the wing joiner pockets in each wing panel. Coat one half of the anti-rotation pin and press it into the hole at the TE edge of one wing panel. Coat one


half of the wing joiner and slide it into one wing panel. Coat the root ribs of both wing panels as well as the exposed ends of the joiner and anti-rotation pin. Join the two wing panels together and use paper towels dampened with denatured alcohol to wipe away any excess epoxy from the joint between the panels. Use masking tape to hold the panels together tightly. Set the wing aside and let the epoxy cure undisturbed.



❑ 5. Draw a line down the middle of the plywood **wing bolt plate**. Use a micro saw or a hobby knife to cut a groove down the line approximately halfway through the thickness of the plate. This groove will allow the plate to easily bend over the dihedral angle of the wing.



❑ 6. Position the wing bolt plate onto the underside of the wing with the bolt holes centered over the holes in the wing. Use a fine, felt-tip pen to trace along the outside of the plate onto the wing.




❑ 7. Remove the covering just inside the lines you drew. Glue the wing bolt plate into position.




How To Cut Covering From Balsa

Use a soldering iron to cut the covering from the area beneath the wing bolt plate. The tip of the soldering iron doesn't have to be sharp, but a fine-tip does work best. Allow the iron to heat fully.




Use a straightedge to guide the soldering iron at a rate that will just melt the covering and not burn into the wood. The hotter the soldering iron, the faster it must travel to melt a fine cut. Peel off the covering.




❑ 8. Use epoxy to glue the nylon wing dowels into the holes in the LE of the wing. The dowels should protrude beyond the LE of the wing 1/2" [13mm].

INSTALL THE RETRACTS




❑ 1. Use a 2mm hex wrench to remove the four set screws (two per side) in the retract pivot. The first set on each side secures the landing gear wire in the retract pivot. The second set screw on each side locks the first set screw in the retract pivot. Apply a drop of threadlocker to the threads of the set screws. Reinstall the set screws making sure that they tighten on the flats on the landing gear wires. Be sure to assemble a left and right retract.



❑ 2. Remove the 3mm set screws from the axles. Apply a drop of threadlocker to the set screws and reinstall them in the axles. Slide the axles onto the landing gear wires tightening the set screws on the flat spots at the end of the wires. Note the direction of the axles.




❑ 3. Apply a drop of threadlocker to the threads of a 6-32 x 1/4" [6.4mm] socket head bolt. Install the bolt in a 4mm wheel collar. Slide the wheel collar onto the axle and tighten the 6-32 bolt. Slide a 3-1/4" [82mm] foam wheel on the axle and secure the wheel with a second wheel collar. Make sure the wheel turns freely.




❑ 4. Insert the retracts in the retract openings in the wing. Adjust the position of the retracts so that the retract body is centered on the mounting rails. Adjust the position of the axle on the landing gear wire so that the wheel is centered in the wheel well.

❑ 5. On the retract mounting rails, mark the four retract mounting holes. Remove the retracts and drill a 7/64" [2.7mm] pilot hole at each mark.



❑ 6. In one end of a 1/16" x 12" [1.6 x 12.7mm] wire pushrod make a Z-bend. Insert the Z-bend in the nylon horn on the retract.



- ❑ 7. Insert the retract wire in the retract pushrod tube. Position the retracts on the retract rails. Secure the retracts to the rails using four #6 x 1/2" [12.7mm] sheet metal screws. Operate the retracts by pushing and pulling the retract wire.

INSTALL THE RETRACT SERVO



- ❑ 1. Glue the **retract servo tray** pieces together inside the **retract servo bay** as shown. The pieces

must be glued together after being inserted into place in the servo bay.





- ❑ 2. Install the retract servo onto the servo tray with the servo spline facing forward using the hardware included with the servo. Be sure to reinforce the servo screw holes with thin CA glue. Use your radio system to bring the retract servo into the counterclockwise locked position (raising the retracts).



- ❑ 3. Cut four arms from a six-arm servo arm, leaving two arms opposite each other. Attach a brass screw-lock pushrod connector to each arm in the outer holes using a nylon retainer to secure them. Loosely thread a 4-40 x 1/8" [3.2mm] SHCS into each screw-lock pushrod connector. Slide the retract pushrod wires through the screw-lock pushrod connectors and press the arm onto the servo spline in the orientation shown. With the retract pushrods all the way in the retracted position, tighten the SHCS in the screw-lock pushrod connectors against the pushrods. Test the operation of the retracts with your radio system.

Confirm that the servo does not bind and that the retracts fully raise and lower to the locked positions. Make any adjustments necessary with the screw-lock pushrod connectors and servo arm position. If the pushrod length interferes with the rotation of the servo, cut them shorter as necessary. When satisfied, secure the servo arm to the servo using the servo arm screw included with the servo.

FINISH THE WING




- ❑ 1. Temporarily install the wing onto the fuselage using two 1/4-20 nylon wing bolts. The wing dowels will fit into receiving holes in the former at the LE edge of the wing. Align the fiberglass **air scoop** onto the underside of the wing in line with the fuselage and tape it into position. Use a felt-tip pen to trace around the air scoop onto the wing. Remove the scoop and trim a 1/4" [6mm] strip of covering from the underside of the wing just inside the line you drew.



❑ 2. Sand the gluing edge of the air scoop with 220-grit sandpaper and clean the surface with alcohol. Place a piece of wax paper or plastic wrap between the wing and fuselage to prevent them from being glued together. Coat the gluing surface with epoxy and return the scoop to the wing. Use tape or a weight to hold the scoop in place while the epoxy cures. Clean up any excess epoxy with denatured alcohol.




❑ 3. Glue the **belly pan** to the front underside of the wing in the same manner as the air scoop.




❑ 4. Roughen the inside surface of the ABS **machine guns** with 220-grit sandpaper. Glue the machine guns to the wing LE 2-7/8" [73mm] from the outside edge of the white stripes.

OPTIONAL STRUT COVER INSTALLATION

*Painted **strut covers** are provided for added realism and can be installed at the modeler's discretion.*



❑ 1. Position the strut covers over the **landing gear struts** aligning the colors on the covers with the covering on the wing. Center the covers in the openings. Use a felt-tip pen to mark the center of the landing gear strut onto each edge of the covers. Also, mark the position of the inside edge of the cover onto the strut. Accuracy in this step will ensure strut covers that are properly positioned onto the struts.




❑ 2. Lower the retracts and remove the wheels. Tape the strut covers to the struts using the marks you made as guides. Place two hump straps onto each strut in the positions shown and mark the location for the screw holes onto the undersides of the strut covers. Drill 3/32" [2.4mm] holes through the covers at the marks. Secure the covers to the




struts using eight 2-56 x 1/2" [13mm] machine screws and eight 2-56 nuts.

ASSEMBLE THE TAIL SECTION

INSTALL THE HORIZONTAL STABILIZER, ELEVATORS, SERVOS & LINKAGES




❑ 1. Cut three arms from a four-armed servo arm included with the elevator servo. Center the servo with your radio system and install the servo arm perpendicular to the servo case. Secure the servo arm with the servo arm screw. Place the servo onto the **servo tray** in the fuselage with the servo spline facing forward. Thread a 2-56 nut and a metal clevis onto a 36" [914mm] pushrod 15 complete turns. Insert the pushrod through the elevator pushrod tube and connect the clevis to the second hole from the center of the servo arm. With the elevator servo now positioned on the servo tray, use the screws that came with the servo to secure it in place. Be sure to harden the screw holes with thin CA.






□ 2. Remove the pushrod and reinsert it from the aft end of the elevator pushrod tube through the **horizontal stabilizer** saddle. Place the elevator joiner rod into the half-circle notches at the aft end of

the stab saddle in the fuselage with the control horn pointing down toward the clevis. Slide the horizontal stab into the saddle in front of the joiner rod. Temporarily (without glue) join the **elevator halves** to the stab with CA hinges. The ends of the joiner rod fit into the holes at the LE of each elevator half.




□ 3. Use the access hole on the underside of the fuselage to connect the clevis to the outer hole of the elevator control horn. A medium-sized flat blade screwdriver can be used to open the clevis and move it onto the control horn. Attach a metal solder clevis to the second hole from the center in the elevator servo arm. Use tape or small clamps to hold the elevators in the neutral position. Mark the elevator pushrod where it will need to be cut shorter to be soldered to the clevis. Before removing the elevators and stab from the fuselage, confirm that both elevator TE are even with each other by looking at the plane from behind. If not, remove the elevators from the stab and bend or “tweak” the joiner rod until they do. Do not attempt to bend the joiner rod while it is installed in the elevators.




□ 4. Temporarily install the wing onto the fuselage using two 1/4-20 nylon wing bolts. Center the stab left and right in the fuselage. Stand back 15 to 20ft [5 to 6m] and check to be sure the stab is parallel to the wing. If necessary, adjust the stab saddle as needed by lightly sanding it until the stab and wing are parallel. Measure the distance from the tip of each wing to the tip of the stab. Adjust the stab until the distance from the tip of the stab to the tip of the wing is equal on both sides. When satisfied with the

position of the stab, use a felt tip marker to mark the outline of the fuselage onto the top and bottom of it.



❑ 5. Remove the elevators and horizontal stab from the fuselage. Remove the covering from both sides of the stab 1/16" [1.6mm] inside the lines you drew. Wipe away the lines with denatured alcohol.

❑ 6. Unhook the clevises from the servo arm and elevator control horn. Remove the pushrod from the fuselage. Cut the pushrod to length and solder the clevis onto the cut end using your mark as a guide. Install a silicone clevis retainer onto the solder clevis. Remove the threaded clevis and 2-56 nut from the other end of the pushrod and insert the threaded end of the pushrod through the aft end of the elevator pushrod tube up to the elevator servo.



How To Solder The Clevis To The Pushrod

1. Where the pushrod will make contact with the solder clevis, roughen the wire with 220-grit sandpaper.
2. Use denatured alcohol to remove any oil residue from the pushrod wire.
3. Apply a couple of drops of flux to the wire. Slide the solder clevis onto the wire. Using a small torch or soldering iron, heat the wire allowing the heated wire to heat the solder clevis. Apply a small amount of solder to the joint. When the

wire and the clevis are hot enough the solder will flow into the joint. Avoid using too much solder causing solder to flow out of the joint and clump. Use just enough solder to make a good joint. Allow the wire and clevis to cool.

4. Put a couple of drops of oil onto a rag and wipe the joint. This will prevent rust from forming on the joint.




❑ 7. Being sure that the elevator joiner rod is still in position in the stab saddle, use 30-minute epoxy to glue the stab into the fuselage being sure the stab is correctly positioned in the stab saddle. Wipe away any excess epoxy with denatured alcohol and let the epoxy cure undisturbed.

IMPORTANT: Make sure you reinstall the elevator pushrod, see step 6.




❑ 8. Roughen the ends of the elevator joiner rod and clean them with alcohol. Insert CA hinges into the

elevator hinge slots. Apply a light coating of epoxy to the ends of the joiner rod and join the elevators to the stab with the hinges. Be sure that the balance tabs on the elevators are centered in the cutouts. When satisfied, apply thin CA to the top and bottom of each hinge to secure the elevators in place. Wipe away any excess epoxy from around the joiner rod.



❑ 9. Connect the solder clevis to the outer hole in the elevator control horn of the elevator joiner wire and slide the silicone clevis retainer to the end of the clevis. Thread a 2-56 nut and threaded clevis back onto the pushrod along with a silicone clevis retainer. Make any adjustments necessary to the clevis so that the elevators are in the neutral position when the servo arm is perpendicular to the servo case. When satisfied, attach the clevis to the second hole from the center of the servo arm, tighten the 2-56 nut against the back of the clevis with threadlocking compound, and slide the silicone clevis retainer to the end of the clevis.


INSTALL THE RUDDER, TAIL WHEEL & LINKAGES



❑ 1. Locate the pieces for the tail wheel assembly. Loosely thread the 3 x 5mm SHCS into the collar hole in the steering arm. Slide the steering arm onto the tail wheel wire and tighten the SHCS against the flat spot in the wire. Be sure that the steering arm is oriented in the same direction as shown in the picture. Slide the tail wheel bracket onto the wire beneath the steering arm. Tighten a 1/8" [3.2mm] wheel collar using a 4-40 set screw onto the wire below the tail wheel bracket. The bracket should still be able to rotate freely on the wire. Secure a brass screw-lock pushrod connector to the linkage hole in the steering arm with a nylon retainer. Loosely thread a 4-40 set screw into the screw-lock pushrod connector.




❑ 2. Coat the barbed posts on the underside of the tail wheel bracket with epoxy or thick CA. Insert the posts into the receiving holes in the **tail wire access hatch** in the fuselage. The end of the tail wire will fit into a bushing that is pre-installed in the fuselage. Secure the assembly with two #2 x 3/8" [9.5mm] self-tapping screws.




❑ 3. Cut three arms from a four-armed servo arm included with the rudder servo. Enlarge the second to outer hole with a 5/64" [2mm] drill bit. Install a .080" ball stud into the inner hole of the servo arm and secure it with a .080" nut with threadlocking compound. Center the servo with your radio system

and install the servo arm perpendicular to the servo case. Secure the servo arm with the servo arm screw. Place the servo onto the servo tray in the fuselage in the position shown with the servo spline facing forward. Attach the servo to the tray with the hardware included with the servo. Be sure to harden the screw holes with thin CA.



❑ 4. Thread a nylon ball cup onto the end of a 2-56 x 36" [914mm] threaded one-end pushrod. Insert the pushrod into the pushrod tube in the fuselage that is inline with the ball stud (closest to the bottom of the fuselage) on the servo arm. Feed the aft end of the pushrod through the brass screw-lock pushrod connector on the tail wire steering arm and out the elevator control horn access hole. Push the ball cup onto the ball stud.


❑ 5. Center the tail wheel wire axle in the neutral position and tighten the set screw in the screw-lock pushrod connector against the tail wheel pushrod. Cut off the excess pushrod 1/2" [13mm] behind the screw-lock pushrod connector.



❑ 6. Fit the **tail wheel hatch cover** in place and secure it with four #2 x 3/8" [9.5mm] screws. Be sure to harden the screw holes with thin CA.





❑ 7. Install the tail wheel onto the tail wheel axle using two 1/8" [3.2mm] wheel collars and two 4-40 set screws. Apply a drop of threadlocking compound to the set screws. Be sure that the wheel rotates on the axle freely. Oil the axle if necessary.



❑ 8. Install the rudder to the fuselage using CA hinges. Temporarily install a metal threaded clevis

onto a 36" [914mm] pushrod 15 complete turns. Insert the pushrod into left pushrod exit slot in the fuselage. Connect the clevis to a nylon control horn and position the horn on the left side of the rudder over the plywood plate, being sure that the holes in the control horn are properly aligned over the rudder hinge line. Mark the locations of the control horn mounting holes. Drill 1/16" [1.6mm] holes at your marks, being sure not to drill through the rudder. Attach the rudder control horn to the rudder using two #2 x 3/8" [9.5mm] self-tapping screws. Remove the screws and harden the holes with thin CA.





❑ 9. Center the rudder in the neutral position and mark the pushrod where it crosses the second to outer hole in the rudder servo arm. Remove the pushrod from the fuselage, bend the pushrod 90 degrees at the mark you made, and cut off the excess pushrod 1/4" [6mm] beyond your mark. Remove the clevis from the pushrod and insert the pushrod into the rudder pushrod tube from the forward end. Hook

the 90° bend into the second to outer hole in the servo arm and secure it with a nylon FasLink. Thread a 2-56 nut, metal clevis, and silicone clevis retainer onto the aft end of the pushrod. Make any necessary adjustments to the clevis position and connect it to the rudder control horn when satisfied. Tighten the 2-56 nut against the back of the clevis with threadlocking compound. Be sure to slide the silicone clevis retainer to the end of the clevis.


INSTALL THE POWER SYSTEM & RECEIVER

GLOW ENGINE INSTALLATION




❑ 1. The fuel tank can be assembled as a two line system consisting of a vent (pressure) line to the muffler and a carb line. Filling and emptying of the tank would need to be done through the carb line, or an optional fuel fill valve (not included). The tank can also be assembled as a three line system having a


vent line, carb line, and fill line. If installing a fill line, puncture the top of the stopper above the sealed off fuel tube hole. The fill and carb lines should extend out 1/2" [13mm] beyond the stopper and the vent line should be bent upwards and left uncut. With the tubes installed in the stopper, fit the stopper plates loosely in place with the 3 x 25mm Phillips screw to hold the assembly together.



❑ 2. Fit the stopper assembly into the tank with the vent line pointing toward the top of the tank, but not touching. The fuel tubing and clunks (fuel pickup) on the carb and fill lines should almost reach the back of the tank but not touch. The clunks must be able to move freely inside the tank when assembled. Adjust the length of the fuel tubing accordingly. When satisfied, tighten the 3 x 25mm screw in the stopper to secure it in place (do not overtighten). Mark the side of the tank that must face up when installed in the plane, and we also suggest marking the tubes in the stopper.






❑ 3. Insert the tank into the fuselage with the correct side facing up. The neck of the tank should pass through the hole in the firewall. Attach a 6" to 7" [152 to 178mm] piece of fuel tubing onto each line coming from the tank.



❑ 4. Using four 8-32 x 1" [25mm] SHCS, four #8 flat washers, four #8 lock washers, and threadlocking compound, attach the engine mount inverted to the firewall. Leave the screws slightly loose. Test fit your engine between the mount halves. Align the centering

mark on the engine mount with the lines on the firewall. Slide the mount halves against the sides of the engine and finish tightening the mount screws.




❑ 5. Position the front of the engine drive washer 6-1/8" [156mm] from the firewall. Mark the location of the engine mount holes onto the mount rails using a Dead Center hole locator. Remove the engine from the mount and use a 8-32 tap and drill set to create



threads in the four mounting holes. Attach the engine to the mount using four 8-32 x 1" [25mm] SHCS, four #8 flat washers, and four #8 lock washers.



❑ 6. Glue the **throttle servo tray** in the location shown. Be sure that the cutout for the throttle servo is on the same side of the plane as the throttle arm on the carburetor.




❑ 7. Cut three arms from a four-armed servo arm. Install a brass screw-lock pushrod connector into the second hole from the center of the remaining arm using a nylon retainer. Loosely thread a 4-40 x 1/8" [3mm] SHCS into the screw-lock pushrod connector. Install the throttle servo into the throttle servo tray with the servo splines toward the rear of the plane. Use your radio system to center the servo and attach the arm perpendicular to the servo case pointing away from the center of the fuselage. Be sure to install the servo arm screw.





❑ 8. Make the necessary bends in the remaining 36" [914mm] pushrod so that it will connect to the throttle arm on your carburetor using a nylon clevis and silicone clevis retainer. If installing the O.S. FS-91 Surpass II four-stroke engine, a "U" bend will need to be made in the pushrod to reach the throttle arm. Be sure that the bends you make are not in the threaded portion of the rod. Some of the threads on the pushrod can be cut off to get the clevis closer to the "U" bend. Fit the aft end of the pushrod through the screw-lock pushrod connector in the throttle servo arm. Make any necessary adjustments to the pushrod position and tighten the screw in the screw-lock pushrod connector when satisfied. Cut off the excess pushrod 1/4" [6mm] beyond the screw-lock pushrod connector.

❑ 9. Test the operation of the throttle servo with your radio system, making sure that the servo can properly open and close the carburetor.

INSTALL THE RECEIVER & BATTERY




❑ 1. Glue the **fuel tank brace** to the receiver tray in the direction shown.




❑ 2. Make two hook and loop straps by overlapping the mating ends by approximately 1" [25mm]. Cut two pieces of foam rubber (not included) to match your receiver and receiver battery pack. Secure the receiver and receiver pack to the receiver tray with the straps and cut them to the necessary length. Feed the antenna and battery lead beneath the air tank tray and secure the radio tray to the fuselage

using four #2 x 3/8" [9.5mm] self-tapping screws and four #2 flat washers. Be sure to harden the screw holes with thin CA.



❑ 3. Install your receiver switch onto the side of the fuselage opposite the muffler and in a location that will not interfere with any of the servos. We used a Great Planes Switch and Charge Jack Mounting Set (GPMM1000). Connect your servos and switch to the receiver and connect the receiver battery to the switch. Be sure to use tape or heat shrink tubing to secure the connection between the switch and the battery.




❑ 4. Install a strain-relief onto the receiver antenna and route it through the antenna tube and out the

back of the fuselage. We used a small piece of fuel tubing glued to the side of the fuselage to hold the antenna out of the way of the elevator servo.


FINISH THE MODEL

INSTALL THE COWL


❑ 1. If you haven't done so already, connect the fuel pickup line to the needle valve on the engine and cut the fill line and pressure line to the proper length. An aluminum fuel line plug is provided for the fill line.




❑ 2. Make the necessary cutouts in the **cowl** to match your engine. In the picture, there is an opening for the engine head, muffler, cooling hole, and needle valve.



❑ 3. Use a felt-tip pen to mark the middle of each **cowl mounting block** just outside the cowl line on the fuselage.



❑ 4. Tape the cowl into position with masking tape. Transfer the marks you made in step 3 onto the cowl 1/4" [6mm] inside the cowl edges.




❑ 5. Drill through the marks on the cowl with a 1/16" [1.6mm] drill bit. Remove the cowl and enlarge the holes in the cowl with a 3/32" [2.4mm] bit. Thread a #2 x 3/8" [9.5mm] self-tapping screw into each cowl mounting block and remove it. Apply a couple drops of

thin CA into each hole to harden the wood. Position the cowl onto the fuselage and shift it to one side in order to install the muffler onto the header pipe. Install the cowl onto the fuselage using seven #2 x 3/8" [9.5mm] self-tapping screws and seven #2 flat washers.




❑ 6. Roughen the edges of the ABS **exhaust stacks** with 220-grit sandpaper. Glue the stacks into the cutouts near the front of the fuselage. There is a left and a right exhaust stack. Be sure that they are glued onto the correct sides of the fuselage. The exhaust stacks should have a slight downward angle when correctly installed.

INSTALL THE COCKPIT & CANOPY




❑ 1. Locate the plywood instrument panel, clear instrument lenses and the two instrument decals.




❑ 2. Remove the backing from the instrument decal that has the instrument faces missing. Attach the decal to the front of the plywood instrument panel aligning the holes in the plywood with the missing instrument faces.

❑ 3. Use a sharp hobby knife to cut out the openings for the clear lenses. You can use a black marker or flat black paint to cover any of the bare wood that is showing.




❑ 4. Attach the clear lenses to the back of the plywood instrument panel by applying a couple of drops of medium CA in the corners of the clear plastic. Do not get the CA close to the lenses. The CA may cause the clear plastic to fog.




❑ 5. Use medium CA to glue the instrument decal with the instrument faces to the back of the clear lenses.



❑ 6. Glue the **instrument panel** in place.



❑ 7. Glue the ABS **radio and battery** at the back of the **cockpit**.



❑ 8. Glue the **pilot figure** and **seat back** to the cockpit floor. For ease of installation, we recommend gluing the seat back to the pilot before installing them into position.




Pilot Figure Base



To provide a larger surface for gluing, install a **plywood base** inside the pilot figure. To do this, trace the outline of the base of the pilot onto a piece of paper. Sketch another line 1/8" [3mm] inside the traced line. Tape the paper to a scrap piece of plywood (not included) and cut out the piece along the inside line you drew. Test fit the piece into the base of the pilot and sand as necessary. Roughen the inside of the pilot figure near the base using

a rotary tool such as a Dremel with a sanding bit or some 220-grit sandpaper. Glue the plywood piece into the base with a mixture of epoxy and Microballoons. When the epoxy has cured, sand away any excess epoxy for a smooth, flat base. A screw can be installed through the cockpit floor and into the plywood piece for extra security after the pilot figure has been glued into the cockpit.




❑ 9. Glue the **canopy** to the fuselage using canopy glue such as J&Z R/C 56 Canopy Glue (JOZR5007).


INSTALL THE PROPELLER & SPINNER



❑ 1. The spinner backplate is drilled to fit a 3/8" [9.5mm] crankshaft. A brass insert is also included for 5/16" [7.9mm] crankshafts. Fit the spinner backplate onto the crankshaft. A flat bottomed spinner nut is provided for use with a two-stroke engine, and a spinner nut is also provided for use with the O.S. .91 four-stroke engine. Install the propeller and prop washer onto the crankshaft and tighten it down with the appropriate spinner nut.




❑ 2. The 4mm spinner bolt may need to be cut shorter depending on your choice of engine installation. Test fit the spinner cone onto the backplate and determine how short the spinner bolt will be. Thread one of the spinner nuts onto the bolt before cutting it shorter in order to straighten any damaged threads that may occur from the cutting process. When satisfied, double check the tightness of the spinner nut, and install the spinner cone onto the backplate using the 4mm spinner bolt.



- ❑ 3. This completes the assembly process!

OPTIONAL PNEUMATIC RETRACTS



Mounting locations are provided in the fuselage for optional pneumatic retract hardware including the air vessel, air valve, and air valve servo. Tabs are designed into the former at the front of the air tank for securing it with rubber bands. Cutout the opening for

a Robart small air tank along the perforations in the air tank tray. Detailed installation instructions are not provided for installing pneumatic retracts, however the installation process for the gear is similar to the mechanical installation. The mechanical retract pushrods will need to be replaced with air lines. Be sure to follow the instructions included with the pneumatic retract kit.

APPLY THE DECALS


- ❑ 1. Use scissors or a sharp hobby knife to cut the decals from the sheet.
- ❑ 2. Be certain the model is clean and free from oily fingerprints and dust. Prepare a dishpan or small bucket with a mixture of liquid dish soap and warm water—about one teaspoon of soap per gallon of water. Submerge the decal in the soap and water and peel off the paper backing. **Note:** Even though the decals have a “sticky-back” and are not the water transfer type, submersing them in soap & water allows accurate positioning and reduces air bubbles underneath.
- ❑ 3. Position a decal on the model where desired. Holding the decal down, use a paper towel to wipe most of the water away.
- ❑ 4. Use a piece of soft balsa wrapped in a paper towel or something similar to squeegee remaining water from under the decal. Apply the rest of the decals the same way.

GET THE MODEL READY TO FLY

CHECK THE CONTROL DIRECTIONS


- ❑ 1. Turn on the transmitter and receiver and center the trims. If necessary, remove the servo arms from the servos and reposition them so they are centered. Reinstall the screws that hold on the servo arms.

- ❑ 2. With the transmitter and receiver still on, check all the control surfaces to see if they are centered. If necessary, adjust the clevises on the pushrods to center the control surfaces.



- ❑ 3. Make certain that the control surfaces and the carburetor respond in the correct direction as shown in the diagram. If any of the controls respond in the wrong direction, use the servo reversing in the transmitter to reverse the servos connected to those controls. Be certain the control surfaces have remained centered. Adjust if necessary.

SET THE CONTROL THROWS



Use a Great Planes AccuThrow (or a ruler) to accurately measure and set the control throw of each control surface as indicated in the chart that follows. If your radio does not have dual rates, we recommend setting the throws at the **low rate** setting.

Note: The throws are measured at the **widest part** of the elevators, rudder and ailerons.

These are the recommended control surface throws:

	High Rate	Low Rate
ELEVATOR:	5/8" [16mm] up 5/8" [16mm] down	3/8" [9.5mm] up 3/8" [9.5mm] down
RUDDER:	1-1/8" [29mm] right 1-1/8" [29mm] left	7/8" [22mm] right 7/8" [22mm] left
AILERONS:	11/16" [17.5mm] up 11/16" [17.5mm] down	1/2" [13mm] up 1/2" [13mm] down
FLAPS:	1-1/4" [32mm] down (full flap)	5/8" [16mm] down (1/2 flap)

IMPORTANT: The P-51 Mustang ARF has been **extensively** flown and tested to arrive at the throws at which it flies best. Flying your model at these throws will provide you with the greatest chance for successful first flights. If, after you have become accustomed to the way the P-51 flies, you would like to change the throws to suit your taste, that is fine. However, too much control throw could make the model difficult to control, so remember, "more is not always better."

FLIGHT NOTE: The high rate elevator is more than enough throw for normal flight. However, the extra throw helps keep the nose up when taking off from rough grass. Once the plane is in the air, the low rate elevator is recommended. Also, 20% to 30% exponential can be put in the high rate elevator to reduce the sensitivity.

BALANCE THE MODEL (C.G.)

More than any other factor, the **C.G.** (balance point) can have the **greatest** effect on how a model flies, and may determine whether or not your first flight will be successful. If you value this model and wish to enjoy it for many flights, **DO NOT OVERLOOK THIS IMPORTANT PROCEDURE.** A model that is not properly balanced will be unstable and possibly unflyable.

At this stage the model should be in ready-to-fly condition with all of the systems in place including the engine, landing gear, and the radio system.

❑ 1. Use a felt-tip pen or 1/8" [3mm]-wide tape to accurately mark the C.G. on the top of the wing on both sides of the fuselage. The C.G. is located 5-5/8" [143mm] back from the LE of the wing where it meets the fuselage sides.

This is where your model should balance for the first flights. Later, you may wish to experiment by shifting the C.G. up to 1/4" [6mm] forward or 1/4" [6mm] back to change the flying characteristics. Moving the C.G. forward may improve the smoothness and stability, but the model may then require more speed for takeoff and make it more difficult to slow for landing. Moving the C.G. aft makes the model more maneuverable, but could also cause it to become too difficult to control. In any case, **start at the recommended balance point** and do not at any time balance the model outside the specified range.



❑ 2. With the wing attached to the fuselage, all parts of the model installed (ready to fly) and an empty fuel tank, place the model upside-down on a Great Planes C.G. Machine, or lift it upside-down at the balance point you marked.

❑ 3. If the tail drops, the model is "tail heavy" and the battery pack and/or receiver must be shifted forward or weight must be added to the nose to balance. If the nose drops, the model is "nose heavy" and the battery pack and/or receiver must be shifted aft or weight must be added to the tail to balance. If possible, relocate the battery pack and receiver to minimize or eliminate any additional ballast required. If additional weight is required, nose weight may be easily added by using a "spinner weight" (GPMQ4645 for the 1 oz. [28g] weight, or GPMQ4646 for the 2 oz. [57g] weight). If spinner weight is not practical or is not enough, use Great

Planes (GPMQ4485) “stick-on” lead. A good place to add stick-on nose weight is to the firewall (don’t attach weight to the cowl—it is not intended to support weight). Begin by placing incrementally increasing amounts of weight on the bottom of the fuselage over the firewall until the model balances. Once you have determined the amount of weight required, it can be permanently attached. If required, tail weight may be added by cutting open the bottom of the fuselage and gluing it permanently inside.

Note: Do not rely upon the adhesive on the back of the lead weight to permanently hold it in place. Over time, fuel and exhaust residue may soften the adhesive and cause the weight to fall off. Use #2 sheet metal screws, RTV silicone or epoxy to permanently hold the weight in place.

4. **IMPORTANT:** If you found it necessary to add any weight, recheck the C.G. after the weight has been installed.

BALANCE THE MODEL Laterally

1. With the wing level, have an assistant help you lift the model by the engine propeller shaft and the bottom of the fuselage under the TE of the fin. Do this several times.

2. If one wing always drops when you lift the model, it means that side is heavy. Balance the airplane by adding weight to the other wing tip. An airplane that has been laterally balanced will track better in loops and other maneuvers.

PREFLIGHT

IDENTIFY YOUR MODEL

No matter if you fly at an AMA sanctioned R/C club site or if you fly somewhere on your own, you should always have your name, address, telephone number and AMA number on or inside your model. It is required at all AMA R/C club flying sites and AMA


sanctioned flying events. Fill out the identification tag on page 29 (or on the decal sheet) and place it on or inside your model.

CHARGE THE BATTERIES

Follow the battery charging instructions that came with your radio control system to charge the batteries. You should always charge your transmitter and receiver batteries the night before you go flying, and at other times as recommended by the radio manufacturer.

CAUTION: Unless the instructions that came with your radio system state differently, the **initial** charge on **new** transmitter and receiver batteries should be done for 15 hours **using the slow-charger that came with the radio system.** This will “condition” the batteries so that the next charge may be done using the fast-charger of your choice. If the initial charge is done with a fast-charger the batteries may not reach their full capacity and you may be flying with batteries that are only partially charged.

BALANCE PROPELLERS



Carefully balance your propeller and spare propellers before you fly. An unbalanced prop can be the single most significant cause of vibration that can damage your model. Not only will engine mounting screws and bolts loosen, possibly with disastrous effect, but vibration may

also damage your radio receiver and battery. Vibration can also cause your fuel to foam, which will, in turn, cause your engine to run hot or quit.

We use a Top Flite Precision Magnetic Prop Balancer (TOPQ5700) in the workshop and keep a Great Planes Fingertip Prop Balancer (GPMQ5000) in our flight box.

GROUND CHECK

If the engine is new, follow the engine manufacturer’s instructions to break-in the engine. After break-in, confirm that the engine idles reliably, transitions smoothly and rapidly to full power and maintains full power—indefinitely. After you run the engine on the model, inspect the model closely to make sure all screws remained tight, the hinges are secure, the prop is secure and all pushrods and connectors are secure.

RANGE CHECK

Ground check the operational range of your radio before the first flight of the day. With the transmitter antenna collapsed and the receiver and transmitter on, you should be able to walk at least 100 feet away from the model and still have control. Have an assistant stand by your model and, while you work the controls, tell you what the control surfaces are doing. Repeat this test with the engine running at various speeds with an assistant holding the model, using hand signals to show you what is happening. If the control surfaces do not respond correctly, **do not fly!** Find and correct the problem first. Look for loose servo connections or broken wires, corroded wires on old servo connectors, poor solder joints in your battery pack or a defective cell, or a damaged receiver crystal from a previous crash.

ENGINE SAFETY PRECAUTIONS

Failure to follow these safety precautions may result in severe injury to yourself and others.

Keep all engine fuel in a safe place, away from high heat, sparks or flames, as fuel is very flammable. Do not smoke near the engine or fuel; and remember that engine exhaust gives off a great deal of deadly carbon monoxide. Therefore, do not run the engine in a closed room or garage.

Get help from an experienced pilot when learning to operate engines.

Use safety glasses when starting or running engines.

Do not run the engine in an area of loose gravel or sand; the propeller may throw such material in your face or eyes.

Keep your face and body as well as all spectators away from the plane of rotation of the propeller as you start and run the engine.

Keep these items away from the prop: loose clothing, shirt sleeves, ties, scarfs, long hair or loose objects such as pencils or screwdrivers that may fall out of shirt or jacket pockets into the prop.

Use a "chicken stick" or electric starter to start the engine. Do not use your fingers to flip the propeller. Make certain the glow plug clip or connector is secure so that it will not pop off or otherwise get into the running propeller.

Make all engine adjustments from behind the rotating propeller.

The engine gets hot! Do not touch it during or right after operation. Make sure fuel lines are in good condition so fuel will not leak onto a hot engine, causing a fire.

To stop a glow engine, cut off the fuel supply by closing off the fuel line or following the engine manufacturer's

recommendations. Do not use hands, fingers or any other body part to try to stop the engine. To stop a gasoline powered engine, an on/off switch should be connected to the engine coil. Do not throw anything into the propeller of a running engine.

AMA SAFETY CODE (EXCERPTS)

Read and abide by the following excerpts from the Academy of Model Aeronautics Safety Code. For the complete Safety Code refer to *Model Aviation* magazine, the AMA web site or the Code that came with your AMA license.

GENERAL

1) I will not fly my model aircraft in sanctioned events, air shows, or model flying demonstrations until it has been proven to be airworthy by having been previously, successfully flight tested.

2) I will not fly my model aircraft higher than approximately 400 feet within 3 miles of an airport without notifying the airport operator. I will give right-of-way and avoid flying in the proximity of full-scale aircraft. Where necessary, an observer shall be utilized to supervise flying to avoid having models fly in the proximity of full-scale aircraft.

3) Where established, I will abide by the safety rules for the flying site I use, and I will not willfully and deliberately fly my models in a careless, reckless and/or dangerous manner.

5) I will not fly my model unless it is identified with my name and address or AMA number, on or in the model. **Note:** This does not apply to models while being flown indoors.

7) I will not operate models with pyrotechnics (any device that explodes, burns, or propels a projectile of any kind).

RADIO CONTROL

1) I will have completed a successful radio equipment ground check before the first flight of a new or repaired model.

2) I will not fly my model aircraft in the presence of spectators until I become a qualified flier, unless assisted by an experienced helper.

3) At all flying sites a straight or curved line(s) must be established in front of which all flying takes place with the other side for spectators. Only personnel involved with flying the aircraft are allowed at or in the front of the flight line. Intentional flying behind the flight line is prohibited.

4) I will operate my model using only radio control frequencies currently allowed by the Federal Communications Commission.

5) I will not knowingly operate my model within three miles of any pre-existing flying site except in accordance with the frequency sharing agreement listed (in the complete AMA Safety Code).

9) Under no circumstances may a pilot or other person touch a powered model in flight; **nor should any part of the model other than the landing gear, intentionally touch the ground, except while landing.**

CHECK LIST

During the last few moments of preparation your mind may be elsewhere anticipating the excitement of the first flight. Because of this, you may be more likely to overlook certain checks and procedures that should be performed before the model is flown. To help avoid this, a check list is provided to make sure these important areas are not overlooked. Many are covered in the instruction manual, so where appropriate, refer to the manual for complete instructions. Be sure to check the items off as they are completed.

- 1. Fuelproof all areas exposed to fuel or exhaust residue such as the cowl mounting blocks, wing saddle area, etc.
- 2. Check the C.G. according to the measurements provided in the manual.
- 3. Be certain the battery and receiver are securely mounted in the fuselage. Simply stuffing them into place with foam rubber is not sufficient.
- 4. Extend your receiver antenna and make sure it has a strain relief inside the fuselage to keep tension off the solder joint inside the receiver.
- 5. Balance your model *laterally* as explained in the instructions.
- 6. Use threadlocking compound to secure critical fasteners such as the set screws that hold the wheel axles to the struts, screws that hold the carburetor arm (if applicable), screw-lock pushrod connectors, etc.
- 7. Add a drop of oil to the axles so the wheels will turn freely.
- 8. Make sure all hinges are **securely** glued in place.
- 9. Reinforce holes for wood screws with thin CA where appropriate (servo mounting screws, cowl mounting screws, etc.).
- 10. Confirm that all controls operate in the correct direction and the throws are set up according to the manual.
- 11. Make sure there are silicone retainers on all the clevises and that all servo arms are secured to the servos with the screws included with your radio.

- 12. Secure connections between servo wires and Y-connectors or servo extensions, and the connection between your battery pack and the on/off switch with vinyl tape, heat shrink tubing or special clips suitable for that purpose.
- 13. Make sure any servo extension cords you may have used do not interfere with other systems (servo arms, pushrods, etc.).
- 14. Secure the pressure tap (if used) to the muffler with high temp RTV silicone, threadlocking compound or J.B. Weld.
- 15. Make sure the fuel lines are connected and are not kinked.
- 16. Use an incidence meter to check the wing for twists and attempt to correct before flying.
- 17. Balance your propeller (and spare propellers).
- 18. Tighten the propeller nut and spinner.
- 19. Place your name, address, AMA number and telephone number on or inside your model.
- 20. Cycle your receiver battery pack (if necessary) and make sure it is fully charged.
- 21. If you wish to photograph your model, do so before your first flight.
- 22. Range check your radio when you get to the flying field.

FLYING

The P-51 Mustang ARF is a great-flying model that flies smoothly and predictably. The P-51 Mustang ARF does not, however, possess the self-recovery characteristics of a primary R/C trainer and should be flown only by experienced R/C pilots.

FUEL MIXTURE ADJUSTMENTS

A fully cowled engine may run at a higher temperature than an un-cowled engine. For this reason, the fuel mixture should be richened so the engine runs at about 200 rpm below peak speed. By running the engine slightly rich, you will help prevent dead-stick landings caused by overheating.

CAUTION (THIS APPLIES TO ALL R/C AIRPLANES): If, while flying, you notice an alarming or unusual sound such as a low-pitched “buzz,” this may indicate control surface *flutter*. Flutter occurs when a control surface (such as an aileron or elevator) or a flying surface (such as a wing or stab) rapidly vibrates up and down (thus causing the noise). In extreme cases, if not detected immediately, flutter can actually cause the control surface to detach or the flying surface to fail, thus causing loss of control followed by an impending crash. The best thing to do when flutter is detected is to slow the model **immediately** by reducing power, then land as soon as safely possible. Identify which surface fluttered (so the problem may be resolved) by checking all the servo grommets for deterioration or signs of vibration. Make certain all pushrod linkages are secure and free of play. If it fluttered once, under similar circumstances it will probably flutter again unless the problem is fixed. Some things which can cause flutter are; Excessive hinge gap; Not mounting control horns solidly; Poor fit of clevis pin in horn; Side-play of wire pushrods caused by large bends; Excessive free play in servo gears; Insecure servo mounting; and one of the most prevalent causes of flutter; Flying an over-powered model at excessive speeds.

TAKEOFF

Before you get ready to takeoff, see how the model handles on the ground by doing a few practice runs at **low speeds** on the runway. Hold “up” elevator to keep the tail wheel on the ground. If necessary, adjust the tail wheel so the model will roll straight down the runway. If you need to calm your nerves before the maiden flight, shut the engine down and bring the model back into the pits. Top off the fuel, then check all fasteners and control linkages for peace of mind.

Remember to takeoff into the wind. When you're ready, point the model straight down the runway, hold a bit of up elevator to keep the tail on the ground to maintain tail wheel steering, then gradually advance

the throttle. As the model gains speed decrease up elevator allowing the tail to come off the ground. One of the most important things to remember with a tail dragger is to always be ready to apply **right** rudder to counteract engine torque. Gain as much speed as your runway and flying site will practically allow before gently applying up elevator, lifting the model into the air. At this moment it is likely that you will need to apply more right rudder to counteract engine torque. Be smooth on the elevator stick, allowing the model to establish a **gentle** climb to a safe altitude before turning into the traffic pattern.

FLIGHT

For reassurance and to keep an eye on other traffic, it is a good idea to have an assistant on the flight line with you. Tell him to remind you to throttle back once the plane gets to a comfortable altitude. While full throttle is usually desirable for takeoff, most models fly more smoothly at reduced speeds.

Take it easy with the P-51 Mustang ARF for the first few flights, gradually getting acquainted with it as you gain confidence. Adjust the trims to maintain straight and level flight. After flying around for a while, and while still at a safe altitude with plenty of fuel, practice slow flight and execute practice landing approaches by reducing the throttle to see how the model handles at slower speeds. Also, at slower speeds, lower the flaps and note any trim change. Add power to see how she climbs as well. Continue to fly around, executing various maneuvers and making mental notes (or having your assistant write them down) of what trim or C.G. changes may be required to fine tune the model so it flies the way you like. Mind your fuel level, but use this first flight to become familiar with your model before landing.

LANDING

To initiate a landing approach, lower the throttle and flaps while on the downwind leg. Allow the nose of the model to pitch downward to gradually bleed off altitude. Continue to lose altitude, but maintain

airspeed by keeping the nose down as you turn onto the crosswind leg. Make your final turn toward the runway (into the wind) keeping the nose down to maintain airspeed and control. Level the attitude when the model reaches the runway threshold, modulating the throttle as necessary to maintain your glide path and airspeed. If you are going to overshoot, smoothly advance the throttle (always ready on the right rudder to counteract torque) and climb out to make another attempt. When you're ready to make your landing flare and the model is a foot or so off the deck, smoothly increase up elevator until it gently touches down. Once the model is on the runway and has lost flying speed, hold up elevator to place the tail on the ground, regaining tail wheel control.

One final note about flying your model. Have a goal or flight plan in mind for **every** flight. This can be learning a new maneuver(s), improving a maneuver(s) you already know, or learning how the model behaves in certain conditions (such as on high or low rates). This is not necessarily to improve your skills (*though it is never a bad idea!*), but more importantly so you do not surprise yourself by impulsively attempting a maneuver and suddenly finding that you've run out of time, altitude or airspeed. Every maneuver should be deliberate, not impulsive. For example, if you're going to do a loop, check your altitude, mind the wind direction (anticipating rudder corrections that will be required to maintain heading), remember to throttle back at the top, and make certain you are on the desired rates (high/low rates). A flight plan greatly reduces the chances of crashing your model just because of poor planning and impulsive moves. **Remember to think.**

Have a ball! But always stay in control and fly in a safe manner.

GOOD LUCK AND GREAT FLYING!

This model belongs to:

Name

Address

City, State, Zip

Phone number

AMA number

Make a copy of this identification tag and put it on or inside your model.

OTHER ITEMS AVAILABLE FROM TOP FLITE



Top Flite Giant-Scale Gold Edition™ B-25J Mitchell

This B-25J Mitchell has plenty of room for scaling out...and Top Flite makes the most of it, while keeping assembly time to just 50 hours. The functional fiberglass gear doors can be locked fully deployed to accommodate the supplied fixed gear – or add Robart retracts (available separately) for maximum realism. Fly the B-25J on a pair of .40s or install two .70 4-strokes for more power. Strong, laser-cut ply nacelles ensure perfect alignment. The working split flaps are big advantages for small-field flying, allowing shorter takeoff rolls and slower landing speeds. Wing sections remove from lightweight aluminum joiner tubes for easy transport. For easy at-field reassembly, take along the included foam/PVC pipe fuselage cradle! **TOPA0980**



Top Flite Gold Edition Beechcraft Staggerwing

Unveiled in 1932, Beech Aircraft Corporation's Staggerwing was instantly distinguished by its forward-projecting lower wing. The Staggerwing continues to impress as this 1.60-size sport-scale ARF – a model that sets new high standards for simplicity of scale detail! Top Flite uses only the best materials – premium woods, high-quality fiberglass, and MonoKote covering – and the finest engineering. For easy transport, the wings disassemble into four manageable pieces. At the field, the halves plug into joiner tubes and secure with nylon bolts. The fiberglass wing struts install easily as well, and authentic-looking stringers perfectly complement rivets and panel lines molded into the fiberglass fuselage. Elevator and rudder linkages mount internally to preserve the scale profile. Add a 1.60-size 2- or 4-stroke engine and you'll have plenty of muscle for powering through the air! **TOPA905**

